Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nobo 1902642

Nobo 1902642 Classic Magnetic Dry Erase Whiteboard User Manual

Model: 1902642 | Dimensions: 900 x 600 mm

Introduction

This manual provides essential instructions for the proper setup, operation, and maintenance of your Nobo 1902642 Classic Magnetic Dry Erase Whiteboard. Please read these instructions carefully before installation and use to ensure optimal performance and longevity of your product.

Setup

Package Contents

- 1 x Nobo Classic Magnetic Dry Erase Whiteboard
- Mounting Hardware
- 1 x Dry Erase Marker

Installation Instructions

The Nobo Classic Whiteboard is designed for easy wall mounting, either horizontally or vertically. Drilling is required for secure installation.

1. **Select Location:** Choose a suitable wall location, ensuring sufficient space for the whiteboard and user access.
2. **Mark Drilling Points:** Hold the whiteboard against the wall in the desired orientation (horizontal or vertical). Use a pencil to mark the positions for the mounting screws. The whiteboard features pre-drilled holes in the frame.
3. **Drill Holes:** Using an appropriate drill bit for your wall type, drill holes at the marked points.
4. **Insert Wall Plugs:** Insert the provided wall plugs into the drilled holes.
5. **Mount Whiteboard:** Align the whiteboard with the wall plugs and secure it using the provided screws. The screws are designed to be hidden by corner covers for a clean finish.
6. **Attach Marker Tray:** Secure the removable marker tray to the bottom edge of the whiteboard.



Image: The Nobo Classic Magnetic Dry Erase Whiteboard, 900 x 600 mm, mounted on a wall, showcasing its aluminum frame and clean design.

Operating Instructions

Using the Dry Erase Surface

The whiteboard features a durable lacquered steel surface designed for use with dry erase markers. Write clearly on the surface using the provided marker or any compatible dry erase markers.

Magnetic Functionality

The steel surface is magnetic, allowing you to attach notes, documents, or other items using magnets (magnets are not included). This feature is ideal for displaying announcements or important information.

Marker Tray

The removable tray provides convenient storage for your dry erase markers and an eraser, keeping them readily accessible during use.



Image: A Nobo whiteboard in an office environment, demonstrating its use for collaboration and visual communication among a group of people.

Maintenance

To ensure the longevity and optimal performance of your whiteboard, frequent cleaning is recommended.

- **Daily Cleaning:** After each use, erase the whiteboard thoroughly with a dry eraser.
- **Deep Cleaning:** For stubborn marks, ink stains, or ghosting, use a specialized whiteboard cleaning spray or a damp cloth with a mild cleaning solution. Some users have found baby wipes to be effective for removing marks and restoring the surface.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or sharp objects on the whiteboard surface, as these can damage the lacquered finish.
- **Frame Care:** Wipe the aluminum frame with a soft, damp cloth to keep it clean.

Troubleshooting

Marker Stains / Ghosting

If marker residue or ghosting appears after erasing, it indicates that the surface requires a deeper clean. Refer to the 'Maintenance' section for detailed cleaning instructions, including the use of specialized cleaners or baby wipes.

Unstable Mounting

Ensure all mounting screws are securely tightened and that appropriate wall plugs were used for your wall type. If the

whiteboard feels loose, re-check the installation steps.

Specifications

Feature	Detail
Model Number	1902642
Dimensions (H x W)	900 x 600 mm
Product Dimensions (L x W x H)	102 x 71 x 2.6 cm
Item Weight	3.25 Kilograms
Material	Lacquered Steel (surface), Aluminum (frame)
Color	White
Mounting Type	Wall Mount

Warranty and Support

Warranty Information

For detailed warranty information regarding your Nobo 1902642 Whiteboard, please refer to the manufacturer's official website or contact Nobo customer support directly. Warranty terms may vary by region and retailer.

Customer Support

If you encounter any issues not covered in this manual or require further assistance, please contact Nobo customer support. Contact details can typically be found on the official Nobo website or on the product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004HV5QIY

More documents and user manuals: **https://manuals.plus/**