BRIO 33028

BRIO Classic Figure 8 Train Set (Model 33028) Instruction Manual

Model: 33028 | Brand: BRIO

Introduction

The BRIO Classic Figure 8 Set is a 22-piece wooden toy train set designed to provide engaging and imaginative play for children aged 2 and up. This set is crafted from FSC-certified wood and other sustainable resources, ensuring durability and adherence to responsible forestry practices. It is fully compatible with other BRIO wooden railway toys, allowing for expansion and varied track configurations.
This manual provides essential information for setting up, operating, and maintaining your BRIO Classic Figure 8 Train Set.

Included Components

Your BRIO Classic Figure 8 Set includes the following 22 pieces:

- 1 x Engine
- 2 x Cargo Wagons
- 1 x Station
- 1 x Bridge
- 17 x Track Sections (curved)
- 3 x Trees



Image: All 22 components of the BRIO Classic Figure 8 Set, including the engine, two cargo wagons, station, bridge, track sections, and trees.

Setup Instructions

Follow these steps to assemble your BRIO Classic Figure 8 Train Set:

1. **Unpack Components:** Carefully remove all 22 pieces from the packaging.
2. **Assemble the Figure 8 Track:**
    - Connect the curved track sections to form two interlocking circles, creating a figure-eight shape. The track pieces are designed for easy interlocking.
    - Place the red bridge piece at the intersection where the two circles meet. Ensure the track pieces align smoothly with the bridge.
3. **Position Accessories:**
    - Place the station next to one of the track sections.

- Arrange the three trees around the track as desired to create a scenic environment.

4. **Place the Train:** Connect the engine to the two cargo wagons using their magnetic connections. Place the assembled train onto any part of the track.



Image: An assembled BRIO Classic Figure 8 Set with a child playing, demonstrating the completed track layout.

Setup Video Guide

Your browser does not support the video tag.

Video: A product overview video demonstrating the assembly and features of the BRIO Classic Figure 8 Set.

Operating Instructions

The BRIO Classic Figure 8 Set is designed for manual operation, encouraging interactive play and motor skill development.

1. **Move the Train:** Gently push the engine and wagons along the wooden tracks. The smooth design allows for easy movement.
2. **Magnetic Connections:** The engine and wagons connect using magnets, making it simple to attach and detach them.
3. **Interactive Play:** Use the station and trees to create various play scenarios. Stop the train at the station, or guide it through a forest of trees.
4. **Expand Your Railway:** This set is compatible with other BRIO World railway products. Connect additional tracks, trains, and accessories to expand your railway system.



Image: A close-up view of the BRIO train cars, highlighting their magnetic connections for easy coupling.

Product Demonstration Video

Your browser does not support the video tag.

Video: A demonstration video showcasing the BRIO World - 33028 Classic Figure 8 set in action, highlighting its play features.

Maintenance and Care

To ensure the longevity and safety of your BRIO Classic Figure 8 Set, follow these maintenance guidelines:

- **Cleaning:** Wipe all wooden components with a damp cloth. Avoid using harsh chemicals or abrasive cleaners, as these can damage the wood and paint.
- **Storage:** Store the set in a dry place away from direct sunlight and extreme temperatures to prevent warping or fading of the wood.
- **Inspection:** Periodically inspect all pieces for any signs of wear, damage, or loose parts. Discontinue use if any part is broken or damaged.
- **Safety:** Ensure all pieces are clean and free from debris before and after play.



Image: A close-up of the wooden track and train, emphasizing the quality and material for maintenance purposes.

Troubleshooting

If you encounter any issues with your BRIO Classic Figure 8 Set, refer to the following common solutions:

- **Track Pieces Don't Connect Smoothly:**

- Ensure all track pieces are oriented correctly. BRIO tracks often have male and female connectors that must align.
- Check for any debris or damage in the connectors.
- Ensure the play surface is flat and even. Uneven surfaces can cause misalignment.

- **Train Derails Frequently:**
  - Verify that the track is assembled correctly and all connections are secure.
  - Check the train wheels for any obstructions or damage.
  - Ensure the train is placed properly on the tracks, with all wheels seated in the grooves.

- **Magnetic Connections are Weak:**
  - Ensure the magnetic surfaces are clean and free from dust or small particles.
  - Magnets are designed to connect in specific orientations; try flipping one of the train cars if they repel.

Specifications

Feature	Detail
Brand Name	BRIO
Model Name	Classic Figure 8 Set
Model Number	33028
Age Range Description	Kid (Minimum Age: 24 Months, Maximum Age: 72 Months)
Included Components	Bridge (1), Cargo Wagon (2), Engine, Station, Track (17)
Number of Pieces	22
Material Type	Wood
Item Dimensions	33.46 x 17.72 x 0.01 inches
Item Weight	1140 Grams
Power Source	Manual
Battery Description	No batteries required
Assembly Required	No (Minimal assembly for track layout)
Compatibility Options	BRIO wooden toy train sets and tracks
Color	Green (referring to station/trees)

Warranty Information

BRIO offers a **Lifetime Warranty Against Manufacturer's Defects** for this product. Please retain your proof of purchase for any warranty claims. For detailed information on warranty terms and conditions, please visit the official BRIO website or contact customer support.

Customer Support

For further assistance, questions, or to report any issues with your BRIO Classic Figure 8 Set, please contact BRIO customer support through their official website or the contact information provided on the product packaging.

© 2026 BRIO. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question