Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia C1-01

Nokia C1-01 Mobile Phone User Manual

Model: C1-01

Introduction

This user manual provides comprehensive instructions for the Nokia C1-01 mobile phone. Designed for essential communication, the Nokia C1-01 offers reliable performance for calls, messaging, and basic multimedia functions. Please read this manual carefully to ensure proper use and maintenance of your device.



Figure 1: Nokia C1-01 Mobile Phone. This image displays the Nokia C1-01 mobile phone in dark grey, highlighting its compact design, clear display, and traditional alphanumeric keypad. The screen shows the current time, date, and network status.

Setup

Follow these steps to prepare your Nokia C1-01 for first use.

1. Inserting the SIM Card

1. Turn off the phone and remove the back cover.
2. Locate the SIM card slot.
3. Insert the SIM card with the gold contacts facing down and the cut corner aligned with the slot.
4. Ensure the SIM card is securely in place.

2. Inserting the Battery

1. Align the battery contacts with the contacts in the battery compartment.

2. Gently press the battery into place until it clicks.
3. Replace the back cover.

3. Charging the Battery

1. Connect the charger to a power outlet.
2. Plug the charger connector into the charging port on your phone.
3. Allow the phone to charge fully before first use. A full charge typically takes a few hours.

4. Inserting a MicroSD Card (Optional)

The Nokia C1-01 supports microSD cards up to 32 GB for expanded storage.

1. Turn off the phone and remove the back cover.
2. Locate the microSD card slot.
3. Insert the microSD card into the slot until it locks into place.
4. Replace the back cover.

Operating Instructions

This section covers the primary functions and features of your Nokia C1-01.

Making Calls and Sending Messages

- **Making a Call:** Enter the phone number using the keypad and press the green call key.
- **Answering a Call:** Press the green call key when the phone rings.
- **Ending a Call:** Press the red end call key.
- **Sending a Text Message (SMS):** Go to *Menu > Messaging > Create message*, type your message, enter the recipient's number, and send.
- **Sending a Multimedia Message (MMS):** Attach images or videos to your message via the messaging menu.

Messaging and Email

The Nokia C1-01 supports various messaging options:

- **Nokia Messaging:** Connect to your personal email accounts.
- **Ovi Chat:** Use the instant messaging application to stay in touch.
- **Ovi Mail:** Access your free email account from Nokia directly on your device.

Internet Connectivity

Access the internet via GPRS for browsing, searching, and sharing.

- **Mobile Web Browser:** Navigate to *Menu > Internet* to launch the browser.
- The 1.8-inch display is designed to show web pages clearly.

Camera and Photos

Capture moments with the built-in camera.

- **Taking Photos:** Access the camera from the menu.
- **Sharing:** Share pictures and videos via MMS, email, Bluetooth, or a microUSB connector cable.

Music and Radio

Enjoy your favorite audio content on the go.

- **FM Radio:** Tune in to radio stations.
- **Music Player:** Play your stored music tracks.
- **Audio Output:** Connect 3.5 mm or Bluetooth headphones, or use the integrated stereo speakers.
- Store more music with support for up to 32 GB of expandable memory.

Nokia Ovi Life Tools

Access useful information and services:

- Receive agricultural news and daily weather reports.
- Access general knowledge and career advice.
- Stay updated with entertainment news and daily horoscopes.

Maintenance

Proper care ensures the longevity and optimal performance of your Nokia C1-01.

- **Battery Care:** To maximize battery life, avoid exposing the phone to extreme temperatures. Charge the battery regularly, but avoid overcharging.
- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid using harsh chemicals or abrasive materials.
- **Storage:** When not in use for extended periods, store the phone in a cool, dry place. Remove the battery if storing for a very long time.
- **Water and Dust:** This phone is not water or dust resistant. Keep it away from liquids and dusty environments.

Troubleshooting

If you encounter issues with your Nokia C1-01, refer to the following common solutions.

Problem	Possible Solution
Phone does not turn on	Ensure the battery is correctly inserted and charged. Try charging the phone for at least 30 minutes.
Cannot make or receive calls	Check if the SIM card is properly inserted. Verify that you have network signal. Contact your service provider if the issue persists.
Poor battery life	Reduce screen brightness. Close unused applications. Limit background data usage. Ensure the battery is not old or damaged.
Keypad unresponsive	Restart the phone. Ensure no physical obstruction or damage to the keypad.
Cannot connect to internet	Check GPRS settings with your service provider. Ensure mobile data is enabled.

If these solutions do not resolve the issue, please refer to the support section or contact Nokia customer service.

Specifications

Key technical specifications for the Nokia C1-01 mobile phone.

- **Model Number:** C1-01
- **Brand:** Nokia
- **Dimensions:** 1.4 x 4.5 x 10.8 cm; 150 g

- **Screen Size:** 1.8 Inches
- **Operating System:** Symbian
- **Memory Storage Capacity:** Up to 32 GB (via microSD card)
- **Wireless Carrier:** Unlocked
- **Cellular Technology:** 2G
- **Battery:** 1 Lithium Ion battery required
- **Manufacturer:** Nokia
- **First Available:** 16 February 2011

Warranty and Support

For warranty information, please refer to the documentation provided at the time of purchase or contact your retailer. Warranty terms and conditions may vary by region and seller.
For further support, technical assistance, or service inquiries, please visit the official Nokia support website or contact their customer service helpline in your region. Keep your product's model number and serial number handy when seeking support.

© 2024 Nokia. All rights reserved.
This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B004OBZQ96

More documents and user manuals: **https://manuals.plus/**