Crock-Pot CPSCVC60LL-S

Crock-Pot 6 Quart Cook & Carry Programmable Slow Cooker

Model: CPSCVC60LL-S

Brand: Crock-Pot

Introduction

The Crock-Pot 6 Quart Cook & Carry Programmable Slow Cooker is designed for convenient and mess-free cooking and transport. This appliance features a digital timer, secure locking lid, and ample capacity to serve large gatherings. Its intelligent temperature settings ensure your food is cooked perfectly and kept warm automatically.



Figure 1: Crock-Pot 6 Quart Cook & Carry Programmable Slow Cooker.

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons. Always read all instructions before using this product.

- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or heating base in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner.
- The stoneware and glass lid are safe for use in the oven up to 400°F and microwave.
- This product contains Aluminum and Stainless Steel (Iron, Chromium, Nickel, Manganese, Copper, Phosphorus).

Components

The Crock-Pot slow cooker consists of the following main components:

- **Heating Base:** The main unit containing the heating element and control panel.
- **Removable Stoneware:** The ceramic pot where food is cooked. This is dishwasher-safe.

- **Glass Lid:** Transparent lid with a handle, allowing you to view food during cooking.
- **Lid-Mounted Locking System:** Secure latches on the lid that attach to the handles of the heating base for spill-proof transport.
- **Digital Control Panel:** Features buttons for selecting temperature, setting the timer, and turning the unit on/off.



Figure 2: Exploded view of the Crock-Pot slow cooker showing its main parts.

Setup

Before first use, remove all packaging materials and wash the stoneware and glass lid in warm, soapy water. Rinse thoroughly and dry. The stoneware and lid are also dishwasher-safe. Wipe the heating base with a soft, damp cloth. Do not immerse the heating base in water.

Place the slow cooker on a flat, level, heat-resistant surface, away from walls or curtains, to ensure proper ventilation.

Operating Instructions

Control Panel Overview



Figure 3: Digital control panel with High, Low, Keep Warm, Select, Timer, and Off buttons.

- **Select Button:** Used to cycle through temperature settings (High, Low, Keep Warm).
- **Timer Buttons (Up/Down Arrows):** Adjusts the cooking time in 30-minute increments, from 30 minutes up to 20 hours.
- **Off Button:** Turns the slow cooker off.

Setting Cook Time and Temperature

1. Place the stoneware into the heating base and add your ingredients.
2. Cover with the glass lid.
3. Plug the power cord into a 120V A.C. electrical outlet. The digital display will flash.
4. Press the **Select** button to choose your desired temperature setting: **High** or **Low**. The corresponding indicator light will illuminate.
5. Use the **Timer Up/Down** arrows to set the desired cooking time. The time will be displayed on the digital screen.
6. Once the set cooking time is complete, the slow cooker will automatically switch to the **Keep Warm** setting. The 'Keep Warm' indicator light will illuminate, and the timer will begin counting up to indicate how long it has been on warm.

7. To turn off the slow cooker, press the **Off** button.

Using the Cook & Carry Feature

The Cook & Carry feature allows for secure transport of your cooked meals. Once cooking is complete and the unit is unplugged and cooled slightly, engage the lid-mounted locking system.

1. Ensure the lid is properly seated on the stoneware.
2. Flip the wire clips on each side of the lid down and hook them onto the handles of the heating base.
3. Ensure both clips are securely fastened to prevent spills during transport.



Figure 4: The secure locking lid system for spill-proof transport.

Maintenance and Cleaning

Proper maintenance ensures the longevity and performance of your slow cooker.

- **Stoneware and Lid:** The removable stoneware and glass lid are dishwasher-safe for easy cleaning. For stubborn food residue, soak the stoneware in warm, soapy water before washing.
- **Heating Base:** Wipe the exterior of the heating base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. Never immerse the heating base in water or any other liquid.
- Always ensure the slow cooker is unplugged and completely cooled before cleaning.

Troubleshooting

If your Crock-Pot slow cooker is not operating as expected, consider the following common issues:

- **Appliance not turning on:** Ensure the power cord is securely plugged into a working electrical outlet. Check if the outlet is receiving power.
- **Food not cooking properly:** Verify that the correct temperature setting (High or Low) and cooking time have been selected. Ensure the lid is properly seated to retain heat.
- **Lid not locking securely:** Check that the lid is correctly aligned with the stoneware and the wire clips are properly hooked onto the handles.

For further assistance, please refer to the full user manual available on the Crock-Pot website or contact customer support.

Specifications

Feature	Specification
Brand	Crock-Pot
Model Number	CPSCVC60LL-S
Color	Stainless Steel
Material	Stainless Steel
Product Dimensions	17"D x 11.8"W x 9.8"H
Capacity	6 Quarts
Wattage	240 watts
Item Weight	11.9 Pounds
Is Dishwasher Safe	Yes (Stoneware & Lid)
Voltage	120 Volts
Shape	Oval
Control Method	Touch
Control Type	Programmable
Number of Settings	3 (High, Low, Keep Warm)

Warranty and Support

For detailed warranty information, please refer to the warranty card included with your product packaging. For customer support, frequently asked questions, or to download the complete user manual (PDF), please visit the official Crock-Pot website or refer to the provided user guide link: User Manual (PDF).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question