Canon Sure Shot TeleMax

Canon Sure Shot TeleMax 35mm Film Camera

Instruction Manual

Introduction

Welcome to the world of film photography with your Canon Sure Shot TeleMax 35mm camera. This manual provides essential information for setting up, operating, and maintaining your camera to ensure optimal performance and enjoyment. The Canon Sure Shot TeleMax is a compact point-and-shoot camera featuring a versatile 38-70mm zoom lens, designed for ease of use and reliable image capture.



Front view of the Canon Sure Shot TeleMax 35mm camera, showcasing its compact design and zoom lens.

Setup

1. Battery Installation

The Canon Sure Shot TeleMax requires two AA batteries for operation. Ensure batteries are inserted with correct polarity as indicated inside the battery compartment.

1. Locate the battery compartment cover on the side or bottom of the camera.
2. Slide or unlatch the cover to open the compartment.
3. Insert two fresh AA batteries, matching the positive (+) and negative (-) terminals with the markings inside the compartment.
4. Close the battery compartment cover securely until it clicks into place.

2. Film Loading

This camera uses standard 35mm film. Always load film in subdued light to prevent accidental exposure.

1. Open the camera back cover by sliding the latch located on the side of the camera.
2. Place a new 35mm film cartridge into the film chamber on the left side.
3. Pull the film leader across to the film take-up spool on the right, ensuring it aligns with the red mark or engages with

the spool's teeth.

4. Close the camera back cover firmly until it latches. The camera will automatically advance the film to the first frame.

3. Attaching the Wrist Strap

Attach the included wrist strap to the designated lug on the camera body for secure handling and to prevent accidental drops.

Operating the Camera

1. Power On/Off

To turn the camera on, slide the lens cover open. The lens will extend, and the camera will be ready for use. To turn off, slide the lens cover closed. The lens will retract.

2. Flash Control

The flash control switch is located on the back of the camera. Slide the switch to select your desired flash mode:

- **Auto Flash:** The camera automatically determines if flash is needed based on lighting conditions.
- **Flash On:** Forces the flash to fire for every shot, useful for fill-flash in bright conditions or for backlighting.
- **Flash Off:** Disables the flash, ideal for situations where flash is prohibited or undesirable.

3. Zoom Operation

The Canon Sure Shot TeleMax features a 38-70mm zoom lens. Use the zoom buttons (usually marked 'W' for Wide and 'T' for Telephoto) located near the shutter button to adjust the focal length. Press 'W' to zoom out (wider angle) and 'T' to zoom in (telephoto).

4. Taking a Picture

1. Turn on the camera by opening the lens cover.
2. Look through the viewfinder to compose your shot.
3. Press the shutter button halfway down to activate the autofocus and exposure system. A green light in the viewfinder indicates focus lock.
4. Press the shutter button fully to take the picture. The camera will automatically advance the film to the next frame.

5. Film Rewind

When the film roll is complete, the camera will automatically rewind the film back into the cartridge. If you need to manually rewind the film before the roll is finished, locate the rewind button (often a small recessed button on the bottom or side) and press it. The camera will rewind the film, and the frame counter will reset.

Maintenance

1. Cleaning the Camera

- Use a soft, lint-free cloth to clean the camera body.
- For the lens, use a lens brush or a specialized lens cleaning cloth and solution. Avoid touching the lens surface with your fingers.
- Keep the viewfinder clean for clear composition.

2. Battery Care

- Remove batteries if the camera will not be used for an extended period to prevent leakage.
- Replace batteries when the low battery indicator appears or if camera functions become sluggish.

3. Storage

Store your camera in a cool, dry place away from direct sunlight and extreme temperatures. Use the included carrying case to protect it from dust and scratches.

Troubleshooting

- **Camera does not turn on:** Check if the batteries are correctly installed and fully charged. Ensure the lens cover is fully open.
- **Flash does not fire:** Verify that the flash mode is not set to 'Flash Off'. Check battery level.
- **Film does not advance/rewind:** Ensure the film is correctly loaded and the camera back is securely closed. Check battery level.
- **Blurred images:** Ensure the autofocus system has locked onto your subject (green light in viewfinder). Hold the camera steady when pressing the shutter.

If you encounter persistent issues, please refer to the support section for further assistance.

Specifications

Feature	Description
Model Name	Sure Shot TeleMax
Lens	Canon Lens 38-70mm f/3.5-6.0 (Zoom)
Film Type	35mm Film
Auto Focus Technology	Hybrid Autofocus
Flash Modes	Auto, On, Off (Built-In)
Viewfinder	Optical
Self Timer	10, 2, 5 seconds
Power Source	2 AA batteries
Exposure Control	Automatic
Form Factor	Compact Point & Shoot

Warranty Information

This Canon product is covered by a limited manufacturer's warranty. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your product or visit the official Canon website.

Support

For technical assistance, service, or additional information regarding your Canon Sure Shot TeleMax camera, please contact Canon Customer Support. You can find contact details on the official Canon website or in the documentation provided with your camera.

Canon Official Website: www.usa.canon.com

© 2023 Canon Inc. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question