Tiger JNP-1000-FL

Tiger JNP-1000-FL 5.5-Cup Rice Cooker and Warmer Instruction Manual

Model: JNP-1000-FL

Introduction

This manual provides essential instructions for the safe and efficient operation of your Tiger JNP-1000-FL 5.5-Cup Rice Cooker and Warmer. Please read it thoroughly before first use and retain it for future reference.

Safety Precautions

To ensure safe operation and prevent damage, always follow these basic safety guidelines:

- Ensure the appliance is placed on a stable, level surface away from heat sources.
- Do not immerse the main unit, cord, or plug in water or other liquids.
- Unplug the appliance from the outlet when not in use and before cleaning.
- Do not operate the appliance with a damaged cord or plug.
- Keep out of reach of children.
- Use only the accessories provided or recommended by the manufacturer.
- Do not cover the steam vent during operation.

Product Overview

Familiarize yourself with the components of your Tiger Rice Cooker:



Figure 1: Front view of the Tiger JNP-1000-FL Rice Cooker. The unit is white with a floral pattern, featuring a control panel with "Rice Cooking" and "Keep Warm" indicator lights and a single lever switch.

- **Main Unit:** Houses the heating element and control panel.
- **Inner Pan:** Non-stick cooking pot for rice. Features water level markings.
- **Lid:** Covers the inner pan during cooking and warming.
- **Steam Vent:** Removable and washable component on the lid for steam release.
- **Control Panel:** Includes "Rice Cooking" and "Keep Warm" indicator lights and a single lever switch for operation.
- **Retractable Power Cord:** For convenient storage.
- **Accessories:** Includes a rice measuring cup and a spatula.

Setup

Before first use, follow these steps:

1. Unpack all components and remove any packaging materials.
2. Wash the inner pan, steam vent, measuring cup, and spatula with warm, soapy water. Rinse thoroughly and dry completely.
3. Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water.
4. Place the rice cooker on a stable, heat-resistant surface.

Operating Instructions

Cooking Rice

1. Measure the desired amount of uncooked rice using the provided measuring cup**NOTE:** Always use the included measuring cup for accurate results.
2. Rinse the rice thoroughly under cold water until the water runs clear.
3. Place the rinsed rice into the non-stick inner pan.
4. Add water according to the water level markings inside the inner pan. For example, if you added 3 cups of rice, fill water to the "3" mark for white rice. Adjust water quantity based on desired rice texture.
5. Place the inner pan into the main unit, ensuring it sits properly.
6. Close the lid securely.
7. Plug the retractable power cord into a standard electrical outlet.
8. Press the single lever switch down to the "Rice Cooking" position. The "Rice Cooking" indicator light will illuminate.
9. Once cooking is complete, the lever switch will automatically flip up, and the "Keep Warm" indicator light will illuminate.
10. Allow the rice to steam for an additional 10-15 minutes after cooking is complete for best results.
11. Open the lid, fluff the rice with the provided spatula, and serve.

Keep Warm Function

The rice cooker automatically switches to the "Keep Warm" function after cooking is completed. This function maintains the rice at an optimal serving temperature for up to 12 hours. The "Keep Warm" indicator light will be illuminated during this period.

Steaming with the Steam Vent

The removable steam vent allows for easy cleaning and efficient steam release during cooking. This model does not include a dedicated steam basket for simultaneous steaming of other foods, but the steam vent ensures proper cooking of rice.

Maintenance and Cleaning

Regular cleaning ensures the longevity and performance of your rice cooker:

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. **Inner Pan:** The non-stick inner pan is easy to clean. Wash with warm, soapy water and a soft sponge. Do not use abrasive cleaners or metal scouring pads, as this can damage the non-stick coating.
3. **Steam Vent:** The steam vent is removable and washable. Detach it from the lid and wash with warm, soapy water.
4. **Lid and Main Unit:** Wipe the exterior of the lid and main unit with a damp cloth. Do not immerse the main unit in water.
5. **Accessories:** Wash the measuring cup and spatula with warm, soapy water.
6. Ensure all parts are completely dry before reassembling and storing.

Troubleshooting

If you encounter any issues, refer to the following common troubleshooting tips:

- **Rice is too hard/dry:** Ensure the correct water-to-rice ratio was used. Allow rice to steam for 10-15 minutes after cooking.
- **Rice is too soft/mushy:** Reduce the water-to-rice ratio slightly for future batches.
- **Rice sticks to the bottom:** Ensure the inner pan's non-stick coating is intact and that the rice was properly rinsed.
- **Appliance does not turn on:** Check if the power cord is securely plugged into both the appliance and the electrical outlet.

For further assistance, please contact Tiger customer support.

Specifications

Feature	Detail
Brand	Tiger
Model Number	JNP-1000-FL
Capacity	5.5-Cup (Uncooked Rice) / 1 Liters
Product Dimensions	10.7"D x 9.8"W x 10.3"H
Item Weight	6.4 Pounds
Power Source	Corded Electric
Wattage	340 watts
Voltage	120 Volts
Special Feature	Retractable Cord, Keep-warm function (up to 12 hours)
Material	Plastic (exterior), Non-stick (inner pan), Stainless Steel (lid)
Product Care Instructions	Hand Wash
Manufacturer	Japan Tiger Corporation of U.S.A

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your product or visit the official Tiger Corporation website. You can also visit the Tiger Store on Amazon for more product details and support resources.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question