**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Nixon A159680-00

# Nixon Men's Fader A159680 Gunmetal Rubber Quartz Watch User Manual

Model: A159680-00

## Introduction

This manual provides essential information for the proper use, setup, and maintenance of your Nixon Men's Fader A159680 Gunmetal Rubber Quartz Watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.

The Nixon Fader watch is designed for durability and style, featuring a gunmetal finish and a comfortable rubber strap, powered by a reliable quartz movement.

## Product Overview




Image 1: Front view of the Nixon Men's Fader A159680 Gunmetal Rubber Quartz Watch, showcasing its gunmetal case, black dial with horizontal lines, and black rubber strap. The watch features a prominent gold second hand.




Image 2: The white retail packaging box for a Nixon watch, with a black interior section visible. The Nixon logo is subtly embossed on the top of the box.

## Setup

### Setting the Time

1. Locate the crown on the right side of the watch case.
2. Gently pull the crown outwards to the first or second click position (depending on the model, some watches have a date function at the first click). For this model, pull it out until the second hand stops.
3. Rotate the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
4. Once the time is set, push the crown back into its original position. The second hand will begin to move again.

### Wearing the Watch

Adjust the rubber strap to fit comfortably around your wrist. Ensure it is snug but not too tight to allow for proper circulation.

## Operating

### Timekeeping

Your Nixon Fader watch is a quartz timepiece, known for its accuracy. It operates on a battery and requires minimal interaction beyond setting the time initially.

### Water Resistance

Refer to the markings on the watch case back for specific water resistance ratings. Generally, avoid operating the crown or pushers when the watch is wet to prevent water ingress.

## Maintenance

### Cleaning

- Wipe the watch case and strap with a soft, damp cloth. For rubber straps, mild soap and water can be used, then rinse thoroughly.
- Avoid using harsh chemicals, solvents, or abrasive cleaners, as these can damage the watch's finish or strap material.
- Ensure the watch is dry before storing or wearing.

### Battery Replacement

The quartz movement is powered by a battery. When the watch stops or the second hand begins to skip (if applicable), it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance integrity.

### Storage

When not in use, store your watch in a cool, dry place, away from direct sunlight and extreme temperatures. Keeping it in its original box or a watch case can protect it from dust and scratches.

## Troubleshooting

| Problem | Possible Cause | Solution |
| --- | --- | --- |
| Watch not running | Dead battery; Crown not pushed in; Internal movement issue. | Replace battery (professional service recommended); Push crown fully in; Seek professional repair. |

| Problem | Possible Cause | Solution |
|---|---|---|
| Incorrect time | Time not set correctly; Crown pulled out. | Re-set the time as per "Setting the Time" instructions; Push crown fully in. |
| Condensation under crystal | Water ingress; Extreme temperature change. | Immediately seek professional service to prevent damage; Avoid extreme temperature changes. |

## Specifications

| Feature | Detail |
|---|---|
| Brand | Nixon |
| Model Number | A159680-00 |
| Movement Type | Quartz |
| Case Material | Gunmetal (implied from title) |
| Strap Material | Rubber |
| Parcel Dimensions | 12.19 x 9.14 x 8.13 cm |
| Item Weight | 136.08 g |
| Date First Available | March 30 2012 |
| ASIN | B004TRUV86 |

## Warranty and Support

For detailed warranty information, please refer to the warranty card included with your purchase or visit the official Nixon website. Warranty terms typically cover manufacturing defects but may not cover damage from misuse, accidents, or unauthorized repairs.
If you require technical support or service, please contact Nixon customer service or the authorized retailer from whom you purchased the watch. Provide your model number (A159680-00) and ASIN (B004TRUV86) when seeking assistance. You can find more information and contact details on the official Nixon website:www.nixon.com

© 2024 Nixon. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B004TRUV86**

More documents and user manuals: **https://manuals.plus/**