Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Conair GMT189RGB

Conair Man Rechargeable All-in-One Trimmer User Manual

Brand: Conair | Model: GMT189RGB

Introduction

Welcome to the Conair Man Rechargeable All-in-One Trimmer user manual. This versatile grooming tool is designed for precision trimming of beards, mustaches, and hair, offering convenience and performance. Please read this manual thoroughly before first use to ensure safe and optimal operation of your new trimmer.

Product Components

Your Conair Man All-in-One Trimmer package includes the following items:

- Rechargeable Trimmer Unit
- Trimmer Blade Attachment
- Foil Shaver Attachment
- Nose/Ear Trimmer Attachment
- Adjustable Comb Attachment
- 3 Jawline Comb Attachments (various lengths)
- USB Charging Cable
- Cleaning Brush
- Lubricating Oil
- Storage Pouch



Figure 1: The Conair Man All-in-One Trimmer shown with all its components, including the main trimmer unit, various blade attachments (trimmer, foil shaver, nose/ear), multiple comb guides, a USB charging cable, cleaning brush, lubricating oil, and a storage pouch. This image provides a comprehensive view of everything included in the product package.



Figure 2: A detailed side view of the Conair Man All-in-One Trimmer, highlighting its ergonomic design and the power switch. The silver body with black grip accents is visible, along with the charging indicator light.



Figure 3: An illustrative image demonstrating the use of a hair clipper on a child's hair. This image showcases the product's application for general hair trimming, emphasizing its suitability for various grooming needs.

Safety Information

Please observe the following safety precautions:

- Always be cautious when using electric shavers to avoid cuts or skin irritation.
- Clean the shaver regularly to prevent bacterial growth.
- Do not use near water or while charging the device.

Getting Started (Setup)

Initial Charge

Before using your trimmer for the first time, it is recommended to fully charge it for approximately 16 hours. This ensures

optimal battery life and performance.

1. Ensure the trimmer is turned off.
2. Connect the USB charging cable to the trimmer's charging port.
3. Plug the other end of the USB cable into a compatible USB power adapter (not included) or a USB port on a computer.
4. The charging indicator light on the trimmer will illuminate to show it is charging.
5. Once fully charged, the light may change color or turn off, depending on the model. Disconnect the charger.

Attaching Trimmer Heads and Comb Guides

To change attachments, ensure the trimmer is off. Align the desired attachment with the trimmer body and gently push until it clicks into place. To remove, pull the attachment away from the trimmer body.

Operation

Turning On/Off

To turn the trimmer on, slide the power switch upwards. To turn it off, slide the switch downwards.

Trimming Techniques

For best results, ensure your hair is clean and dry. Use the appropriate attachment for your desired style and length.

- **Beard and Mustache Trimming:** Select a comb guide that matches your desired length. Always trim against the direction of hair growth for an even cut. Start with a longer comb guide and gradually reduce the length if needed.
- **Hair Trimming:** For general hair trimming, use the adjustable comb or specific comb guides. Move the trimmer slowly against the direction of hair growth.
- **Detailing and Edging:** Use the precision trimmer blade without a comb guide for sharp lines around your beard, mustache, sideburns, or neckline.
- **Nose and Ear Hair Trimming:** Attach the nose/ear trimmer head. Gently insert the trimmer tip into your nostril or ear canal and move it in a circular motion to trim unwanted hair.
- **Foil Shaving:** Attach the foil shaver head for a close, smooth finish on small areas, such as cheeks or neck. Use short, gentle strokes.

Care and Maintenance

Cleaning the Trimmer

Regular cleaning ensures optimal performance and hygiene.

1. Turn off and unplug the trimmer before cleaning.
2. Remove the trimmer head.
3. Use the provided cleaning brush to remove loose hairs from the blades and trimmer body.
4. Some trimmer heads may be rinseable under running water (refer to specific product instructions for water resistance). Ensure the trimmer body itself does not get wet unless explicitly stated as waterproof.
5. Allow all parts to air dry completely before reattaching or storing.

Lubricating Blades

To maintain blade sharpness and smooth operation, apply a drop or two of the provided lubricating oil to the blades after every few uses, or as needed. Turn the trimmer on for a few seconds to distribute the oil evenly.

Storage

Store the trimmer and its accessories in the provided storage pouch in a cool, dry place, away from direct sunlight and moisture.

Troubleshooting

Problem	Possible Cause	Solution
Trimmer does not turn on.	Battery is depleted.	Charge the trimmer for the recommended time.
Trimmer pulls hair or cuts poorly.	Blades are dull or clogged with hair/debris. Blades need lubrication.	Clean the blades thoroughly. Apply lubricating oil to the blades. If issues persist, blades may need replacement.
Trimmer is making unusual noise.	Blades are not properly aligned or lubricated. Internal issue.	Ensure blades are clean and lubricated. If noise persists, contact customer support.
Charging indicator light not working.	Faulty cable or power source. Trimmer not connected properly.	Check cable connection. Try a different USB port or power adapter.

Specifications

Model Name: GMT189GB

Item Model Number: GMT189RGB

Brand: Conair

Power Source: Battery Powered (Rechargeable)

Recommended Uses: Beard, Grooming, Mustache, Nose, Trimming

Manufacturer: Conair

First Available: April 22, 2011

Warranty and Support

For information regarding warranty coverage, product registration, or technical support, please refer to the warranty card included in your product packaging or visit the official Conair website. Keep your purchase receipt as proof of purchase for any warranty claims.
You can visit the official Conair store for more products and information:Conair Official Store

© 2024 Conair. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00509KG50

More documents and user manuals: **https://manuals.plus/**