Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lelit PS355

Lelit PS355 Dry Iron Instruction Manual

Model: PS355

1. Introduction

Thank you for choosing the Lelit PS355 Dry Iron. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before first use and keep them for future reference.

Product Overview

The Lelit PS355 is a high-quality dry iron designed for efficient and precise ironing. It features a durable aluminum soleplate and a comfortable cork handle, ensuring excellent results on various fabric types.



Figure 1: Lelit PS355 Dry Iron. This image shows the overall design of the iron, highlighting its cork handle, black body, and shiny aluminum soleplate.

2. Safety Information

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions when using electrical appliances.

- Always ensure the voltage indicated on the iron corresponds to your mains voltage.
- Do not leave the iron unattended while it is switched on or connected to the power supply.
- Keep the iron and its cord out of reach of children.
- Do not immerse the iron in water or any other liquid.
- Always unplug the iron from the electrical outlet before cleaning or when not in use.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged. Contact authorized service personnel for repair.
- Use the iron only for its intended purpose, which is ironing fabrics.
- Place the iron on a stable, heat-resistant surface when resting.

3. Setup

1. **Unpacking:** Carefully remove the iron and all accessories from the packaging. Retain the packaging for storage or transport.
2. **Inspect:** Check the iron for any signs of damage. If damaged, do not use it and contact your retailer.
3. **Placement:** Place the iron on a stable, heat-resistant ironing board or surface. Ensure the power cord is not tangled or obstructing your work area.
4. **Rubber Mat:** The package includes a rubber mat. Place this mat on a suitable surface to safely rest the hot iron during use and for cooling down after use. The mat's special teeth provide stability and aid in soleplate cooling.

Figure 2: Included Rubber Mat. This image displays the black rubber mat designed for safely resting the hot iron and assisting with soleplate cooling.

4. Operating Instructions

Temperature Settings

The Lelit PS355 dry iron features a graded rotary knob for precise temperature control, allowing you to select the appropriate heat setting for different fabric types. Always check the garment's care label before ironing.

1. **Sort Fabrics:** Separate garments according to their ironing temperature requirements (e.g., low heat for synthetics, medium for wool/silk, high for cotton/linen).
2. **Connect Power:** Plug the iron into a suitable electrical outlet (230V).
3. **Set Temperature:** Turn the temperature control knob to the desired setting. The iron will begin to heat up. The reduced heating time ensures quick readiness with low energy consumption.
4. **Indicator Light:** A pilot light will illuminate to indicate that the iron is heating. It will turn off once the set temperature is reached and cycle on/off during ironing to maintain the temperature.
5. **Ironing:** Begin ironing with the lowest temperature settings first, then gradually increase for higher heat fabrics. The aluminum soleplate maintains a consistent temperature, preventing fabric damage and ensuring smooth gliding. The iron's weight (1.640 kg) assists in effective ironing without requiring excessive pressure.
6. **Finish:** Once ironing is complete, turn the temperature knob to the 'Min' or 'Off' position and unplug the iron from the power outlet.

5. Maintenance and Care

Cleaning the Soleplate

To ensure optimal performance and prevent fabric damage, keep the soleplate clean.

1. **Cool Down:** Always ensure the iron is unplugged and completely cool before cleaning.
2. **Wipe Clean:** Wipe the soleplate with a damp cloth and a mild, non-abrasive cleaner if necessary. Do not use harsh scouring pads or metallic cleaners, as these can scratch the aluminum soleplate.
3. **Stubborn Stains:** For stubborn stains, a specialized soleplate cleaning stick (available separately) can be used following its instructions.

Storage

Store the iron in a safe, dry place once it has completely cooled down. Use the provided rubber mat for cooling and stable storage. Wrap the power cord neatly around the iron to prevent damage.



Figure 3: Optional Soleplate Protector. This image shows a perforated soleplate protector, which can be used to protect delicate fabrics or the iron's soleplate (sold separately).

6. Troubleshooting

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; temperature knob set to 'Off' or 'Min'.	Ensure iron is securely plugged in. Check power outlet with another appliance. Turn temperature knob to a desired heat setting.
Iron is too hot/cold for fabric.	Incorrect temperature setting for fabric type.	Adjust the temperature knob according to the fabric care label. Allow time for the iron to reach the new temperature.
Soleplate is dirty or sticky.	Residue from fabrics or starch.	Clean the soleplate as described in the 'Maintenance and Care' section. Ensure iron is cool before cleaning.
Ironing results are unsatisfactory.	Incorrect temperature; fabric not prepared; iron needs cleaning.	Verify temperature setting. Ensure fabrics are slightly damp if required for better results. Clean the soleplate.

7. Specifications

Brand: Lelit

Model: PS355

Type: Dry Iron

Material: Aluminum Soleplate, Cork Handle

Power: 800 Watts

Voltage: 230V

Dimensions (L x W x H): Approximately 23.5 x 10 x 15 cm (9.25 x 3.94 x 5.91 inches)

Weight: Approximately 1.8 kg (3.97 lbs)

Special Features: Temperature Control, Non-slip Cork Handle

Manufactured: Italy

First Available Date: September 10, 2012

8. Warranty and Support

Lelit products are manufactured to high-quality standards. For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Lelit website. Keep your proof of purchase for any warranty claims.
For further assistance, please contact Lelit customer service through their official channels.

© 2026 Lelit. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0050IJ5QM

More documents and user manuals: **https://manuals.plus/**