Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Acer VZ.K2800.001

Acer K11 Projector Remote Control Replacement Part VZ.K2800.001 User Manual

Model: VZ.K2800.001 | Brand: Acer

Introduction

This manual provides essential instructions for the setup, operation, and maintenance of your Acer K11 Projector Remote Control Replacement Part, model VZ.K2800.001. Please read this manual thoroughly to ensure proper use and longevity of your remote control.

Product Overview

The Acer VZ.K2800.001 is a replacement remote control designed for the Acer K11 projector. It provides full functionality to control your projector, including power, menu navigation, source selection, and volume adjustments.

Image: Placeholder for the Acer K11 Projector Remote Control. A typical product image would display the remote's design and button layout.

Setup

1. **Battery Installation:**
   - Locate the battery compartment on the back of the remote control.
   - Slide open the battery cover.
   - Insert two AAA batteries (not included), ensuring the correct polarity (+ and -) as indicated inside the compartment.
   - Close the battery cover securely.
2. **First Use:**

   Point the remote control directly at the Acer K11 projector's infrared (IR) receiver. The remote should function immediately without additional pairing steps, as it is a direct replacement part.

Operating Instructions

The remote control provides access to all standard functions of your Acer K11 projector. Below are common button functions:

- **Power Button:** Turns the projector on or off.
- **Menu Button:** Opens or closes the projector's on-screen display (OSD) menu.
- **Navigation Buttons (Up, Down, Left, Right):** Used to navigate through menu options.
- **Enter/OK Button:** Confirms a selection in the menu.
- **Source Button:** Cycles through available input sources (e.g., HDMI, VGA, USB).
- **Volume Up/Down:** Adjusts the audio output level (if the projector has built-in speakers or audio output).
- **Mute Button:** Mutes or unmutes the audio.

- **Aspect Ratio Button:** Changes the display aspect ratio.
- **Keystone Correction:** Adjusts image distortion.

Refer to your Acer K11 projector's main user manual for detailed explanations of specific projector functions and menu options.

Maintenance

- **Cleaning:**

  Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, aerosols, or abrasive materials, as these can damage the surface or internal components.

- **Battery Replacement:**

  Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA). Remove batteries if the remote will not be used for an extended period to prevent leakage.

- **Storage:**

  Store the remote control in a cool, dry place, away from direct sunlight and extreme temperatures.

Troubleshooting

Problem	Possible Cause	Solution
Remote not working.	Dead or incorrectly installed batteries.	Check battery polarity. Replace batteries with new ones.
Remote works intermittently.	Weak batteries; obstruction between remote and projector.	Replace batteries. Ensure clear line of sight to the projector's IR receiver.
Limited range.	Weak batteries; interference; distance.	Replace batteries. Reduce distance to projector. Remove sources of interference (e.g., bright lights).
Specific button not responding.	Button malfunction; projector not in correct mode.	Ensure the projector is in the correct mode for the button's function. If other buttons work, the specific button might be faulty (rare for new remotes).

Specifications

- **Model Number:** VZ.K2800.001
- **Brand:** Acer
- **Compatibility:** Acer K11 Projector
- **Power Source:** 2 x AAA Batteries (not included)
- **Weight:** Approximately 500 g (including packaging, as per product data)
- **Manufacturer:** Acer

Warranty and Support

This replacement part is typically covered by the original manufacturer's warranty for replacement parts. Please refer

to the warranty information provided with your purchase or contact Acer customer support for specific details regarding warranty coverage and technical assistance.
For further support or inquiries, please visit the official Acer support website or contact their customer service.

© 2025 Acer. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0051B4V6W

More documents and user manuals: **https://manuals.plus/**