WMF 0797809990

WMF Juicer/Steamer Instruction Manual

Model: 07.9780.9990

Introduction

This manual provides essential information for the safe and efficient operation, maintenance, and care of your WMF Juicer/Steamer, model 07.9780.9990. Please read these instructions thoroughly before first use and keep them for future reference.



Image: Fully assembled WMF Juicer/Steamer, showcasing its stainless steel construction and multi-tier design.

Important Safety Instructions

- Always ensure the juicer/steamer is placed on a stable, heat-resistant surface during operation.
- Do not touch hot surfaces. Use oven mitts or handles. Steam can cause severe burns.
- Keep out of reach of children.

- Do not overfill the water pot or fruit basket.
- Ensure the silicone hose is properly attached and the clamp is closed before heating.
- Never allow the water pot to boil dry.
- This appliance is designed for household use only.

Components Overview

Your WMF Juicer/Steamer consists of several key components designed for efficient juice extraction through steaming.





Image: Exploded view showing all individual parts of the WMF Juicer/Steamer, including the lid, fruit basket, juice collection pot, water pot, silicone hose, and clamp.

1. **Glass Lid:** With a heat-resistant handle.
2. **Fruit Basket (Perforated Pot):** For holding fruits or vegetables.
3. **Juice Collection Pot:** Collects the extracted juice, features a spout for the silicone hose.
4. **Water Pot (Bottom Pot):** Holds water for steam generation.
5. **Silicone Hose with Clamp:** For draining the extracted juice.

Setup and Assembly

Before first use, wash all parts thoroughly with warm soapy water and rinse well. Assemble the juicer/steamer as follows:

1. Place the **Water Pot** on your stovetop. Ensure your stovetop is compatible with the TransTherm® universal base, suitable for glass-ceramic, electric, gas, and induction hobs.
2. Fill the **Water Pot** with water up to approximately 2/3 capacity. Do not exceed the maximum fill line if present.
3. Place the **Juice Collection Pot** on top of the Water Pot, ensuring it sits securely.
4. Attach the **Silicone Hose** to the spout on the Juice Collection Pot. Ensure it is firmly attached to prevent leaks. Close the clamp on the hose.
5. Place the **Fruit Basket** on top of the Juice Collection Pot.

6. Add your prepared fruits or vegetables to the Fruit Basket. Do not overfill.
7. Place the **Glass Lid** securely on top of the Fruit Basket.



Image: Underside of the WMF pot, displaying the "TransTherm" logo and icons indicating compatibility with various cooktop types: glass-ceramic, electric, gas, and induction.

Operating Instructions (Juice Extraction)

Follow these steps to extract juice from fruits or vegetables using steam:

1. After assembly and filling the fruit basket, place the assembled juicer/steamer on your stovetop.
2. Heat the water pot on medium to high heat until steam begins to rise. Once steam is consistently produced, reduce heat to a simmer. The steam will rise through the fruit basket, causing the fruit cells to burst and release their juice.
3. Allow the juicing process to continue for the recommended time, which varies depending on the type and ripeness of the fruit (e.g., 60-90 minutes for berries, 90-120 minutes for harder fruits like apples or

pears).

4. Periodically check the water level in the bottom pot to ensure it does not boil dry. Refill with hot water if necessary.
5. Once the juicing process is complete, carefully open the clamp on the silicone hose to drain the hot juice into a heat-resistant container or sterilized bottles. Use oven mitts as the hose and clamp will be hot.
6. Close the clamp once all juice is drained.



Image: The WMF Juicer/Steamer in operation on a kitchen counter, filled with red currants and sugar, demonstrating the steam

juicing process with the silicone hose ready for juice collection.

Cleaning and Maintenance

Proper cleaning and maintenance will ensure the longevity and performance of your WMF Juicer/Steamer.

- Allow the juicer/steamer to cool completely before cleaning.
- All stainless steel parts are dishwasher safe. For best results and to prevent water spots, hand wash with warm soapy water and dry immediately.
- Clean the silicone hose thoroughly after each use to prevent residue buildup. A small brush can be used for the interior.
- For stubborn stains or mineral deposits, use a stainless steel cleaner or a solution of vinegar and water.
- Store all components in a dry place.

Troubleshooting

Problem	Possible Cause	Solution
No juice extraction or very little juice.	Insufficient heating time; fruit not ripe enough; water pot boiled dry.	Increase heating time; use riper fruit; check and refill water pot.
Steam escaping from joints.	Pots not seated correctly; lid not properly placed.	Ensure all pots are securely stacked and the lid is firmly in place.
Silicone hose leaking.	Hose not properly attached; clamp not closed or faulty.	Re-attach hose firmly; ensure clamp is fully closed; inspect hose and clamp for damage.
Discoloration on stainless steel.	Hard water deposits; overheating.	Clean with vinegar solution or stainless steel cleaner. Avoid excessive heat.

Specifications

Brand: WMF

Model Number: 07.9780.9990

Product Dimensions: 14.96 x 14.96 x 12.8 inches

Item Weight: 0.176 ounces

Material: Cromargan® Stainless Steel 18/10

Hob Compatibility: Glass-Ceramic, Electric, Gas, Induction (TransTherm® universal base)

Care Instructions: Dishwasher Safe

Batteries Required: No

Warranty and Support

For information regarding warranty coverage, product registration, or customer support, please refer to the official WMF website or contact WMF customer service directly. Keep your proof of purchase for any warranty claims.

You can typically find contact information and warranty details on the manufacturer's official website: www.wmf.com

© 2024 WMF. All rights reserved.