Westpointe FZ10-9HB

Westpointe FZ10-9HB Tower Fan User Manual

Model: FZ10-9HB (TV137382)

Introduction

Thank you for purchasing the Westpointe FZ10-9HB Tower Fan. This manual provides important information for the proper assembly, operation, and maintenance of your new fan. Please read it thoroughly before use and retain it for future reference.
The Westpointe FZ10-9HB is designed to circulate air efficiently, offering three speed settings and an oscillating motion for consistent cooling throughout a room. Its slim, free-standing design allows for unobtrusive placement in various indoor environments.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using this fan.
- Ensure the power source matches the electrical requirements of the fan (120V AC, 60Hz).
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect fan, turn controls to OFF, then remove plug from outlet.
- Do not insert or allow fingers or foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the fan.
- Do not block air intakes or exhaust in any manner.
- Do not use outdoors. This fan is intended for indoor use only.
- This fan is UL listed, indicating compliance with safety standards.

Parts List

Please check to ensure all components are present:

- Tower Fan Unit (with integrated power cord)
- Base Assembly (typically two halves and screws)
- User Manual (this document)

Setup and Assembly

Follow these steps to assemble your Westpointe Tower Fan:

1. Carefully remove all packaging materials from the fan and its components.
2. Assemble the base: If the base comes in two halves, align them and secure them together using the provided screws.
3. Attach the fan unit to the assembled base: Carefully place the tower fan unit onto the base, ensuring the alignment tabs or holes match. Secure the fan to the base using the provided screws, typically from the underside of the base.
4. Place the fan on a firm, level surface.
5. Plug the power cord into a standard 120V AC wall outlet.



Figure 1: Assembled Westpointe FZ10-9HB Tower Fan. This image shows the fan's sleek black tower design, its stable base, and the control panel located on the top surface.

Operating Instructions

Your Westpointe Tower Fan features touch controls for easy operation.

1. **Power On/Off:** Press the **Power** button (usually indicated by a power symbol) on the control panel to turn the fan ON or OFF.
2. **Adjusting Fan Speed:** Press the **Speed** button (often indicated by fan blades or multiple lines) repeatedly to cycle through the three available speed settings: Low, Medium, and High.
3. **Oscillation Function:** Press the **Oscillation** button (often indicated by an arrow circling) to activate or deactivate the oscillating motion. When activated, the fan will rotate from side to side to distribute air across a wider area.

Always ensure the fan is unplugged before moving or performing any maintenance.

Maintenance and Care

Regular cleaning will help maintain your fan's performance and extend its lifespan.

- **Cleaning:** Always unplug the fan from the power outlet before cleaning. Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
- **Dust Removal:** Use a vacuum cleaner with a brush attachment to gently remove dust from the air intake and exhaust grilles.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging to protect it from dust and damage.
- Do not immerse the fan in water or any other liquid.

Troubleshooting

If your fan is not operating correctly, please check the following common issues before contacting support:

Problem	Possible Cause	Solution
Fan does not turn on.	Not plugged in; Power outlet not working; Fan switch is OFF.	Ensure plug is firmly in outlet; Test outlet with another device; Press the Power button to ON.
Air flow is weak.	Fan speed set too low; Air intake/exhaust blocked; Dust accumulation.	Increase fan speed; Clear any obstructions; Clean air grilles as per Maintenance section.
Fan is making unusual noise.	Fan not on a level surface; Internal obstruction; Loose parts.	Place fan on a flat, stable surface; Unplug and check for visible obstructions; If noise persists, discontinue use and contact support.
Oscillation not working.	Oscillation function is OFF.	Press the Oscillation button to activate.

Specifications

Model: FZ10-9HB (TV137382)

Brand: Westpointe

Type: Tower Fan

Color: Black

Power Source: Electric (Corded)

Number of Speeds: 3

Special Features: Oscillating

Control Method: Touch

Indoor/Outdoor Usage: Indoor

Safety Certification: UL Listed

Item Weight: Approximately 5.5 Pounds

Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your purchase or visit the official Westpointe website. Keep your purchase receipt as proof of purchase for any warranty claims.
For general inquiries or troubleshooting assistance not covered in this manual, please contact Westpointe customer service. Contact details can typically be found on the product packaging or the brand's official website.

© 2025 Westpointe. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question