Pentair 77707-0203

Pentair 77707-0203 Flameholder Replacement Kit Instruction Manual

1. Product Overview

This document provides instructions for the installation and maintenance of the Pentair 77707-0203 Flameholder Replacement Kit. This kit is designed to replace the flameholder component in compatible Pentair and Sta-Rite pool and spa heaters, ensuring proper combustion and efficient operation.

A flameholder is a critical component within a pool or spa heater's combustion chamber. Its primary function is to stabilize the flame during operation, ensuring complete and efficient fuel combustion. Over time, flameholders can degrade due to high temperatures and corrosive environments, necessitating replacement to maintain heater performance and safety.

2. Compatibility

The Pentair 77707-0203 Flameholder Replacement Kit is compatible with the following pool and spa heater models:

- Pentair MasterTemp Pool and Spa Heater Model 300
- Pentair Sta-Rite Max-E-Therm Heater Model 333

Verify your heater's model number before proceeding with installation to ensure proper fit and function.

3. Safety Information

WARNING: Improper installation, adjustment, alteration, service, or maintenance can cause property damage, injury, or death. Read the installation and operating instructions thoroughly before installing or servicing this equipment.

- Always disconnect all electrical power to the heater at the main circuit breaker before attempting any service or maintenance.
- Turn off the gas supply to the heater before beginning work.
- Allow the heater to cool completely before handling any internal components.
- Wear appropriate personal protective equipment (PPE), including gloves and eye protection.
- If you are unsure about any step, consult a qualified pool heater technician.
- Refer to your specific heater's owner's manual for detailed disassembly and reassembly procedures.

4. Installation Instructions

The following steps provide a general guide for replacing the flameholder. Always refer to your specific heater's service manual for precise instructions and diagrams.



Figure 1: Pentair 77707-0203 Flameholder Replacement Kit. This image shows the cylindrical, perforated metal flameholder with a square mounting plate at the top, featuring four screw holes and a central opening.

1. **Prepare the Heater:** Ensure the heater is completely cool. Disconnect all electrical power at the main circuit breaker and turn off the gas supply valve to the heater.

2. **Access the Combustion Chamber:** Carefully remove the heater's outer jacket panels and any internal baffles or insulation necessary to gain access to the combustion chamber where the flameholder is located. Refer to your heater's manual for specific panel removal instructions.
3. **Locate the Old Flameholder:** Identify the existing flameholder. It is typically a cylindrical, perforated metal component situated above the burner assembly.
4. **Remove the Old Flameholder:** Unfasten any screws, clips, or other retaining mechanisms holding the old flameholder in place. Carefully lift and remove the old flameholder from the heater. Note its orientation for correct installation of the new part.
5. **Inspect and Clean:** While the chamber is open, inspect the surrounding area for any debris, soot, or corrosion. Clean as necessary, ensuring no foreign objects remain that could obstruct airflow or combustion.
6. **Install the New Flameholder:** Position the new Pentair 77707-0203 Flameholder Replacement Kit (as shown in Figure 1) into the combustion chamber, ensuring it is correctly oriented and seated. Secure it with the original fasteners or any new hardware provided with the kit. Ensure all connections are snug but do not overtighten.
7. **Reassemble the Heater:** Replace any baffles, insulation, and outer jacket panels that were removed. Ensure all panels are securely fastened to maintain proper heater operation and safety.
8. **Restore Power and Gas:** Once reassembly is complete, turn on the gas supply valve to the heater and restore electrical power at the main circuit breaker.
9. **Test Heater Operation:** Follow your heater's normal startup procedure. Observe the flame for proper ignition and stable operation. Check for any unusual noises, smells, or error codes. If issues persist, refer to the troubleshooting section or consult a qualified technician.

5. Operating Verification

After installing the new flameholder, it is crucial to verify the heater's proper operation:

- **Ignition:** Ensure the heater ignites smoothly and consistently.
- **Flame Appearance:** Observe the flame through any inspection ports. A healthy flame should be blue and stable, without excessive yellow tipping or lifting.
- **Heating Performance:** Confirm the heater is raising the water temperature effectively and reaching the set point.
- **Error Codes:** Check the heater's display for any new or persistent error codes.

If any anomalies are observed, immediately shut down the heater and consult the troubleshooting section or a professional technician.

6. Maintenance

While the flameholder itself is a replacement part, regular maintenance of your pool/spa heater is essential for its longevity and efficient operation:

- **Annual Inspection:** Have a qualified technician inspect your heater annually, especially before the heating season.
- **Keep Area Clear:** Ensure the area around the heater is free from debris, combustible materials, and obstructions to airflow.
- **Ventilation:** Verify that the heater's ventilation system is clear and unobstructed.
- **Water Chemistry:** Maintain proper pool/spa water chemistry to prevent corrosion and scale buildup within the heater.

7. Troubleshooting

If you encounter issues after replacing the flameholder, consider the following common troubleshooting steps:

- **Heater Not Igniting:**
  - Check if gas supply is fully open.
  - Verify electrical power is restored.
  - Ensure all wiring connections are secure.
  - Consult your heater's manual for specific ignition troubleshooting.
- **Poor Flame Quality (Yellow/Unstable):**
  - Confirm the new flameholder is correctly seated and not obstructed.
  - Check for proper airflow to the combustion chamber.
  - This could indicate a gas pressure issue or a problem with other heater components; professional inspection is recommended.
- **Error Codes Displayed:**
  - Refer to your heater's owner's manual for the meaning of specific error codes and recommended actions.
  - Common codes might relate to ignition failure, high limit, or pressure switch issues.

For persistent problems, contact a certified pool heater service technician.

8. Specifications

- **Model Number:** 77707-0203
- **Product Dimensions:** 12.5 x 12.4 x 5.1 inches
- **Item Weight:** 11 ounces
- **Manufacturer:** Pentair
- **Country of Origin:** United States

9. Warranty and Support

Specific warranty information for the Pentair 77707-0203 Flameholder Replacement Kit is not provided in this document. Please refer to the original product packaging or the official Pentair website for detailed warranty terms and conditions.

For technical support, replacement parts, or service inquiries, please contact Pentair customer service or visit their official website:

- Pentair Official Website
- Consult your local authorized Pentair dealer or service center.

© 2023 Pentair. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question