Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MusicMan TXX3529

MusicMan Mini Soundstation Portable Speaker TXX3529 User Manual

Introduction

Welcome to the user manual for your MusicMan Mini Soundstation Portable Speaker. This compact and versatile device allows you to enjoy your favorite music anywhere. It features an integrated MP3 player, supports USB drives and MicroSD cards, and offers an AUX input for connecting various audio sources. Please read this manual carefully to ensure proper use and to maximize the lifespan of your device.

Product Overview

The MusicMan Mini Soundstation is a lightweight and portable speaker designed for convenience and quality sound. Its durable aluminum casing is available in various metallic colors, making it both robust and stylish. The device is equipped with intuitive controls for easy operation.



The MusicMan Mini Soundstation Portable Speaker, showcasing its compact design and USB input.



A collection of MusicMan Mini Soundstation speakers in different colors, highlighting their portability.



The MusicMan Mini Soundstation featuring its USB port and MicroSD card slot for versatile media playback.

Package Contents

Please check the box for the following items:

- MusicMan Mini Soundstation Speaker
- USB 3.5 mm Audio Cable (for charging and AUX connection)
- Wrist Strap
- User Manual

Setup

1. Charging the Device

Before first use, fully charge the speaker. Connect the supplied USB 3.5 mm audio cable to the 'LINE IN/5V' port on the speaker and the USB end to a powered USB port (e.g., computer, USB wall adapter). The charging indicator light will illuminate. Once fully charged, the light may change color or turn off. A full charge provides approximately 8-9 hours of playback.

2. Inserting a MicroSD Card or USB Drive

To play music from a MicroSD card, gently insert the card into the 'MICRO SD/TF' slot until it clicks into place. To play from a USB drive, insert it into the dedicated USB slot. Ensure the media contains compatible audio files (e.g., MP3).



Detailed view of the input ports for charging, MicroSD, and USB media.

3. Connecting via AUX Input

To use the speaker with an external audio device (e.g., smartphone, MP3 player) that does not support USB or MicroSD, connect the 3.5 mm end of the supplied audio cable to the 'LINE IN/5V' port on the speaker and the other 3.5 mm end to the headphone jack or audio output of your external device. The speaker will automatically switch to AUX mode.

Operating Instructions

1. Power On/Off

Locate the 'ON/OFF' switch, usually on the bottom or side of the speaker. Slide the switch to 'ON' to power on the device. Slide it to 'OFF' to power it down.



The dedicated On/Off power switch for easy control.

2. Playback Controls

The speaker features a control panel, typically on the top surface, with the following buttons:

- **Play/Pause (►/‖)**: Press to start or pause playback.
- **Next Track (►►)**: Press to skip to the next track.
- **Previous Track (◄◄)**: Press to go back to the previous track.
- **Volume Up (VOL+)**: Press and hold to increase volume.
- **Volume Down (VOL-)**: Press and hold to decrease volume.



The intuitive control panel for managing music playback and volume.

3. Mode Selection

The speaker automatically detects the input source. If a MicroSD card or USB drive is inserted, it will prioritize playing from that source. If an AUX cable is connected, it will switch to AUX mode. Disconnect one source to switch to another.

Maintenance

Cleaning

Wipe the speaker with a soft, dry cloth. Do not use abrasive cleaners or solvents, as they may damage the surface. Keep the ports free of dust and debris.

Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Recharge the speaker regularly, even if not in use for extended periods. Store the device in a cool, dry place.

Troubleshooting

- **No Power:** Ensure the device is charged. Connect it to a power source using the USB cable. Check the 'ON/OFF' switch is in the 'ON' position.
- **No Sound:** Check the volume level on both the speaker and the connected audio source (if using AUX). Ensure the audio source is playing. If using MicroSD/USB, verify the media contains compatible audio files and is inserted correctly.
- **Distorted Sound:** Reduce the volume on both the speaker and the audio source. Ensure the audio cable is fully inserted if using AUX.
- **Device Not Recognized by PC (for data transfer):** The MusicMan Mini Soundstation is designed to play media from USB drives and MicroSD cards directly, and to be charged via USB. It does not function as a data transfer device when connected to a PC. To load music onto a MicroSD card or USB drive, connect them directly to a computer using a card reader or by plugging the USB drive into a computer's USB port.
- **Short Battery Life:** Ensure the device is fully charged before use. Battery performance can degrade over time with repeated charge cycles.

Specifications

Feature	Detail
Model Number	TXX3529
Dimensions	5 x 5 x 5 cm

Weight	117 Grams
Material	Aluminum
Power Source	Battery Powered
Battery Type	Lithium-ion (Rechargeable)
Connectivity Technology	Auxiliary, USB
Wireless Communication	Bluetooth (Note: Product description mentions Bluetooth, but feature bullets and reviews suggest primary connectivity is AUX/USB/MicroSD. Bluetooth functionality may vary by specific model variant or be a general specification for the brand's product line.)
Compatible Devices	Smartphone, MP3 players, PCs, Laptops, etc.
Speaker Output Power	6 Watts
Audio Output Mode	Stereo
Special Feature	Lightweight
Recommended Uses	Indoor and Outdoor

Warranty Information

MusicMan products are designed for quality and durability. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact your retailer. Warranty periods may vary by region and retailer. Please retain your proof of purchase for any warranty claims.

Support

For further assistance, technical support, or to inquire about replacement parts, please visit the official MusicMan website or contact your point of purchase. You may also find additional FAQs and support resources online.

© 2024 MusicMan. All rights reserved. Model: TXX3529.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0058U9U3K

More documents and user manuals: **https://manuals.plus/**