Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Jazwares 15200

Jazwares Star Wars Darth Vader Alarm Clock Radio Instruction Manual

1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your Jazwares Star Wars Darth Vader Alarm Clock Radio. Please read this manual thoroughly before using the product to ensure proper function and longevity.


STAR WARS
RADIO-ALARM
ALARM MODE
OFF
12:10 AM
09
TUE

Figure 1: Front view of the Darth Vader Alarm Clock Radio.

2. Product Features

- Digital LCD screen displaying time, date, and radio station.
- Integrated FM radio tuner.
- Alarm options: radio, buzzer, or Darth Vader sound effects.
- Darth Vader's lightsaber illuminates red when the alarm sounds.
- Pressing the Star Wars logo activates the LCD screen backlight and lightsaber illumination.
- Adjustable volume control.
- Dual power options: AC adapter or 3 AA batteries.

3. Package Contents

Verify that all items are present in the package:

- Darth Vader Alarm Clock Radio unit
- AC Power Adapter
- 3 x AA Batteries (pre-installed or included separately)
- Instruction Manual (this document)

4. Setup

4.1. Powering the Device

The alarm clock can be powered by either the included AC adapter or 3 AA batteries.

1. **AC Power:** Connect the AC adapter to the DC input jack located on the back of the unit. Plug the adapter into a standard wall outlet.
2. **Battery Power:** For portable use or as a backup, install 3 AA batteries into the battery compartment.

4.2. Battery Installation

1. Locate the battery compartment cover on the back or bottom of the unit.
2. Open the cover by sliding or unscrewing it.
3. Insert 3 new AA batteries, ensuring correct polarity (+ and -) as indicated inside the compartment.
4. Replace the battery compartment cover securely.



Figure 2: Back view of the unit, indicating the battery compartment and power input.

5. Operating Instructions

Familiarize yourself with the control buttons located on the base of the unit.





Figure 3: Close-up of the control panel on the alarm clock base.

5.1. Setting the Time

1. Press and hold the **TIME SET** button (or similar, e.g., MODE) until the hour display flashes.
2. Use the **+/-** buttons (or UP/DOWN arrows) to adjust the hour. Pay attention to AM/PM indicators.
3. Press the **TIME SET** button again to confirm the hour and move to minute adjustment.
4. Use the **+/-** buttons to adjust the minutes.
5. Press **TIME SET** once more to save the time and exit setting mode.

5.2. Setting the Date

1. Press and hold the **DATE SET** button (or cycle through MODE until date flashes).
2. Use the **+/-** buttons to adjust the year.
3. Press **DATE SET** to confirm the year and move to month adjustment.
4. Use the **+/-** buttons to adjust the month.
5. Press **DATE SET** to confirm the month and move to day adjustment.
6. Use the **+/-** buttons to adjust the day.
7. Press **DATE SET** once more to save the date and exit setting mode.

5.3. Setting the Alarm

1. Press and hold the **ALARM SET** button until the alarm time flashes.
2. Use the **+/-** buttons to adjust the alarm hour (observe AM/PM).
3. Press **ALARM SET** to confirm the hour and move to minute adjustment.
4. Use the **+/-** buttons to adjust the alarm minutes.
5. Press **ALARM SET** to confirm the alarm time.
6. Immediately after setting the time, use the **ALARM MODE** button to select your desired alarm sound: **RADIO**, **BUZZER**, or **DARTH VADER SOUNDS**.
7. Press **ALARM SET** again to activate the alarm and exit setting mode. An alarm icon should appear on the display.
8. To turn off a sounding alarm, press the **SNOOZE/LIGHT** button for a temporary snooze, or press **ALARM OFF** to disable it until the next set time.

5.4. Radio Operation

1. Press the **RADIO ON/OFF** button to turn the radio on.
2. Use the **FM BAND SELECTOR** dial to tune into your desired FM station.
3. Adjust the volume using the **VOLUME CONTROL** dial or buttons.
4. To turn off the radio, press the **RADIO ON/OFF** button again.

5.5. Volume Control

The volume for both radio and alarm sounds can be adjusted using the **VOLUME CONTROL** dial or buttons on the unit's base.

5.6. Lightsaber and LCD Backlight

Press the **STAR WARS LOGO** button located on the base to illuminate the LCD screen backlight and activate the lightsaber's red glow.

6. Maintenance

- **Cleaning:** Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Battery Replacement:** Replace batteries when the display dims or functions become erratic. Always replace all three batteries at the same time with new AA batteries.
- **Storage:** If storing the unit for an extended period, remove the batteries to prevent leakage.

7. Troubleshooting

Problem	Possible Cause	Solution
Unit does not power on.	No power from AC adapter; dead batteries; incorrect battery installation.	Check AC adapter connection and outlet. Replace batteries, ensuring correct polarity.
Display is dim or blank.	Low batteries.	Replace batteries. Ensure AC adapter is securely connected.
Alarm does not sound.	Alarm not set; alarm volume too low; alarm mode not selected.	Verify alarm time is set and activated. Check alarm volume. Ensure an alarm mode (Radio, Buzzer, Vader Sounds) is selected.
Difficulty setting time/date/alarm.	Incorrect button sequence.	Refer to sections 5.1, 5.2, and 5.3 and follow steps carefully. Some settings require holding buttons.
Radio reception is poor.	Weak signal; interference.	Adjust the unit's position. Ensure no electronic devices are causing interference.

8. Specifications

- **Brand:** Jazwares
- **Model Number:** 15200
- **Display Type:** Digital LCD
- **Power Source:** AC Adapter (included) or 3 x AA Batteries (included)
- **Dimensions:** 8.05 x 9.55 x 12.6 inches (L x W x H)
- **Item Weight:** 2.2 pounds (approximately 1 Kilogram)
- **Special Features:** Alarm, Calendar Display, FM Radio, Lights & Sounds
- **Recommended Age:** 6 - 15 years

- **UPC:** 681326152002

9. Warranty and Support

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Jazwares website. Keep your purchase receipt as proof of purchase for any warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B005D71SMY

More documents and user manuals: **https://manuals.plus/**