Briggs & Stratton 692423

Briggs & Stratton 692423 Engine Crankshaft Counterweight Instruction Manual

Genuine Original Equipment Manufacturer (OEM) Part

Introduction

This manual provides essential instructions for the proper installation, operation, and maintenance of the Briggs & Stratton 692423 Engine Crankshaft Counterweight. This component is a genuine Original Equipment Manufacturer (OEM) part designed for specific Briggs & Stratton lawn and garden equipment engines. Adhering to these instructions will ensure optimal performance and longevity of your engine.

Please read this manual thoroughly before attempting any installation or maintenance procedures. Keep this manual for future reference.

Safety Information

Always prioritize safety when working with engine components. Failure to follow safety precautions can result in serious injury or damage to equipment.

- Ensure the engine is turned off and cooled down before beginning any work.
- Disconnect the spark plug wire to prevent accidental starting.
- Wear appropriate personal protective equipment (PPE), including safety glasses and gloves.
- Refer to your engine's primary service manual for specific torque specifications and additional safety guidelines.
- If you are unsure about any procedure, consult a qualified service technician.

Part Identification

The Briggs & Stratton 692423 is an engine crankshaft counterweight. It is crucial for balancing the crankshaft assembly, reducing vibration, and ensuring smooth engine operation.



Image: The Briggs & Stratton 692423 Engine Crankshaft Counterweight. This image displays the component, which is essential for engine balance and smooth operation.

Setup and Installation

Installation of the crankshaft counterweight requires careful attention to detail and adherence to manufacturer specifications. This procedure typically involves disassembling parts of the engine.

1. **Engine Preparation:** Ensure the engine is completely cool and the spark plug wire is disconnected. Drain engine oil if necessary for access.
2. **Accessing the Crankshaft:** Depending on your engine model, this may involve removing the engine sump, flywheel, or other components to expose the crankshaft assembly. Refer to your specific engine's service manual for detailed disassembly instructions.
3. **Removing Old Counterweight (if applicable):** If replacing an existing counterweight, carefully remove it, noting its orientation.
4. **Installing New Counterweight:** Position the Briggs & Stratton 692423 counterweight onto the crankshaft in the correct orientation. Ensure it seats properly.
5. **Securing the Counterweight:** Fasten the counterweight using the appropriate bolts and torque them to the specifications found in your engine's service manual. Incorrect torque can lead to component failure or engine damage.
6. **Reassembly:** Reassemble all removed engine components, ensuring all fasteners are tightened to their correct specifications.
7. **Final Checks:** Reconnect the spark plug wire, refill engine oil if drained, and perform a test run to ensure proper operation and absence of unusual vibrations.

Note: Professional installation is recommended if you are not familiar with engine repair procedures.

Operating Considerations

Once installed, the crankshaft counterweight operates as an integral part of the engine's internal mechanics. No direct user operation is required for this specific component. Its function is to maintain engine balance during operation.

- Ensure the engine runs smoothly without excessive vibration after installation.

- Any unusual noises or vibrations after installation should be investigated immediately.

Maintenance

The Briggs & Stratton 692423 Engine Crankshaft Counterweight is designed for long-term durability and typically requires no specific routine maintenance once correctly installed. Its maintenance is generally part of overall engine maintenance.

- **Regular Engine Inspections:** During routine engine maintenance (e.g., oil changes, spark plug replacement), visually inspect accessible engine components for any signs of wear, damage, or loose fasteners.
- **Vibration Monitoring:** Pay attention to any changes in engine vibration levels. Increased vibration could indicate an issue with internal engine components, including the counterweight.
- **Cleanliness:** Keep the engine exterior clean to prevent debris from entering internal components during future service.

Troubleshooting

Issues related to the crankshaft counterweight are rare but can manifest as engine imbalance or excessive vibration. Since this is an internal engine component, troubleshooting often requires engine disassembly.

Common Issues and Solutions

Symptom	Possible Cause	Solution
Excessive engine vibration after installation	Counterweight not seated correctly, incorrect torque on fasteners, or other internal engine issue.	Re-check installation, verify torque specifications. If problem persists, consult engine service manual or a professional.
Unusual knocking or grinding noises from engine	Loose or damaged counterweight, or other severe internal engine damage.	Immediately shut down the engine. Do not operate. Requires professional inspection and repair.

Important: Do not attempt to operate an engine exhibiting severe symptoms. This can lead to catastrophic engine failure.

Specifications

- **Part Number:** 692423
- **Part Type:** Engine Crankshaft Counterweight
- **Brand:** Briggs & Stratton
- **Manufacturer:** Briggs & Stratton
- **Product Dimensions:** 1 x 7 x 8 inches (approximate, as per product listing)
- **Item Weight:** 7.22 pounds (approximate, as per product listing)
- **Condition:** New (Genuine OEM Part)

Warranty and Support

As a genuine Briggs & Stratton OEM part, this counterweight is typically covered by the standard Briggs & Stratton parts warranty. For specific warranty terms and conditions, please refer to the official Briggs & Stratton website or contact their customer support directly.

For technical assistance, service, or to locate an authorized service dealer, please visit the official Briggs & Stratton website or use the contact information provided in your engine's primary owner's manual.

- **Briggs & Stratton Official Website:** www.briggsandstratton.com
- **Customer Support:** Refer to the website for contact numbers and support options.

© 2023 Briggs & Stratton. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question