Fischer & Honsel 36331

Fischer & Honsel 36331 Wall Lamp Instruction Manual

Model: 36331

Introduction

This manual provides essential information for the safe installation, operation, and maintenance of your Fischer & Honsel 36331 Wall Lamp. This fixture features a main E27 light socket and an integrated, flexible LED reading light. Please read these instructions carefully before installation and retain them for future reference.

Important Safety Information:

- Always disconnect the power supply before installation, maintenance, or bulb replacement.
- Installation should be performed by a qualified electrician if you are unsure.
- This product is designed for indoor use only and is suitable only for enclosed spaces.
- Do not exceed the maximum wattage specified for the main E27 bulb (60W).
- Ensure all connections are secure and properly insulated.

Setup and Installation

The Fischer & Honsel 36331 Wall Lamp requires assembly and electrical connection. Follow these steps carefully.

Package Contents:

- Wall lamp fixture (main body with flexible LED arm)
- Lampshade
- Mounting hardware (screws, wall plugs)
- Instruction manual

Note: Main E27 bulb is not included.

Tools Required (Not Included):

- Screwdriver (Phillips head)
- Drill and drill bits (appropriate for wall material)
- Wire strippers
- Voltage tester
- Pencil
- Measuring tape

Installation Steps:

1. **Power Disconnection:** Before starting, turn off the main power supply at the circuit breaker to the area where the lamp will be installed. Verify power is off using a voltage tester.
2. **Mounting Location:** Choose a suitable location on the wall. Mark the drilling points for the mounting bracket using the lamp's base as a template.
3. **Drilling:** Drill holes at the marked points. Insert appropriate wall plugs if necessary.
4. **Wiring:** Connect the household electrical wires to the lamp's wires. Typically, this involves connecting live (L), neutral (N), and ground (E) wires. Ensure correct polarity and secure all connections with terminal blocks or wire nuts.
5. **Mounting the Fixture:** Secure the lamp's mounting bracket to the wall using the provided screws. Carefully attach the lamp body to the mounting bracket.
6. **Lampshade Assembly:** Attach the lampshade to the main fixture according to the design.
7. **Bulb Installation:** Insert one E27 bulb (max 60W, compatible with ESL 20W) into the main lamp socket. Do not overtighten.
8. **Power Restoration:** Once installation is complete and all connections are secure, restore power at the circuit breaker.



Image: The Fischer & Honsel 36331 Wall Lamp installed, highlighting its design and the flexible LED reading light. An inset shows the control switches.

Operating Instructions

Your Fischer & Honsel 36331 Wall Lamp is designed for ease of use, featuring independent control for the

main light and the integrated LED reading light.

Main Light Operation:

- The main light, which uses an E27 bulb, is typically controlled by a wall switch connected to the fixture's power supply.
- Flip the wall switch to turn the main light ON or OFF.

LED Reading Light Operation:

- The integrated LED reading light has its own dedicated switch located on the lamp's base.
- Press the switch to turn the LED reading light ON or OFF.
- The flexible arm allows you to adjust the direction of the LED light to suit your needs. Gently bend the arm to position the light.



Image: Detail of the two independent switches for controlling the main light and the LED reading light.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your wall lamp.

Cleaning:

- **Always disconnect power before cleaning.**
- Wipe the metal parts of the fixture with a soft, dry cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- For the lampshade, use a soft, slightly damp cloth if necessary, then dry immediately. Avoid excessive moisture.

Bulb Replacement (Main Light):

- **Ensure power is disconnected and the bulb has cooled down before attempting to replace it.**
- Carefully unscrew the old E27 bulb from the socket.
- Screw in a new E27 bulb, ensuring it does not exceed 60W. Compatible with 20W ESL bulbs.
- Restore power and test the light.

LED Reading Light:

- The LED module in the reading light is typically not user-replaceable. If it malfunctions, contact a qualified technician or the manufacturer.

Troubleshooting

If you encounter issues with your wall lamp, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Main light does not turn on.	No power supply; Faulty bulb; Loose wiring connection.	Check circuit breaker. Replace bulb. Verify wiring connections (with power off).
LED reading light does not turn on.	No power supply; Faulty switch; Faulty LED module.	Check main power. Ensure the LED switch is pressed. If still not working, contact support.
Light flickers.	Loose bulb; Incompatible bulb; Unstable power supply.	Tighten bulb. Ensure bulb type is compatible. Consult an electrician for power supply issues.
Lamp gets excessively hot.	Bulb wattage too high.	Replace bulb with one that does not exceed 60W.

Product Specifications



Image: The Fischer & Honsel 36331 Wall Lamp, showcasing its contemporary design and dual lighting functionality.

Model Number: 36331

Brand: Fischer & Honsel

Manufacturer: Honsel Leuchten

Dimensions (L x W x H): 26 x 16 x 28 cm

Item Weight: 900 Grams

Material: Metal

Fixture Color: Matte nickel/chrome

Lampshade Color: Warm White

Style: Contemporary

Power Source: AC

Voltage: 220 Volts

Main Light Socket: 1 x E27

Max Wattage (Main Light): 60 Watts (compatible with 20W ESL)

Secondary Light Source: Integrated LED (Power included)

Specific Uses: Suitable only for enclosed spaces

Assembly Required: Yes

Warranty Information

Specific warranty details for the Fischer & Honsel 36331 Wall Lamp are not provided in the product information. Please refer to your purchase documentation or contact the retailer for warranty terms and conditions.

Support

For technical assistance, replacement parts, or further inquiries regarding your Fischer & Honsel 36331 Wall Lamp, please contact your retailer or the manufacturer directly. Contact information is typically available on the product packaging or the manufacturer's official website.