Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Presto 07061

Presto 07061 22-inch Electric Griddle User Manual

Model: 07061
Brand: Presto

Important Safeguards

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse control probe, cord, or plug in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

Product Overview

The Presto 07061 22-inch Electric Griddle is designed for convenient and efficient cooking. Its extra-large cooking surface allows for preparing meals for the entire family, while detachable handles ensure compact storage in most standard 18-

inch kitchen cabinets. The griddle features a premium textured cooking surface for enhanced nonstick performance and easy cleaning. The Control Master heat control automatically maintains the desired cooking temperature, and the heavy cast aluminum base is virtually warp-proof. A slide-out drip tray simplifies cleanup, and the griddle is fully immersible once the heat control is removed.



The Presto 22-inch Electric Griddle in use, cooking a variety of breakfast foods simultaneously.

Key Features

- **EXTRA-LARGE COOKING SURFACE:** This 22-inch electric griddle offers an expansive cooking area, perfect for preparing meals for the entire family. The XL griddle ensures you have plenty of space to cook multiple items at once.
- **NONSTICK CERAMIC COATING:** The nonstick electric griddle features a PFAS-free ceramic coating with a textured surface, providing superior nonstick performance and making it easier to clean up after cooking.
- **REMOVABLE HANDLES FOR EASY STORAGE:** The innovative design includes detachable handles, allowing the XL griddle to fit in most standard 18-inch cabinets. Simply open the latch clips to remove the handles for compact storage.
- **PRECISION TEMPERATURE CONTROL:** The Control Master heat control system maintains your desired cooking temperature automatically, ensuring consistent results every time you use your nonstick electric griddle.
- **EASY TO CLEAN:** The slide-out drip tray collects excess grease and removes easily for quick and hassle-free cleanups. Plus, the heavy cast aluminum base is virtually warp-proof and fully immersible when the heat control is detached.
- **DURABLE AND RELIABLE DESIGN:** Crafted from heavy cast aluminum, this electric griddle is built to last, offering long-lasting durability and even heat distribution, making it a reliable addition to your kitchen.



Detailed diagram highlighting the key features of the Presto Electric Griddle.

Setup

Initial Cleaning

Before first use, wash the griddle base, handles, and drip tray in warm, soapy water. Rinse thoroughly and dry. Do not immerse the Control Master heat control in water or other liquids.

Attaching Handles and Drip Tray

The griddle comes with detachable handles for easy storage and cleaning. To attach the handles, simply open the latch clips on each handle and align them with the designated posts on the griddle base. Press firmly until they click into place, ensuring they are securely fastened. The slide-out drip tray easily slides into the opening at the front of the griddle.



Attaching the removable handles to the griddle base for secure setup.



Inserting the slide-out drip tray for grease collection during cooking.

Operating Instructions

Temperature Control

Insert the Control Master heat control into the griddle. Plug the cord into a 120V AC electrical outlet. Turn the temperature dial to your desired setting. The griddle features settings from WARM up to 400°F. The indicator light will turn off when the desired temperature is reached, and cycle on and off during cooking to maintain the temperature.

Cooking

Allow the griddle to preheat for approximately 5-10 minutes before placing food on the cooking surface. The large surface is ideal for cooking multiple items simultaneously, such as pancakes, eggs, bacon, or French toast. For best nonstick performance, avoid using metal utensils that could scratch the surface. Use heat-resistant plastic, nylon, or wooden utensils.



The griddle's large surface allows for cooking a full breakfast with ease.

Maintenance and Cleaning

Disassembly for Cleaning

Always unplug the Control Master heat control from the wall outlet and then from the griddle before cleaning. Allow the griddle to cool completely. Remove the slide-out drip tray. To remove the handles, open the latch clips and pull the handles away from the griddle base.



The removable handles make cleaning and storage more convenient.

Cleaning Instructions

The griddle base, with handles removed, is fully immersible and can be washed in a dishwasher or in warm, soapy water. The premium nonstick surface allows for stick-free cooking and easy cleaning. The slide-out drip tray can also be washed in warm, soapy water. Do not use steel wool or abrasive cleaners on the nonstick surface. For stubborn food residue, soak the griddle in warm, soapy water before cleaning.

Storage

With handles removed, the griddle base stores neatly in most standard 18-inch kitchen cabinets, allowing for compact and convenient storage.



The griddle's design allows for vertical storage in standard kitchen cabinets.

Troubleshooting

Problem	Possible Cause	Solution
Griddle not heating	Control Master not properly inserted or plugged in; power outlet issue.	Ensure Control Master is fully inserted into the griddle. Check if the power cord is securely plugged into a working outlet. Test the outlet with another appliance.

Problem	Possible Cause	Solution
Food sticking to surface	Surface not properly seasoned or cleaned; excessive heat; use of cooking sprays not recommended for nonstick surfaces.	Ensure the griddle surface is clean and free of residue. Adjust temperature setting. Avoid using aerosol cooking sprays as they can build up residue. Use a small amount of oil or butter if needed.
Uneven heating	Griddle not fully preheated; internal heating element issue.	Allow the griddle to preheat for the recommended 5-10 minutes until the indicator light turns off. If problem persists, contact customer support.
Handles difficult to remove/attach	Latch clips not fully engaged/disengaged; debris in mechanism.	Ensure latch clips are fully pressed or pulled. Check for any food particles or debris obstructing the mechanism and clean if necessary.

Specifications

Feature	Detail
Model Number	07061
Brand	Presto
Product Dimensions	13.5"D x 26.25"W x 2.5"H
Item Weight	5.7 Pounds
Wattage	1500 watts
Voltage	120 volts AC, 60 Hz
Material	Heavy Cast Aluminum Base, PFAS Free Ceramic Coating
Special Features	Removable handles, Immersible, Easy storage, Textured cooking surface
Included Components	1-Slide-Out Drip Tray, Presto 07061 22-Inch Electric Griddle
Color	Black
Country of Origin	China

Warranty and Support

The Presto 07061 22-inch Electric Griddle comes with a**1-year limited warranty** from the date of purchase. This warranty covers defects in material and workmanship under normal household use.

For warranty claims, technical support, or any questions regarding your Presto Electric Griddle, please contact Presto Customer Service. Keep your purchase receipt as proof of purchase for warranty validation.

For further assistance, please refer to the official Presto website or contact their customer support line.

© 2024 Presto. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B005FYF3OY

More documents and user manuals: **https://manuals.plus/**