Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Supersonic SC-1311

Supersonic SC-1311 13.3-Inch DLED HDTV User Manual

Model: SC-1311

1. Introduction

Thank you for purchasing the Supersonic SC-1311 13.3-Inch DLED HDTV. This manual provides essential information for the safe and efficient operation of your television. Please read this manual thoroughly before use and retain it for future reference.

2. Safety Information

To ensure safe operation and prevent damage, please observe the following precautions:

- Do not expose the TV to rain or moisture.
- Do not block ventilation openings.
- Use only attachments/accessories specified by the manufacturer.
- Refer all servicing to qualified service personnel.
- Ensure the power source matches the voltage requirements of the TV.

3. What's in the Box

Verify that all items are present upon unpacking:

- Supersonic SC-1311 13.3-Inch DLED HDTV
- Remote Control
- AC Power Adapter
- User Manual (this document)
- 2 AAA batteries (for remote control)

4. Product Overview

Front View



This image shows the front of the Supersonic SC-1311 DLED HDTV, highlighting its display and the brand logo. The screen is active, showing a vibrant image.

Back View



The rear panel of the Supersonic SC-1311 HDTV, illustrating the VESA mounting holes for wall installation and the location of the input/output ports.

Side View





A side view of the Supersonic SC-1311 HDTV, demonstrating its compact and slim profile, suitable for various placements.

Control Buttons



This image provides a top-down view of the television, revealing the physical control buttons located on the top edge of the unit for basic operation.

The TV features intuitive controls for power, volume, channel, and input selection, accessible via the side/top panel buttons or the included remote control.

Connectivity Ports

The Supersonic SC-1311 offers multiple connectivity options:

- **HDMI Input:** For connecting high-definition devices like Blu-ray players, gaming consoles, or streaming sticks.
- **USB Port:** For media playback from USB storage devices.
- **Antenna Input:** For connecting an external antenna for over-the-air broadcasts.
- **AC/DC Power Input:** Supports both standard AC power and 12V DC power for versatile use, including RVs and campers.

5. Setup

Connecting Power

Connect the AC power adapter to the TV's power input and then to a standard wall outlet. For 12V DC operation, use a compatible DC power source (not always included) with the appropriate connector.

Connecting External Devices

- **HDMI:** Use an HDMI cable to connect your device to the HDMI input port on the TV.
- **USB:** Insert a USB storage device into the USB port for accessing photos, music, or videos.
- **Antenna:** Connect a coaxial cable from your antenna to the ANT/CABLE input.

Mounting Options

The SC-1311 is designed to be wall-mountable. Ensure you use a VESA-compatible wall mount (sold separately) that supports the TV's weight and VESA pattern. Follow the wall mount manufacturer's instructions carefully for safe installation.

6. Operating Instructions

Power On/Off

Press the Power button on the remote control or on the TV's control panel to turn the TV on or off.

Input Selection

Press the 'Input' or 'Source' button on the remote control to cycle through available input sources (e.g., TV, HDMI, USB).

Menu Navigation

Use the arrow buttons on the remote to navigate through the on-screen menu. Press 'OK' or 'Enter' to confirm selections and 'Exit' or 'Menu' to return to the previous screen or exit the menu.

Picture and Sound Settings

Access the Picture menu to adjust settings such as brightness, contrast, color, and sharpness. The TV includes various picture modes and digital noise reduction for enhanced visual quality. The Sound menu allows adjustment of bass, treble, and selection of sound modes.

7. Maintenance

To maintain your TV's performance and appearance:

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, use a screen cleaner specifically designed for electronics.
- **Cleaning the Cabinet:** Wipe the cabinet with a soft, dry cloth. Avoid using abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings are clear of dust and obstructions to prevent overheating.

8. Troubleshooting

If you encounter issues with your TV, refer to the following common solutions:

- **No Power:** Check if the power adapter is securely connected to both the TV and the power outlet. Ensure the outlet is functional.
- **No Picture/Sound:** Verify the correct input source is selected. Check all cable connections (HDMI, antenna) for secure fit.
- **Poor Picture Quality:** Adjust picture settings in the menu. For antenna reception, try repositioning the antenna or performing a channel scan.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.

For further assistance, please contact Supersonic customer support.

9. Specifications

Feature	Specification
Brand	Supersonic
Model Number	SC-1311
Screen Size	13.3 Inches
Display Technology	DLED
Resolution	1080p
Refresh Rate	60 Hz
Aspect Ratio	16:9
Connectivity Technology	HDMI, USB
Output Wattage	18 Watts
Voltage	240 Volts (AC), 12 Volts (DC compatible)
Item Weight	2.56 Pounds
Product Dimensions	9 x 0.38 x 6 inches

Feature	Specification
Color	Black
Special Feature	Flat, Wall Mountable
Speaker Type	Multimedia
Batteries (Remote)	2 AAA batteries (included)

10. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official Supersonic website. You may also contact Supersonic customer service directly for assistance with product operation, troubleshooting, or parts replacement.

© 2025 Supersonic. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where is the DC power cord plug located on the Supersonic SC-1311 13.3-inch TV (2009 model)?

On the Supersonic SC-1311, the power input port is located on the rear panel of the television. According to the product overview, the input/output ports are grouped together on the back of the unit,...

Read full answer

Open the live page

https://manuals.plus/asin/B005GM6H8G

More documents and user manuals: **https://manuals.plus/**