Beurer UB 90

Beurer UB 90 Comfort Heated Underblanket User Manual

Model: UB 90

1. Introduction

The Beurer UB 90 Comfort Heated Underblanket is designed to provide warmth and comfort for your bed. Featuring individually adjustable temperature zones for the body and feet, it offers nine temperature levels and an anti-allergy setting. This underblanket is equipped with the Beurer Safety System (BSS) for secure operation and includes an automatic downgrade function for temperature levels. Its comfortable cotton top surface and integrated PURE silver finish ensure hygiene and freshness, and it is machine washable for easy care.



Figure 1: Beurer UB 90 Comfort Heated Underblanket with its control unit and product packaging.

2. Important Safety Warnings

Please read all safety instructions carefully before use to prevent injury or damage.

- Do not use a power cable different from the one supplied with the UB 90.
- Switch off the UB 90 if you detect excessive overheating.
- Do not use the UB 90 in the presence of liquid or excessive humidity.
- Keep the UB 90 out of reach of children and pets.
- Do not use the UB 90 if you are unconscious or have limited mobility.

3. Setup Instructions

1. Unpack the heated underblanket and ensure all components are present: the underblanket and the detachable control unit.

2. Lay the underblanket flat on your mattress, ensuring it is smooth and free of creases. The side with the control unit connector should be positioned near the head of the bed for easy access.
3. Connect the control unit securely to the connector on the underblanket. Ensure it clicks into place firmly.
4. Plug the power cable of the control unit into a suitable electrical outlet.



Figure 2: The Beurer UB 90 underblanket laid out on a bed, demonstrating its size and comfortable fit.

4. Operating Instructions

4.1 Powering On/Off

To turn on the underblanket, press the power button on the control unit. The LCD display will illuminate. To turn off, press the power button again.

4.2 Temperature Settings

The UB 90 features 9 temperature levels and individually adjustable temperature zones for the body and feet. Use the

dedicated buttons on the control unit to select your desired heat level for each zone.



Figure 3: The underblanket offers two distinct heat zones for customized comfort for the body and feet.

4.3 Automatic Downgrade Function

For safety and energy efficiency, the underblanket automatically downgrades the temperature from levels 7, 8, or 9 to level 6 after three hours of continuous operation. This feature helps prevent excessive heat exposure during prolonged use.



Figure 4: The automatic temperature reset feature ensures safe and comfortable use.

4.4 Anti-Allergy Temperature Level

The UB 90 includes a special anti-allergy temperature level designed to combat dust mites. Refer to the control unit's specific settings for activating this mode.

4.5 Preheating Time

The underblanket has a rapid heating function with a preheating time of approximately 15 minutes to reach your desired temperature.

4.6 Timer Function

You can individually set the operating time in hourly steps using the illuminated LCD display on the detachable switch.

5. Maintenance and Care

5.1 Cleaning Instructions

The Beurer UB 90 is machine washable up to 30°C. Before washing, always detach the control unit from the underblanket. Ensure the underblanket is completely dry before reattaching the control unit and using it again.



Figure 5: The underblanket is conveniently machine washable for easy hygiene.

5.2 Hygiene and Freshness

The integrated PURE silver finish provides an antibacterial and anti-odor effect, contributing to the hygiene and freshness of the underblanket.

6. Troubleshooting

Problem	Possible Cause	Solution
Underblanket does not heat.	Power cable not properly connected or control unit not attached correctly.	Check power plug connection. Ensure control unit is firmly attached to the underblanket.

Problem	Possible Cause	Solution
Underblanket overheats.	Improper use or malfunction.	Immediately switch off the UB 90. Allow it to cool down. Check for any obstructions or improper folding. If problem persists, discontinue use.
Temperature changes unexpectedly.	Automatic downgrade function activated.	This is normal behavior for levels 7, 8, or 9 after 3 hours. Adjust setting if desired.
Control unit display is off or unresponsive.	Loose connection or power issue.	Unplug and re-plug the power cable. Detach and reattach the control unit.

7. Specifications

Feature	Specification
Model Number	370.00
Dimensions (L x W x H)	150 x 80 x 0.1 cm
Weight	1.3 Kilograms
Power	60 Watts
Number of Temperature Settings	9
Material	Cotton
Special Features	Machine washable, Lightweight, Portable
Country of Origin	Hungary

8. Warranty and Support

For information regarding warranty coverage and customer support, please refer to the documentation included with your product packaging or visit the official Beurer website. Beurer has been a trusted brand in health and well-being products since 1919, committed to quality and customer satisfaction.

© 2025 Beurer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question