Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Whirlpool 1129313

Whirlpool 1129313 Ice Maker Kit

User Instruction Manual

Introduction

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Whirlpool 1129313 Add-On Ice Maker Kit. This kit is a genuine OEM (Original Equipment Manufacturer) part, designed and engineered to exact specifications for compatibility with Whirlpool refrigerators.

Important Safety Information:

- Always disconnect the appliance from all utilities (power, water) prior to any service or repair to prevent electric shock or water damage.
- It is recommended to use safety equipment, such as gloves and eye protection, during installation.
- Some repairs may require a trained service professional to complete. Refer to your appliance's owner's manual for specific instructions and to confirm part numbers.

Parts Included

The Whirlpool 1129313 Add-On Ice Maker Kit typically includes the following components:

- Ice Maker Assembly
- Wiring Harness
- Fill Tubes
- Water Valve
- Ice Bin
- Mounting Hardware (screws, clips, brackets)
- Installation Instructions



Figure 1: Components of the Whirlpool 1129313 Ice Maker Kit. This image displays all components included in the kit, typically laid out on a white surface. Visible parts include the main ice maker assembly, a water valve, various tubes and connectors, an ice storage bin, a wiring harness, and an assortment of screws and mounting hardware. An instruction manual is also shown.

Setup and Installation

This ice maker kit is designed for refrigerator models with 30, 33, and 36-inch wide cabinets. It can serve as a replacement or an add-on for compatible refrigerators and some full-sized upright freezers. Before proceeding, consult your appliance's Use & Care guide to confirm compatibility and specific installation requirements.

Pre-Installation Checklist:

- Verify appliance compatibility with the ice maker kit.
- Ensure all necessary tools are available (e.g., screwdrivers, pliers, wrench).
- Confirm access to a water supply line with adequate pressure.
- **Disconnect power and water supply to the refrigerator before beginning installation.**

Installation Steps (General Guidelines):

1. Locate the designated ice maker mounting area inside your refrigerator's freezer compartment.
2. Install the water valve according to your refrigerator's specific instructions, connecting it to the household water supply.
3. Route the fill tubes from the water valve to the ice maker assembly.
4. Mount the ice maker assembly securely using the provided hardware.
5. Connect the wiring harness from the ice maker assembly to the refrigerator's electrical connection point.
6. Place the ice bin in its designated position beneath the ice maker.

7. Reconnect the water supply and check for leaks.
8. Reconnect power to the refrigerator.
9. Allow several hours for the ice maker to produce its first batch of ice.

For detailed, model-specific installation instructions, always refer to the instruction manual included with your kit and your refrigerator's owner's manual.

Operation

Once properly installed and connected to a water supply, your Whirlpool ice maker will automatically produce ice. The ice maker typically has an ON/OFF switch or a wire arm that controls its operation.

- **Turning On:** Ensure the ice maker's control arm is in the down position or the switch is set to 'ON'.
- **First Ice Production:** After initial setup or prolonged disuse, it may take 12-24 hours for the ice maker to produce its first full batch of ice. Discard the first few batches of ice to ensure the water lines are flushed.
- **Ice Level Control:** The ice maker will stop producing ice automatically when the ice bin is full. If the control arm is lifted or the switch is set to 'OFF', ice production will cease.

Maintenance

Regular maintenance helps ensure optimal performance and longevity of your ice maker.

- **Cleaning the Ice Bin:** Periodically remove the ice bin and wash it with mild soap and warm water. Rinse thoroughly and dry completely before returning it to the freezer.
- **Water Filter (if applicable):** If your refrigerator has a water filter, ensure it is replaced regularly according to the manufacturer's recommendations to maintain water quality and ice production.
- **Water Line Inspection:** Occasionally check the water supply line and connections for any signs of leaks or kinks.
- **Vacation Mode:** If you will be away for an extended period, turn off the ice maker and empty the ice bin to prevent ice from clumping or developing odors.

Troubleshooting

Before calling for service, review the following common issues and their solutions:

Problem	Possible Cause	Solution
Ice maker not producing ice.	Ice maker is turned off. Water supply is off or kinked. Water filter is clogged. Freezer temperature is too high.	Ensure ice maker control arm is down or switch is ON. Check water supply valve and line for obstructions. Replace water filter. Adjust freezer temperature to 0°F (-18°C).
Small or hollow ice cubes.	Low water pressure. Clogged water filter. Partially frozen fill tube.	Check household water pressure. Replace water filter. Thaw and clear the fill tube.
Ice has an unusual taste or odor.	Old ice in bin. Contaminated water supply. Food odors in freezer.	Discard old ice and clean ice bin. Replace water filter. Ensure food is properly sealed in freezer.

If the problem persists after attempting these solutions, contact a qualified service technician.

Specifications

Brand	Whirlpool
Model Number	1129313
Item Weight	3 pounds
Product Dimensions	13.6 x 11.1 x 10 inches
Compatible Cabinet Widths	30, 33, and 36 inches
Replaces Part Numbers	1105298, 1114185, 1118554, 1118555, 1118746, 1129312, 1129313VP, 1129314, 2290, 468150, 8050, 8050-1, 8050-2, 8150, 940556, 941555, 984827, 987613, 99989732, AH317558, EA317558, ECK-MF11, ECK-MF2, ECK-MF3, ECK-MF4, ECK-MF5, ECK-MF51, ECK-MF6, ECK-MF61, ECK-MF63, ECK-MF64, ECKMF-64, ECKMF11, ECKMF2, ECKMF3, ECKMF4, ECKMF5, ECKMF51, ECKMF6, ECKMF61, ECKMF63, ECKMF64, KIMF8, PS317558, ECKMF94
UPC	050946006499, 050946232980

Warranty and Support

As a genuine OEM part, the Whirlpool 1129313 Ice Maker Kit is manufactured to high-quality standards. For specific warranty information regarding this part, please refer to the documentation included with your purchase or visit the official Whirlpool website.

For technical support, service inquiries, or to locate authorized service providers, please contact Whirlpool Customer Service directly or visit their official support channels. Always provide your product's model number (1129313) and your refrigerator's model number when seeking assistance.

You can find more information and support on theWhirlpool Store on Amazon.

© 2024 Whirlpool Corporation. All rights reserved.
This manual is for informational purposes only. Always prioritize safety and consult professional assistance when necessary.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B005HFB7E6

More documents and user manuals: **https://manuals.plus/**