GERBER DA511006N

GERBER Danze DA511006N 47-inch Stainless Steel Braided Side Spray Hose Instruction Manual

Model: DA511006N

Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of your GERBER Danze DA511006N 47-inch Stainless Steel Braided Side Spray Hose. Designed for durability and ease of use, this replacement part ensures reliable performance for your kitchen faucet system. Please read these instructions thoroughly before installation and use to ensure proper function and longevity of your product.

Safety Information

- Always turn off the main water supply before attempting any plumbing installation or repair.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- Ensure all connections are secure to prevent leaks. Do not overtighten, as this can damage threads.
- If you are unsure about any step, consult a qualified plumber.

Package Contents

Verify that all components are present before beginning installation:

- One (1) GERBER Danze DA511006N 47-inch Stainless Steel Braided Side Spray Hose



Image: The GERBER Danze DA511006N 47-inch Stainless Steel Braided Side Spray Hose, showing its chrome finish and braided construction.

Setup and Installation

This section outlines the steps for replacing an existing side spray hose with the GERBER Danze DA511006N. Basic plumbing tools are required.

Tools Required:

- Adjustable Wrench
- Plumber's Tape (optional, for extra seal)
- Bucket or Towel (to catch drips)

Installation Steps:

1. **Turn Off Water Supply:** Locate the shut-off valves under your sink and turn them clockwise to completely stop the

water flow to the faucet.

2. **Disconnect Old Hose:** Place a bucket or towel under the sink to catch any residual water. Using an adjustable wrench, carefully loosen and remove the old side spray hose from the faucet's diverter or connection point.
3. **Prepare New Hose:** Ensure the new GERBER Danze DA511006N hose has its rubber washers in place at both ends. If desired, apply a small amount of plumber's tape clockwise around the threads of the connection points for an extra seal.
4. **Connect New Hose:** Hand-tighten one end of the new hose to the side spray head and the other end to the faucet's diverter or connection point.
5. **Secure Connections:** Use the adjustable wrench to gently tighten both connections. Do not overtighten, as this can strip threads or damage the hose. A snug fit is sufficient.
6. **Restore Water Supply:** Slowly turn the water shut-off valves counter-clockwise to restore water flow.
7. **Check for Leaks:** Turn on the faucet and operate the side spray. Carefully inspect all connections for any signs of leaks. If leaks are present, tighten the connections slightly until they stop.



Image: A circular logo indicating "Genuine GERBER Replacement Parts" with text "High Quality & Crafted to Optimize Product Performance".

Operating Instructions

Using your GERBER Danze side spray hose is straightforward:

- Ensure the main faucet is turned on to allow water flow to the side spray.
- Lift the side spray head from its holder.
- Press the trigger or button on the side spray head to activate the water flow. Release the trigger to stop the flow.
- After use, return the side spray head to its holder.

Maintenance

Regular maintenance will help prolong the life and appearance of your side spray hose:

- **Cleaning:** Clean the chrome finish regularly with a soft cloth and mild soap and water. Avoid abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- **Inspection:** Periodically inspect the hose for any signs of wear, kinks, or damage. Replace the hose if any significant damage is observed to prevent leaks.
- **Connection Check:** Occasionally check the connections for tightness. If you notice any drips, gently tighten the connections with an adjustable wrench.

Troubleshooting

Problem	Possible Cause	Solution
Water leaks from connections.	Loose connections, damaged washer, improper installation.	Ensure connections are tightened properly. Check for damaged washers and replace if necessary. Re-install following instructions carefully.
Low water pressure from spray.	Main water supply not fully open, kink in hose, clogged spray head.	Ensure water shut-off valves are fully open. Check hose for kinks. Clean spray head nozzle if clogged.
Hose does not retract smoothly.	Obstruction under sink, hose tangled.	Clear any obstructions under the sink. Untangle the hose if it is twisted.

Specifications

- **Model:** DA511006N
- **Brand:** GERBER (Manufacturer: Danze)
- **Material:** Alloy Steel (Stainless Steel Braided)
- **Color:** Polished Chrome
- **Length:** 47 inches (119.4 cm)
- **Item Weight:** 191 g
- **Nominal Wall Thickness:** 0.03 inches
- **UPC:** 719934009538
- **Included Components:** Plumbing Parts or Fixture
- **Application:** Kitchen Side Spray Hose Replacement

Warranty and Support

GERBER products are manufactured to high-quality standards and are backed by a manufacturer's warranty. For specific warranty details, product support, or to inquire about replacement parts, please refer to the official GERBER website or contact their customer service department. Keep your purchase receipt as proof of purchase.
For further assistance, please visit: www.gerberonline.com

© 2024 GERBER. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question