Panasonic KX-TG1611

Panasonic KX-TG1611 DECT Cordless Telephone User Manual

Model: KX-TG1611

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Panasonic KX-TG1611 DECT Cordless Telephone. Please read this manual thoroughly before using the product and retain it for future reference.





Image 1.1: The Panasonic KX-TG1611 DECT Cordless Telephone, showing the handset docked in its base unit.

2. Setup

2.1 Package Contents

Verify that your package contains the following items:

- Cordless Handset
- Base Unit
- AC Power Adaptor for Base Unit
- Telephone Line Cord
- Rechargeable AAA Batteries (2)

2.2 Battery Installation

1. Remove the battery compartment cover on the back of the handset.
2. Insert the two supplied AAA rechargeable batteries, observing the correct polarity (+ and -).
3. Replace the battery compartment cover.

2.3 Base Unit Connection

1. Connect the AC power adaptor to the base unit and plug it into a standard electrical outlet.
2. Connect one end of the telephone line cord to the base unit and the other end to your telephone wall jack.

2.4 Initial Charge

Place the handset on the base unit. The handset will begin charging. For optimal battery performance, allow the handset to charge for approximately 7 hours before its first use.





Image 2.1: Side view of the handset correctly placed on the base unit for charging.

3. Basic Operation





Image 3.1: Close-up of the handset's 1-Line Dot LCD display and keypad.

3.1 Making Calls

1. Lift the handset from the base or press the **Talk** button ( ).
2. Dial the desired phone number.
3. Press the **Talk** button again to end the call, or place the handset back on the base unit.

3.2 Receiving Calls

When the phone rings, lift the handset or press any key (Any Key Answer) to answer the call. Alternatively, if Auto Talk is enabled, simply lifting the handset will answer the call.

3.3 Adjusting Volume

During a call, use the navigation buttons (up/down arrows) to adjust the earpiece volume. The ringer volume can be adjusted via the menu settings when the phone is idle.

3.4 Phonebook

The phonebook can store up to 50 names and numbers. To access, add, or edit entries, navigate through the menu using the **Menu**/**OK** button.

3.5 Caller ID

The phone is Caller ID capable and stores up to 50 caller memories. To view the Caller ID list, press the **Caller ID** button (usually the down arrow on the navigation pad when idle).

3.6 Redial Function

The phone stores the last 10 dialed numbers. Press the **Redial** button (often the up arrow on the navigation pad when idle) to access the redial list.

3.7 Clock and Alarm

Set the current time and date through the handset's menu. An alarm function is also available and can be configured in the settings.

4. Care and Maintenance

4.1 Cleaning

Wipe the handset and base unit with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure the device is unplugged from the power source before cleaning.

4.2 Battery Care

Use only the specified rechargeable AAA batteries. Do not dispose of batteries in fire. Replace batteries when their performance significantly diminishes.

5. Troubleshooting

If you experience issues with your telephone, try the following basic troubleshooting steps:

- **No Dial Tone:** Ensure the base unit is properly connected to the power outlet and the telephone line jack. Check if the handset batteries are charged.
- **Cannot Make/Receive Calls:** Verify all connections. If using a DSL service, ensure a DSL filter is installed.
- **Display Issues:** Recharge the handset batteries. If the display is blank, ensure the handset is powered on.
- **Poor Sound Quality:** Move the handset closer to the base unit. Ensure there are no large metal objects or other electronic devices interfering with the signal.
- **Handset Not Charging:** Ensure the handset is correctly seated in the base unit and the charging contacts are clean.

For more detailed troubleshooting, refer to the full user guide available on the Panasonic support website.

6. Specifications

Feature	Description
Model Number	KX-TG1611
Telephone Type	DECT Cordless
Frequency	1.8GHz
Display	1-Line Dot LCD, Amber Backlit
Phonebook Capacity	50 names and numbers
Caller ID Memory	50 callers
Redial Memory	10 numbers
Talk Time	Up to 15 hours

Feature	Description
Standby Time	Up to 170 hours
Batteries	2 x AAA rechargeable (included)
Charging Time	Approximately 7 hours
Dimensions (Handset)	2.79 x 24.64 x 16.51 cm
Weight (Handset)	126 g
Material	Acrylonitrile Butadiene Styrene (ABS)
Wall Mountable	Base unit is wall mountable

7. Warranty and Support

Your Panasonic KX-TG1611 DECT Cordless Telephone is covered by a manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions.
For technical assistance, spare parts, or further support, please visit the official Panasonic support website or contact their customer service department.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I set up call forwarding (call follow) on the Panasonic KX-TG1611 cordless phone?

Based on the manual for the Panasonic KX-TG1611, this specific model is a basic DECT cordless telephone and does not have a built-in menu setting for "Call Forwarding" or "Call Follow" directly on the...

Read full answer