Dyson DC34

Dyson DC34 Handheld Vacuum Instruction Manual

Model: DC34

1. Product Overview

The Dyson DC34 Handheld Vacuum is engineered for powerful and convenient cleaning. It features advanced technology to ensure consistent suction and ease of use for various tasks around your home or vehicle.



Figure 1.1: Dyson DC34 Handheld Vacuum Cleaner.

Key Features:

- **Dyson Digital Motor:** Provides powerful suction, up to three times faster than conventional motors.
- **Root Cyclone Technology:** Patented technology that prevents loss of suction power by spinning dust and dirt out of the air.
- **22.2 Volt Lithium-ion Battery:** Delivers consistent power without fade and recharges up to three times faster than other batteries.
- **Hygienic Bin Emptying:** Designed for quick and clean disposal of dirt with a simple push-button mechanism.
- **Lightweight and Ergonomic:** Weighing only 2.9 lbs, with balanced weight distribution for comfortable and easy handling.

2. Setup and Charging

Before first use, ensure your Dyson DC34 is fully charged. The powerful Lithium-ion battery recharges efficiently to provide optimal performance.

Charging Instructions:

1. Locate the charging port on the vacuum cleaner.
2. Connect the provided charging dock or power adapter to the vacuum.
3. Plug the power adapter into a suitable electrical outlet.
4. Allow the unit to charge completely. The battery indicator will show charging status.



Figure 2.1: Connecting the Dyson DC34 to its charger.

3. Operating the Vacuum

The Dyson DC34 is designed for versatile cleaning across various surfaces and situations.

Power Modes:

- **High Constant Suction:** Provides up to 15 minutes of powerful cleaning for everyday tasks.
- **Boost Mode:** For more difficult tasks requiring maximum suction, activate Boost mode for up to 6 minutes of intensified power.

Using Attachments:

The DC34 comes with various attachments to suit different cleaning needs. The wide debris nozzle can be converted into a brush

tool for delicate surfaces or to dislodge stubborn dirt.



Figure 3.1: The Dyson DC34 effectively cleaning debris from a floor surface.



Figure 3.2: Using the brush tool attachment to clean a keyboard.



Figure 3.3: The crevice tool for reaching tight spaces.

Official Product Video:

Watch the official Dyson video for a comprehensive demonstration of the DC34's features and operation, including its powerful digital motor, Root Cyclone technology, and versatile cleaning capabilities across various surfaces like shelves, tables, laptops, sofas, radiators, and car interiors.

[redacted]

Video 3.1: Dyson DC34 Cordless Vacuum Cleaner demonstration.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your Dyson DC34.

Emptying the Dust Bin:

The DC34 features a hygienic bin emptying mechanism. When the bin is full, simply press the release button to empty the contents directly into a waste bin, minimizing contact with dust and dirt.



Figure 4.1: Hygienically emptying the dustbin of the Dyson DC34.

Filter Cleaning:

Refer to the full user manual for detailed instructions on cleaning the cyclonic filter to maintain optimal suction power.

5. Troubleshooting

If you encounter any issues with your Dyson DC34, please refer to the following general advice. For specific problems, consult the comprehensive user manual or contact Dyson customer support.

- **No Power:** Ensure the battery is fully charged and the charger is properly connected.
- **Loss of Suction:** Check if the dust bin is full and needs emptying. Inspect the filter for blockages and clean as per instructions. Ensure no blockages in the nozzle or attachments.
- **Unusual Noises:** Discontinue use and check for any foreign objects lodged in the brush bar or air pathways.

6. Specifications

Brand	Dyson
Model Number	DC34
Special Feature	Cyclonic, Cordless, Bagless
Filter Type	Cyclonic Filter
Included Components	Charging Dock
Is Cordless?	Yes
Recommended Uses	Carpet, Furniture, Hard Floor, Home, Rug, Bare Floor, Sofa
Form Factor	Handheld
Color	Iron/Yellow
Battery Type	Lithium-Ion
Item Weight	0.01 ounces (approx. 2.9 lbs actual product weight)
Product Dimensions	4.4 x 12.7 x 8.1 inches
UPC	879957005235

Note: Item weight listed as 0.01 ounces is likely a data entry error; the product is stated to be 2.9 lbs in feature bullets.

7. Warranty and Support

Warranty Information:

The Dyson DC34 Handheld Vacuum is covered by a **2-year parts and labor warranty**, ensuring peace of mind regarding its durability and performance.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact the US-based Dyson customer support center. Contact details can typically be found on the official Dyson website or within your product packaging.

© 2023 Dyson. All rights reserved. This manual is for informational purposes only.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question