Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dainolite DAINDSTX-36-WH

Dainolite 36W White Floor Lamp User Manual

Model: DAINDSTX-36-WH

Introduction

Thank you for choosing the Dainolite 36W White Floor Lamp. This versatile fluorescent light stick is designed to provide even illumination without harsh glare, suitable for various indoor settings. It can function as a standalone floor lamp or be mounted to a wall or ceiling using the supplied clips. This manual provides essential information for safe installation, operation, and maintenance of your new lamp.

Safety Information

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- **WARNING:** This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.
- Ensure the power supply is disconnected before installation, cleaning, or maintenance.
- Do not operate the lamp with a damaged cord or plug.
- This lamp is designed for indoor use only. Do not expose to moisture or extreme temperatures.
- Use only the specified type and wattage of bulb (fluorescent, 36W) to avoid overheating or damage.

Package Contents

Carefully unpack the box and ensure all items are present and undamaged. If any parts are missing or damaged, do not attempt to assemble or use the lamp. Contact customer support immediately.

- Dainolite 36W White Floor Lamp (Fluorescent Light Stick)
- Power Cord with In-line Toggle Switch
- Mounting Clips (for wall/ceiling installation)

Setup Instructions

Your Dainolite lamp offers flexible installation options. Choose the method that best suits your needs.



Image: The Dainolite 36W White Floor Lamp, a slender, white fluorescent light stick, shown in a vertical orientation.

Option 1: Floor Lamp Setup

1. Place the lamp on a flat, stable surface where it will not be easily knocked over.

2. Ensure the power cord can reach an electrical outlet without being stretched or obstructed.
3. Proceed to the Operating Instructions.

Option 2: Wall or Ceiling Mounting

1. Identify the desired mounting location on a wall or ceiling. Ensure the surface is suitable for drilling and can support the lamp's weight.
2. Using the provided mounting clips, mark the positions for drilling. Ensure the clips are spaced appropriately to securely hold the lamp.
3. Drill pilot holes at the marked positions. Insert appropriate wall anchors if necessary (not included).
4. Secure the mounting clips to the wall or ceiling using screws (not included).
5. Carefully snap the lamp into the secured mounting clips.
6. Ensure the power cord can reach an electrical outlet without being stretched or obstructed.
7. Proceed to the Operating Instructions.

Operating Instructions

Operating your Dainolite lamp is straightforward.

1. Plug the lamp's power cord into a standard 120V AC electrical outlet.
2. Locate the in-line toggle switch on the power cord.
3. Flip the toggle switch to the 'ON' position to illuminate the lamp.
4. Flip the toggle switch to the 'OFF' position to turn off the lamp.

Maintenance

Regular maintenance will help prolong the life and appearance of your lamp.

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Use a soft, dry cloth to wipe down the lamp's surface. Do not use abrasive cleaners, solvents, or polishes, as these may damage the finish.
- **Bulb Replacement:** This lamp uses a 36W fluorescent bulb. When replacing, ensure the lamp is unplugged and the bulb has cooled. Carefully remove the old bulb and insert a new one of the same type and wattage.

Troubleshooting

If you encounter issues with your lamp, try the following solutions:

- **Lamp does not turn on:**
  - Ensure the power cord is securely plugged into a working electrical outlet.
  - Check if the in-line toggle switch is in the 'ON' position.
  - Verify that the electrical outlet is functional by plugging in another device.
  - Check the bulb. If it's old or appears burnt out, replace it with a new 36W fluorescent bulb.
- **Light is flickering:**
  - Ensure the bulb is securely seated in its socket.
  - The bulb may be nearing the end of its life. Try replacing it with a new 36W fluorescent bulb.
  - Ensure the lamp is receiving consistent power from the outlet.

If these steps do not resolve the issue, please contact customer support.

Specifications

Brand	Dainolite
Model Number	DAINDSTX-36-WH
Product Dimensions	1.5 x 1.5 x 53 inches
Item Weight	1.25 pounds
Color	White
Material	Metal (Frame), Glass (Shade)
Type of Bulb	Fluorescent
Wattage	36 watts
Voltage	120 volts
Power Source	Corded-Electric
Switch Style	In-line Toggle
Light Direction	Uplight
Special Features	Eco-Friendly

Warranty Information

Specific warranty details for the Dainolite 36W White Floor Lamp are not provided in this manual. Please refer to the warranty card included with your purchase or contact Dainolite directly for information regarding warranty coverage and terms.

Customer Support

For further assistance, technical support, or to inquire about replacement parts, please contact the retailer where you purchased the product or visit the official Dainolite website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B006WZFCG4

More documents and user manuals: **https://manuals.plus/**