Lovehoney Silencer

Lovehoney Silencer Whisper Quiet Classic Vibrator Instruction Manual

Model: Silencer

1. Introduction

This manual provides essential information for the safe and effective use of your Lovehoney Silencer Whisper Quiet Classic Vibrator. Please read all instructions carefully before first use and retain this manual for future reference.



Image 1.1: The Lovehoney Silencer Whisper Quiet Classic Vibrator.

2. Product Features

- **Whisper-Quiet Operation:** Designed for discreet use with minimal sound output.
- **Material:** Smooth-coated plastic for comfortable use.
- **Design:** Rounded tip and wavy shaft for varied stimulation.
- **Vibration Settings:** 3 speeds and 4 patterns, controlled by a single push button.
- **Waterproof:** Fully submersible for use in the bath or shower, and easy cleaning.
- **Dimensions:** 7 inches insertable length, 4.75 inches circumference.



Image 2.1: Rounded tip and wavy length for targeted stimulation.



Image 2.2: The vibrator features a 7-inch insertable length.

3. Setup

3.1 Battery Installation

1. Twist the base of the vibrator counter-clockwise to open the battery compartment.
2. Insert 2 AA batteries, ensuring correct polarity (+/-).
3. Twist the base clockwise until securely closed. Ensure it is tightly sealed for waterproof functionality.

Note: Always use fresh batteries for optimal performance. Do not mix old and new batteries.

4. Operating Instructions

4.1 Power On/Off and Mode Selection

1. To turn on, press and hold the power button located on the base for 2-3 seconds. The vibrator will start on its lowest speed.
2. Press the power button repeatedly to cycle through the 3 speeds and 4 vibration patterns.
3. To turn off, press and hold the power button for 2-3 seconds until the vibrations stop.



Image 4.1: The single push button on the base controls all functions.

Your browser does not support the video tag.

Video 4.1: Demonstration of the Lovehoney Silencer Whisper Quiet Classic Vibrator's features and operation.

5. Cleaning and Maintenance

5.1 Cleaning

- Always clean your vibrator before and after each use.
- Wash with warm water and a toy cleaner or mild antibacterial soap.

- Rinse thoroughly and pat dry with a lint-free cloth.

5.2 Lubrication

- For optimal comfort and pleasure, use a water-based lubricant with this product.
- Avoid silicone-based lubricants as they can damage plastic materials.



Image 5.1: The vibrator is fully submersible for easy cleaning.

6. Storage

Store your vibrator in a clean, dry place away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent damage or reactions.

7. Troubleshooting

7.1 Device Not Turning On

- Ensure batteries are inserted correctly with the proper polarity.
- Replace with fresh AA batteries.
- Check that the battery compartment is securely closed.

7.2 Weak Vibrations

- Batteries may be low. Replace with fresh AA batteries.
- Ensure the battery compartment is tightly sealed.

8. Specifications

Feature	Detail
Model Name	Silencer
Brand	Lovehoney
Material	Plastic
Color	Pink
Insertable Length	7 inches
Circumference	4.75 inches
Product Dimensions	11.42 x 3.54 x 2.36 inches
Weight	7.04 ounces
Power Source	2 AA batteries (not included)
Functions	3 speeds, 4 patterns
Waterproof	Yes, fully submersible

9. Safety Information

- This product is intended for adult use only.
- Discontinue use immediately if you experience any discomfort or pain.
- Do not use if the product appears damaged or cracked.
- Consult a healthcare professional if you have any concerns about using this product.
- Keep out of reach of children.

10. Warranty and Support

For warranty information and customer support, please refer to the official Lovehoney website or contact their customer service directly. Keep your proof of purchase for any warranty claims.
For further assistance, visit: Lovehoney Store on Amazon

© 2026 Lovehoney. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question