Morphy Richards 28 RSS

Morphy Richards 28 RSS Oven Toaster Grill User Manual

Model: 28 RSS | Capacity: 28 Liters | Power: 1600 Watts

1. Introduction

Thank you for choosing the Morphy Richards 28 RSS Oven Toaster Grill. This appliance is designed for versatile cooking, including baking, grilling, and toasting. To ensure safe and efficient operation, please read this manual thoroughly before first use and retain it for future reference.



Image: The Morphy Richards 28 RSS Oven Toaster Grill with its door open, revealing the interior rack.

2. Important Safety Instructions

- Always place the appliance on a stable, heat-resistant surface, away from walls and other appliances to ensure proper ventilation.
- Do not touch hot surfaces. Use oven mitts or gloves when handling hot items or parts.
- Ensure the power cord does not come into contact with hot surfaces.
- Unplug the appliance from the outlet when not in use and before cleaning. Allow it to cool completely before adding or removing parts.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.

- Do not insert oversized foods or metal utensils into the oven as they may create a fire or risk of electric shock.
- Never use abrasive cleaners or metal scouring pads to clean the oven.

3. Parts and Features

Familiarize yourself with the components of your Morphy Richards 28 RSS OTG:

- **Temperature Control Knob:** Adjusts temperature from 100°C to 250°C.
- **Function Selector Knob:** Selects cooking modes (Keep Warm, Broil, Rotisserie, Bake, Toast).
- **Timer Knob:** Sets cooking time up to 60 minutes or selects 'Stay On' mode.
- **Power Indicator Light:** Illuminates when the oven is operating.
- **Glass Door:** Tempered glass for viewing cooking progress.
- **Wire Rack:** For grilling and supporting baking trays.
- **Baking Tray:** For baking items.
- **Crumb Tray:** Collects crumbs and drips for easy cleaning.
- **Rotisserie Rod Set:** For rotisserie cooking.
- **Rotisserie Tong:** For safely handling the hot rotisserie rod.
- **Skewer Rods:** For grilling kebabs.
- **Tong:** General purpose tong for handling hot accessories.



Image: Close-up view of the control panel with temperature, function, and timer knobs.



Image: The included baking tray, suitable for various baking needs.



Image: The removable crumb tray for easy cleaning of food debris.



Image: The rotisserie tong, used for safe handling of the hot rotisserie rod.

4. Setup and First Use

4.1 Unpacking and Placement

1. Remove all packaging materials, including any internal packing and protective films.
2. Place the OTG on a flat, stable, and heat-resistant surface. Ensure there is at least 10-15 cm of clear space on all sides for adequate ventilation.
3. Do not place the appliance near flammable materials or under overhead cabinets.

4.2 Before First Use (Burn-in Process)

It is recommended to perform a burn-in cycle before cooking food for the first time to eliminate any manufacturing odors.

1. Insert the baking tray and wire rack into the oven.

2. Set the Temperature Control Knob to 250°C.
3. Set the Function Selector Knob to 'Toast' (both top and bottom heating elements).
4. Set the Timer Knob to 15-20 minutes.
5. The oven will emit a slight odor and possibly some smoke during this process. This is normal. Ensure the area is well-ventilated.
6. Once the cycle is complete, turn all knobs to 'OFF' and allow the oven to cool down completely.

5. Operation

This section details how to use the various cooking functions of your OTG.

5.1 General Operation Steps

1. Place the food item on the appropriate accessory (wire rack, baking tray, rotisserie rod).
2. Insert the accessory into the desired rack position inside the oven.
3. Close the oven door securely.
4. Set the Temperature Control Knob to the desired temperature.
5. Set the Function Selector Knob to the desired cooking mode.
6. Set the Timer Knob to the desired cooking time. The power indicator light will illuminate.
7. When the timer reaches 'OFF', a bell will ring, and the oven will turn off. If using 'Stay On' mode, manually turn the timer to 'OFF' when cooking is complete.
8. Carefully remove the cooked food using oven mitts and the provided tongs.

5.2 Cooking Functions

- **Keep Warm:** Activates the top heating element lightly to keep food warm without further cooking.
- **Broil (Grill):** Uses the top heating elements for grilling. Ideal for meats, vegetables, and browning dishes.
- **Rotisserie:** Activates the top heating elements and the rotisserie motor for even roasting of poultry or larger meat cuts.
- **Bake:** Primarily uses the bottom heating element, with a lightly activated top element, for baking cakes, cookies, and casseroles.
- **Toast:** Activates both top and bottom heating elements for toasting bread or similar items.

Your browser does not support the video tag.

Video: An overview of the Morphy Richards 28 RSS Oven Toaster Grill, demonstrating its features and potential uses, such as baking a pizza.



Image: The oven toaster grill in use, with a pizza baking inside on the wire rack.

6. Cleaning and Maintenance

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. Always unplug the oven and allow it to cool completely before cleaning.
2. **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, a non-abrasive cleaner can be used. Avoid spraying cleaners directly onto heating elements.
3. **Exterior:** Wipe the exterior with a damp cloth. Do not use abrasive cleaners or polishes.
4. **Accessories:** The baking tray, wire rack, crumb tray, rotisserie rod, and tongs can be washed in warm, soapy water. Rinse thoroughly and dry completely before storing or reusing.
5. **Crumb Tray:** Remove the crumb tray regularly and empty it. Wash as needed.

7. Troubleshooting

Problem	Possible Cause	Solution
Oven does not turn on.	Not plugged in; power outlet malfunction; timer not set.	Ensure the plug is securely in the outlet. Check the power outlet with another appliance. Set the timer to the desired duration or 'Stay On'.
Food is cooking unevenly.	Incorrect rack position; oven not preheated; food too close to heating elements.	Adjust rack position. Preheat the oven for 5-10 minutes before placing food inside. Use the drip tray on a lower notch to disperse heat if food is charring.
Timer does not activate below 10 minutes.	Mechanical design of the timer.	For timings under 10 minutes, use the 'Stay On' mode and a separate kitchen timer, then manually turn the knob to 'OFF'.
Oven exterior gets very hot.	Normal operation for OTGs.	This is normal. Always use oven mitts and avoid touching hot surfaces. Ensure adequate ventilation around the appliance.
Oven power cycles on and off during operation.	Thermostat regulating temperature.	This is normal. The thermostat cycles the heating elements on and off to maintain the set temperature.

8. Product Specifications

Feature	Detail
Brand	Morphy Richards
Model Number	28 RSS
Capacity	28 Liters
Power (Wattage)	1600W
Product Dimensions	32.5D x 45W x 27H Centimeters
Control Type	Knob

Feature	Detail
Special Features	Non-stick coating, Temperature Control
Door Material	Tempered Glass
Included Components	Oven toaster grill, Baking tray, Crumb tray, Rotisserie rod set, Rotisserie tong, Wire rack, Skewer rod, Tong, Instructional manual, Customer care list and Guarantee card
Item Weight	9 kg 320 g



Image: Rear view of the Morphy Richards 28 RSS OTG, showing the power cord and ventilation.

9. Warranty and Support

9.1 Warranty Information

This Morphy Richards 28 RSS Oven Toaster Grill comes with a **2-year warranty** from the date of purchase. Please refer to the Guarantee Card included with your product for detailed terms and conditions. Keep your purchase receipt as proof of purchase for warranty claims.

9.2 Customer Support

For any service, repair, or technical assistance, please contact Morphy Richards customer care. A customer care list is provided with your product for contact details. Ensure you have your model number (28 RSS) and purchase details ready when contacting support.

© 2023 Morphy Richards. All rights reserved.