Meyer MPC-2.3RD

Meyer MPC-2.3RD Microwave Pressure Cooker Instruction Manual

Model: MPC-2.3RD | Brand: Meyer

Introduction

This manual provides essential instructions for the safe and effective use of your Meyer MPC-2.3RD Microwave Pressure Cooker. Please read all instructions carefully before first use and retain this manual for future reference.

Important Safety Information

- Always ensure the lid is properly sealed before microwaving.
- Do not exceed the maximum fill line to prevent over-pressurization.
- Use only in microwave ovens with a maximum wattage of 700 watts. Higher wattage microwaves may require reduced cooking times or lower power settings to prevent damage or overcooking.
- Allow pressure to release naturally or use the quick-release method (if applicable) before opening the lid.
- Always use oven mitts when handling the hot pressure cooker.
- Keep out of reach of children.
- Do not use on stovetops or conventional ovens.
- Inspect the cooker for any damage before each use. Do not use if damaged.

Product Components

The Meyer MPC-2.3RD Microwave Pressure Cooker includes the following parts:

- Cooker Base (2.3 Liter capacity)
- Lid with pressure indicator and release valve
- Food Basket
- Steamer Plate



Image 1: The Meyer MPC-2.3RD Microwave Pressure Cooker, fully assembled with its red lid.

Setup and First Use

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, wash all parts (cooker base, lid, food basket, steamer plate) with warm, soapy water. Rinse thoroughly and dry. All parts are dishwasher safe.
3. **Assembly:**
    - Place the steamer plate at the bottom of the cooker base if steaming.
    - Insert the food basket into the cooker base if using for steaming or separating ingredients.
    - Ensure the lid is clean and the pressure valve is clear.

Operating Instructions

Follow these steps for safe and effective microwave pressure cooking:

1. **Add Ingredients:** Place your ingredients into the cooker base. If using the food basket or steamer plate, arrange food accordingly. Add the required amount of liquid (water, broth, etc.) as per your recipe. *Do not exceed the maximum fill line.*
2. **Secure the Lid:** Place the lid onto the cooker base, aligning the handles. Rotate the lid clockwise until it locks securely into place. Ensure the pressure indicator valve is properly seated.
3. **Microwave Cooking:**

- Place the assembled pressure cooker into your microwave oven.
- Set your microwave to the appropriate power level and cooking time as specified by your recipe. For microwaves with wattage higher than 700W, consider reducing cooking time or power level.
- During cooking, the pressure indicator will rise, indicating pressure has built up inside.

4. **Pressure Release:** Once cooking is complete, carefully remove the pressure cooker from the microwave using oven mitts.
    - **Natural Release:** Allow the cooker to stand undisturbed for several minutes until the pressure indicator drops completely. This is recommended for foamy foods or larger cuts of meat.
    - **Quick Release:** If your model has a quick-release button (a white button on one handle), press it to release steam rapidly. *Exercise extreme caution as hot steam will be released. Keep hands and face away from the steam vent.*
5. **Open the Lid:** Once the pressure indicator has dropped and all steam has been released, rotate the lid counter-clockwise to unlock and carefully remove it. Always open the lid away from your face to avoid residual steam.
6. **Serve:** Your meal is now ready to serve.



Image 2: Cooked potatoes inside the Meyer microwave pressure cooker, ready for serving.



Image 3: A variety of steamed vegetables, including carrots, broccoli, and cauliflower, prepared in the Meyer microwave pressure cooker.



Image 4: A hearty stew with meat and vegetables simmering in the Meyer microwave pressure cooker.

Care and Maintenance

- **Cleaning:** All parts of the Meyer MPC-2.3RD Microwave Pressure Cooker are dishwasher safe. For hand washing, use warm, soapy water and a soft sponge. Rinse thoroughly.
- **Drying:** Ensure all parts are completely dry before storing to prevent odors or bacterial growth.
- **Storage:** Store the cooker in a clean, dry place. You may store the lid inverted on the base to allow air circulation.
- **Inspection:** Regularly inspect the lid gasket and pressure valve for wear or damage. Replace if necessary to ensure proper sealing and safe operation.

Troubleshooting

Problem	Possible Cause	Solution
Cooker not building pressure / Steam escaping from lid.	Lid not properly sealed; Gasket dirty or damaged; Pressure valve obstructed.	Ensure lid is locked securely. Clean or inspect the gasket and pressure valve for food debris or damage. Replace gasket if worn.
Food is undercooked.	Insufficient cooking time; Microwave wattage too low; Too much liquid.	Increase cooking time. Adjust power settings for lower wattage microwaves. Reduce liquid slightly in future recipes. Ensure pressure was maintained during cooking.
Microwave stops during cooking / Overheating.	Microwave oven is too powerful for the cooker; Cooker is overfilled.	Reduce microwave power setting or cooking time. Ensure the cooker is not filled above the maximum line. Consult your microwave oven's manual for safe usage with pressure cookers.

Product Specifications

Feature	Detail
Brand	Meyer
Model Number	MPC-2.3RD
Capacity	2.3 Liters (approximately 0.6 gallons)
Material	Plastic
Color	Red
Special Features	Dishwasher Safe, Locking Lid
Recommended Microwave Wattage	Up to 700 watts (adjust cooking time/power for higher wattage)
Item Weight	0.65 Kilograms (1.43 pounds)
Product Dimensions (L x W x H)	8.66 x 10.24 x 4.92 inches
Operation Mode	Manual

Warranty Information

Specific warranty details for the Meyer MPC-2.3RD Microwave Pressure Cooker may vary by region and retailer. Please refer to the packaging or contact Meyer customer support for comprehensive warranty information.
Generally, products are covered against manufacturing defects for a limited period from the date of purchase. Keep your proof of purchase for any warranty claims.

Customer Support

For further assistance, questions, or to report any issues with your Meyer Microwave Pressure Cooker, please contact Meyer customer support.
You can often find contact information on the official Meyer website or through the retailer where you purchased the product.

Note: Always provide your product model number (MPC-2.3RD) and purchase date when contacting support.

© 2024 Meyer. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question