Samsung DVD-E360

Samsung DVD-E360 DVD Player Instruction Manual

Model: DVD-E360

1. Introduction

Thank you for purchasing the Samsung DVD-E360 DVD Player. This manual provides essential information for setting up, operating, and maintaining your device. Please read it thoroughly to ensure optimal performance and safe use.



Image: Front view of the Samsung DVD-E360 DVD Player, a compact black unit with a disc tray and control buttons.

2. Safety Information

Always follow basic safety precautions when using this product to reduce the risk of fire, electric shock, and injury. Keep the player away from water and moisture. Do not block ventilation openings. Refer to the full safety guidelines in the included printed manual.

3. Package Contents

Ensure all items are present in the box:

- Samsung DVD-E360 DVD Player
- Remote Control (batteries not included, requires 2 AAA batteries)
- Composite RCA Cable (Yellow, Red, White)
- Power Cord
- User Manual

4. Product Overview

Front Panel

- **Power Button:** Turns the player on/off.
- **Disc Tray:** For inserting DVDs and CDs.
- **Open/Close Button:** Opens and closes the disc tray.
- **Play/Pause Button:** Starts or pauses playback.
- **Stop Button:** Stops playback.
- **USB Port:** For connecting USB storage devices for media playback.
- **Display:** Shows playback status and time.

Rear Panel

- **HDMI Output:** Connects to an HDTV or projector for high-definition video and audio.
- **RCA Output (Composite Video/Audio):** Connects to older TVs or audio systems.
- **Coaxial Digital Audio Output:** For connecting to a compatible audio receiver for enhanced sound.
- **Power Input:** Connects the power cord.

5. Setup

5.1 Connecting to Your TV

Choose one of the following connection methods:

1. **HDMI Connection (Recommended for HDTVs):**
   Connect one end of an HDMI cable (not included) to the HDMI OUT port on the DVD player and the other end to an HDMI IN port on your TV. Select the corresponding HDMI input on your TV.
2. **RCA Connection (for older TVs):**
   Connect the yellow video cable to the VIDEO OUT port on the DVD player and the yellow VIDEO IN port on your TV. Connect the red and white audio cables to the AUDIO R (Red) and AUDIO L (White) OUT ports on the DVD player and the corresponding AUDIO R and AUDIO L IN ports on your TV. Select the AV input on your TV.

5.2 Power Connection

Plug the power cord into the AC INPUT on the rear of the DVD player, then plug the other end into a wall outlet.

5.3 Initial Setup

Turn on your TV and the DVD player. Follow any on-screen prompts for initial language and display settings. Ensure your TV input is set to the correct HDMI or AV port.

Video: A demonstration of connecting a DVD player to a TV using an HDMI cable and plugging in the power cord. This video also highlights the various ports on the back of the player and the front panel controls.

6. Operating Instructions

6.1 Playing a Disc

1. Press the Power button to turn on the DVD player.
2. Press the Open/Close button to open the disc tray.
3. Place a DVD or CD onto the disc tray with the label side facing up.
4. Press the Open/Close button again to close the tray. The player will automatically begin playback or display the disc menu.
5. Use the remote control to navigate menus and control playback (Play, Pause, Stop, Skip, Fast Forward, Rewind).

6.2 USB Playback

The DVD-E360 supports playback of MP3, WMA, and JPEG files from a USB flash drive (FAT32 format, up to 128GB). NTFS and exFAT formats are not supported.

1. Insert your USB flash drive into the USB port on the front panel.
2. The player should automatically detect the USB device and display its contents. If not, press the 'USB' button on the remote or select the USB input from the main menu.
3. Navigate through your files using the remote control and press 'OK' or 'Play' to start playback.

6.3 Remote Control Functions

The remote control provides full functionality for the DVD player, including:

- Power On/Off
- Disc Tray Open/Close
- Playback Controls (Play, Pause, Stop, Fast Forward, Rewind, Skip)
- Menu Navigation (Arrow keys, OK)
- Volume Control (if connected directly to an audio system)
- Subtitle, Audio, Angle selection
- Zoom, Repeat, Parental Controls

7. Maintenance

To ensure the longevity of your DVD player:

- Keep the unit clean by wiping it with a soft, dry cloth.
- Avoid using liquid cleaners or abrasive materials.
- Handle discs by their edges to prevent scratches.
- Do not insert damaged or irregularly shaped discs.

8. Troubleshooting

If you encounter issues, try these solutions:

Problem	Solution
No power	Check if the power cord is securely connected to the player and the wall outlet.

Problem	Solution
No picture/sound	Ensure the HDMI or RCA cables are correctly connected and your TV is on the correct input source.
Disc not playing	Check if the disc is inserted correctly (label side up) and is clean/undamaged. Ensure it is a compatible DVD or CD (not Blu-ray).
USB device not recognized	Ensure the USB drive is formatted to FAT32 and contains compatible media files (MP3, WMA, JPEG).

9. Specifications

Feature	Description
Model Name	DVD-E360
Media Type	DVD, CD
Special Feature	Progressive Scan
Video Output Resolution	1080p (upscaled)
Connector Type	HDMI, RCA
Connectivity Technology	USB
Audio Output Mode	Surround
Supported Audio Format	Dolby Digital, DTS Surround
Video Encoding	MPEG-2, MPEG-4, WMV
File Format (USB)	MP3, JPEG, WMA
Item Weight	2.4 Pounds

10. Warranty & Support

This Samsung DVD-E360 DVD Player comes with a**1-year warranty** covering both labor and parts. For technical support, service, or warranty claims, please refer to the contact information provided in your product packaging or visit the official Samsung support website.