Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

T'nB HPMX21WH

T'nB HPMX21WH 2.1 Multimedia Computer Speakers User Manual

Model: HPMX21WH

1. Introduction

Thank you for choosing the T'nB HPMX21WH 2.1 Multimedia Computer Speakers. This manual provides detailed instructions for the proper setup, operation, maintenance, and troubleshooting of your new speaker system. Please read this manual thoroughly before using the product to ensure optimal performance and longevity.



Figure 1: T'nB HPMX21WH Speakers product packaging.

This image displays the retail packaging of the T'nB HPMX21WH 2.1 Multimedia Computer Speakers. The box features the T'nB logo, "MULTIMEDIA SPEAKERS" text, and an illustration of the white subwoofer and two satellite speakers. Key features like "MX 2.1 VOLUME CONTROL UNIVERSAL" and compatibility with "NOTEBOOK, TABLET PCs, COMPUTER..." are highlighted.

2. Package Contents

Please verify that all items listed below are present in your package:

- 1 x T'nB HPMX21WH Subwoofer
- 2 x T'nB HPMX21WH Satellite Speakers
- 1 x Audio Input Cable (3.5mm jack)
- 1 x Power Cable
- 1 x User Manual (this document)



Figure 2: T'nB HPMX21WH Speakers and Subwoofer.

This image shows the T'nB HPMX21WH 2.1 speaker system components. It features the central white subwoofer unit with a front-facing speaker and a volume knob, flanked by two smaller white and black satellite speakers. The overall design is compact and modern.

3. Setup Instructions

Follow these steps to set up your T'nB HPMX21WH speaker system:

1. **Placement:** Position the subwoofer on a flat, stable surface, ideally on the floor or a sturdy desk. Place the two satellite speakers on either side of your computer monitor or listening area, ensuring they are equidistant from your listening position for optimal stereo sound.
2. **Connect Satellite Speakers:** Locate the audio output ports on the back of the subwoofer. Connect the cables from the two satellite speakers into these designated ports. Ensure a firm connection.
3. **Connect Audio Source:** Take the 3.5mm audio input cable. Plug one end into the "Audio In" port on the subwoofer and the other end into the headphone jack or audio output port of your computer, laptop, tablet, or other audio device.
4. **Connect Power:** Plug the power cable into the power input port on the subwoofer. Then, plug the other end of the power cable into a standard electrical wall outlet.
5. **Power On:** Locate the power switch, usually on the back or front of the subwoofer. Turn the switch to the "ON" position. An indicator light (if present) should illuminate.

Your T'nB HPMX21WH speakers are now ready for use.

4. Operating Instructions

Once set up, operating your speakers is straightforward:

- **Volume Control:** The main volume control knob is located on the front of the subwoofer. Rotate it clockwise to increase the volume and counter-clockwise to decrease it.
- **Audio Source Volume:** For best sound quality, set the volume on your computer or audio device to about 75-80% and then adjust the main volume on the speakers.
- **Power Off:** When not in use, it is recommended to turn off the speakers using the power switch to conserve energy.

5. Maintenance and Care

To ensure the longevity and optimal performance of your speakers, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the surfaces of the speakers and subwoofer. Do not use liquid cleaners, aerosols, or abrasive materials, as they may damage the finish or internal components.
- **Environment:** Keep the speakers away from direct sunlight, excessive heat, humidity, and dust. Ensure adequate ventilation around the subwoofer to prevent overheating.
- **Handling:** Avoid dropping or subjecting the speakers to strong impacts. Do not place heavy objects on top of the speakers.
- **Cables:** Periodically check all cables for any signs of wear or damage. Replace damaged cables immediately.

6. Troubleshooting

If you encounter any issues with your T'nB HPMX21WH speakers, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No sound from speakers.	• Speakers not powered on. • Volume too low. • Cables not connected properly. • Audio source not playing or muted.	• Ensure the power switch is ON and the power cable is securely plugged in. • Increase the volume on the speaker's control knob and on your audio device. • Check all audio and power cable connections. Re-plug them firmly. • Verify that your audio source (computer, phone) is playing audio and is not muted.
Distorted or unclear sound.	• Volume set too high (clipping). • Poor audio source quality. • Loose cable connection.	• Reduce the volume on both the speakers and your audio source. • Try playing audio from a different source or a higher quality file. • Check and re-secure all audio cable connections.
Only one satellite speaker produces sound.	• Loose connection for the silent speaker. • Faulty satellite speaker. • Audio source output issue.	• Check the connection of the silent satellite speaker to the subwoofer. • Swap the satellite speakers to determine if the issue is with the speaker or the subwoofer's output port. • Ensure your audio source is outputting stereo sound correctly.

7. Technical Specifications

Below are the technical specifications for the T'nB HPMX21WH speakers:

Brand: T'nB

Model: HPMX21WH

Speaker Type: Subwoofer (2.1 channel system)

Channel Configuration: 2.1

Color: White

Power Source: AC (Alternating Current)

Product Dimensions: Approximately 25.8 x 24.4 x 22.6 cm (10.16 x 9.61 x 8.9 inches)

Product Weight: Approximately 1.72 kg (3.79 lbs)

Form Factor: Built-in

8. Warranty and Support

T'nB products are designed and manufactured to the highest quality standards. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region and retailer.

For detailed warranty information, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official T'nB website. You may also contact your local retailer for assistance.

Official T'nB Website: www.tnb.com (Please note: This is a general placeholder link. Refer to your product's specific documentation for the exact support contact or website.)

© 2024 T'nB. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B007H373GW

More documents and user manuals: **https://manuals.plus/**