Beurer 649.03

Beurer MG 100 Infrared Tapping Massager Instruction Manual

Model: 649.03

1. Introduction

Thank you for choosing the Beurer MG 100 Infrared Tapping Massager. This device is designed to provide a relaxing and invigorating tapping massage with optional infrared heat, promoting well-being and muscle relaxation. Please read this instruction manual carefully before first use and keep it for future reference. Ensure that these instructions are accessible to all users.



Image of the Beurer MG 100 Infrared Tapping Massager, showing its ergonomic design, control panel, and dual massage heads.

2. Important Safety Instructions

To ensure safe operation and prevent injury or damage, observe the following safety warnings:

- **General Use:** Do not use the massager on injured, swollen, burned, or sensitive skin areas. Avoid using the device while lying down or near water.
- **Electrical Safety:** Always unplug the device from the power outlet when not in use, before cleaning, or in case of a malfunction. Do not operate the device with wet hands.
- **Children and Vulnerable Individuals:** This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
- **Medical Conditions:** Consult your doctor before using the massager if you have a pacemaker, implants, acute illnesses, circulatory disorders, diabetes, or are pregnant.
- **Overheating:** Do not cover the massager during operation. Allow it to cool down if it becomes excessively warm.
- **Maintenance:** Do not attempt to repair the device yourself. Contact authorized service personnel for repairs.

3. Product Components and Features

The Beurer MG 100 Infrared Tapping Massager includes the following key components and features:

- **Ergonomic Design:** Features a long handle and two non-slip grips for easy reach and comfortable application to various body parts.
- **Dual Massage Heads:** Equipped with two tapping massage heads for effective muscle stimulation.
- **Interchangeable Attachments:** Comes with two interchangeable massage attachments for varied massage experiences.
- **Infrared Heat Function:** Optional infrared heat can be activated to enhance relaxation and blood circulation.
- **Multiple Massage Programs:** Offers 4 distinct massage programs to suit different needs.
- **Adjustable Intensity:** Provides 5 massage speed levels for personalized intensity control.

4. Setup

1. **Unpack the Device:** Carefully remove the massager and all accessories from the packaging. Retain the packaging for future storage or transport.
2. **Inspect for Damage:** Before first use, check the device and its accessories for any signs of damage. Do not use a damaged device.
3. **Attach Massage Heads:** Select one of the two interchangeable massage attachments and securely fix it onto the massage heads. Ensure it is firmly in place.
4. **Connect to Power:** Plug the power cord into a suitable electrical outlet. The device operates via mains power.

5. Operating Instructions

Follow these steps for effective use of your Beurer MG 100 massager:

1. **Power On:** Press the 'ON/OFF' button to switch on the device.
2. **Select Program:** Use the program selection buttons to choose one of the 4 available massage programs. Experiment to find the one that best suits your preference.
3. **Adjust Intensity:** Use the speed control buttons to select one of the 5 intensity levels. Start with a lower intensity and gradually increase as desired.
4. **Activate Infrared Heat (Optional):** Press the infrared heat button to activate the warming function. The heat will become noticeable after a short period.
5. **Apply Massager:** Gently apply the massager to the desired body area. Use the ergonomic handle and non-slip grips to reach your back, neck, shoulders, legs, or other muscles. Move the massager slowly and evenly over the skin.
6. **Duration of Use:** A massage session should typically last 10-15 minutes per body area. Avoid prolonged use on a single spot.
7. **Power Off:** After use, press the 'ON/OFF' button to switch off the device and unplug it from the power outlet.

6. Maintenance and Cleaning

Proper care ensures the longevity and hygiene of your massager:

- **Cleaning the Device:** Always unplug the massager before cleaning. Wipe the device with a slightly damp cloth. Do not use abrasive cleaning agents or immerse the device in water.
- **Cleaning Attachments:** The massage attachments can be cleaned with mild soap and water. Ensure they are completely dry before reattaching or storing.
- **Storage:** When not in use, detach the massage heads and store the device in a cool, dry place, away from direct sunlight and out of reach of children.

7. Troubleshooting

If you encounter issues with your Beurer MG 100 massager, consider the following:

- **Device Not Turning On:**
  - Ensure the power cord is securely plugged into a functional electrical outlet.
  - Check if the power outlet itself is working by plugging in another appliance.
- **Weak Massage Intensity:**
  - Verify that the intensity level is set to your desired setting (1-5).
  - Ensure the massage attachments are correctly fitted.
- **Infrared Heat Not Working:**
  - Confirm that the infrared heat function is activated via its dedicated button.
  - Allow a few minutes for the heat to become noticeable.
- **Unusual Noises or Odors:**
  - Immediately switch off the device and unplug it.
  - Do not use the device if it emits unusual noises or odors. Contact customer support.

If these steps do not resolve the issue, please contact Beurer customer service for further assistance.

8. Specifications

Specification	Detail
Brand	Beurer
Model Number	649.03
Product Dimensions (L x W x H)	16L x 15W x 45H centimeters
Net Product Weight	1 Kilogram
Item Weight	1.79 Grams
Material	Plastic
Color	Silver, Grey
Power Source	Corded Electric
Special Feature	Heat Function
Massager Form	Wand Massager
Usage	Full Body Massage
Country of Origin	China

9. Warranty and Support

For information regarding warranty terms, conditions, and customer support, please refer to the official Beurer website or the warranty card included with your product. You may also contact your local Beurer distributor or retailer for assistance.
Manufacturer: Beurer GmbH

© 2023 Beurer GmbH. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question