NOMA N1506

NOMA 24 Hour Outdoor Timer

Model: N1506

Product Overview

The NOMA N1506 24 Hour Outdoor Timer is designed to provide automated control for outdoor electrical appliances and lighting. Its robust, weather-proof construction ensures reliable operation in various outdoor conditions. This grounded timer offers a simple solution for managing power to devices, enhancing security and promoting energy efficiency.



Image: The NOMA 24 Hour Outdoor Timer, Model N1506, shown in its retail packaging. The timer unit is black, grounded, and features a

durable, weather-proof design suitable for outdoor use.

- Controls outdoor lighting for greater security.
- Ideal for car heating accessories.
- Manages outdoor electrical appliances for convenient energy savings.
- Features a 24-hour cycle and is grounded for safety.
- Simple push-button programming for setting ON/OFF times.

Safety Information

Read all instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- **Outdoor Use Only:** This timer is designed for outdoor use. Ensure all connections are secure and protected from direct water exposure.
- **Grounded Connections:** Always connect the timer to a grounded outlet. Do not remove the grounding prong.
- **Load Capacity:** Do not exceed the maximum electrical rating of 15 Amps, 1875 Watts. Overloading may cause damage to the timer or connected devices.
- **Water Safety:** Do not immerse the timer in water. Ensure the outlet cover is closed when not in use.
- **Children and Pets:** Keep the timer and connected cords out of reach of children and pets.
- **Maintenance:** Do not attempt to open or repair the timer. Refer all servicing to qualified personnel.

Setup

Follow these steps for initial setup of your NOMA outdoor timer:

1. **Unpack:** Carefully remove the timer from its packaging.
2. **Placement:** Choose a suitable outdoor location that is protected from direct heavy rain and accessible for programming.
3. **Plug In:** Insert the timer's grounded plug into a grounded outdoor electrical outlet.
4. **Connect Device:** Plug the appliance or lighting fixture you wish to control into the timer's grounded receptacle. Ensure the device is turned ON if it has its own power switch.



Image: A close-up view of the NOMA outdoor timer's grounded three-prong outlet, designed for connecting outdoor electrical devices securely.

Operating Instructions

The NOMA N1506 timer features simple push-button programming for setting ON/OFF times.



Image: Top view of the NOMA outdoor timer, displaying its control buttons and the digital time display, used for programming the ON/OFF cycles.

1. **Set Current Time:**
    - Press the "CLOCK" button.
    - Use the "HOUR" and "MINUTE" buttons to adjust the current time.
    - Press "CLOCK" again to confirm.
2. **Program ON/OFF Times:**
    - Press the "PROG" button to enter programming mode. The display will show "1 ON".
    - Use "HOUR" and "MINUTE" buttons to set the desired ON time for the first program.
    - Press "PROG" again. The display will show "1 OFF".
    - Use "HOUR" and "MINUTE" buttons to set the desired OFF time for the first program.
    - Repeat for additional ON/OFF programs if available (this model typically supports one ON/OFF cycle per 24 hours).
    - Press the "CLOCK" button to exit programming mode and return to current time display.
3. **Activate Timer:**
    - Press the "ON/AUTO/OFF" button to cycle through modes.
    - Select "AUTO" for the timer to operate according to your programmed settings.
    - "ON" will keep the connected device continuously on.
    - "OFF" will keep the connected device continuously off.

Maintenance

Proper maintenance ensures the longevity and safe operation of your NOMA outdoor timer.

- **Cleaning:** Disconnect the timer from the power source before cleaning. Wipe the exterior with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** If storing the timer for an extended period, disconnect it from the power source and store it in a dry, cool place away from direct sunlight.
- **Inspection:** Periodically inspect the power cord and plug for any signs of damage, fraying, or corrosion. Do not use the timer if any damage is observed.
- **Weather Protection:** While weather-proof, it is recommended to position the timer in a location that minimizes direct exposure to extreme weather conditions like heavy rain or snow.

Troubleshooting

If you encounter issues with your NOMA outdoor timer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Timer not turning ON/OFF at programmed times.	Timer is not in "AUTO" mode. Incorrect time set. Incorrect program times set.	Ensure the timer is set to "AUTO" mode. Verify the current time is set correctly. Re-program the ON/OFF times carefully.
Connected device not receiving power.	Timer not plugged in. Device not plugged into timer. Device's own switch is OFF. Overload.	Ensure the timer is securely plugged into a live outlet. Ensure the device is securely plugged into the timer. Turn the device's power switch to ON. Check if the total wattage exceeds 1875W; reduce load if necessary.
Display is blank or flickering.	No power to the timer. Internal battery low (if applicable).	Check the power outlet. If the issue persists, contact customer support.

Specifications

Feature	Detail
Brand	NOMA
Model	N1506
Type	24 Hour Outdoor Timer
Color	Black
Electrical Rating	15 Amps / 1875 Watts
Grounded	Yes
Number of Settings	1 ON/OFF cycle per 24 hours

Feature	Detail
Item Weight	~227 g (0.5 Pounds)
Parcel Dimensions	~22.86 x 15.24 x 5.08 cm
UPC	062964491195

Warranty and Support

For warranty information or technical support, please refer to the documentation included with your purchase or contact NOMA customer service directly. Keep your proof of purchase for warranty claims.

NOMA Customer Service:

- Visit the official NOMA website for contact details.
- Refer to the product packaging for specific support phone numbers or email addresses.

© 2024 NOMA. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question