Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced 20VL64G

RemotesReplaced Remote Control User Manual for Toshiba 20VL64G

Model: 20VL64G

1. Introduction

Thank you for choosing the RemotesReplaced remote control. This remote is designed as a direct replacement for your original Toshiba 20VL64G television remote, offering full functionality without the need for complex programming. This manual provides essential information for setting up, operating, maintaining, and troubleshooting your new remote control.

2. Setup

2.1. Battery Installation

The remote control requires two AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment cover on the back of the remote control.
2. Press down and slide the cover off.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

2.2. Initial Use

This RemotesReplaced remote control is pre-programmed for the Toshiba 20VL64G television. No setup codes or programming are required. Once batteries are installed, the remote is ready for immediate use.





Figure 1: Front view of the remote control. This image displays the full button layout, including power, mute, channel, volume, navigation, and media control

buttons.

3. Operating Instructions

Point the remote control directly at your Toshiba 20VL64G television's infrared receiver. Ensure there are no obstructions between the remote and the TV.

3.1. Key Functions

- **POWER**: Turns the television on or off.
- **MUTE**: Mutes or unmutes the television audio.
- **TV** / **SAT** / **DVD** / **AUX** : Selects input sources.
- **MENU**: Accesses the main menu of the television.
- **EXIT**: Exits the current menu or on-screen display.
- **SHIFT**: (Functionality may vary depending on TV model, typically for secondary button functions).
- **0-9 (Number Buttons)**: Directly selects channels or enters numerical values.
- **SOURCE**: Cycles through available input sources.
- **-/--**: Toggles between single and double-digit channel entry.
- **GUIDE**: Displays the electronic program guide (EPG).
- **SUB**: Activates or deactivates subtitles.
- **SIZE**: Adjusts screen size or aspect ratio.
- **SETUP**: Accesses setup or settings menu.
- **TEXT**: Activates or deactivates Teletext.
- **Volume Up/Down (V+/V-)** : Adjusts the volume level.
- **Channel Up/Down (P+/P-)**: Changes the television channel.
- **Navigation Buttons (Up, Down, Left, Right, OK)** : Navigates through menus and confirms selections.
- **BACK**: Returns to the previous menu or screen.
- **SLEEP**: Sets the sleep timer.
- **TV/DTV**: Switches between analog and digital television modes.
- **INFO**: Displays information about the current program or input.
- **EPG**: Electronic Program Guide.
- **FAV**: Accesses favorite channels list.
- **NET TV** / **SMART**: Accesses smart TV features or internet-connected services (if supported by your TV model).
- **Colored Buttons (Red, Green, Yellow, Blue)**: Specific functions within menus or applications, as indicated on-screen.
- **Media Control Buttons (Rewind, Play/Pause, Fast Forward, Stop)** : Controls media playback.



Figure 2: Side view of the remote control. This image highlights the ergonomic design and the infrared emitter at the top.

4. Maintenance

4.1. Battery Replacement

Replace batteries when the remote control's response becomes sluggish or stops working. Always replace both batteries at the same time with new AAA batteries. Do not mix old and new batteries, or different types of batteries.

4.2. Cleaning

To clean the remote control, wipe it with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these can damage the remote's surface or internal components.

4.3. Storage

Store the remote control in a cool, dry place away from direct sunlight and extreme temperatures. If the remote will not be used for an extended period, remove the batteries to prevent leakage.

5. Troubleshooting

Problem	Possible Cause	Solution
Remote control is not working.	• Dead or incorrectly inserted batteries. • Obstruction between remote and TV. • Remote control is out of range.	• Replace batteries with new AAA batteries, ensuring correct polarity. • Remove any objects blocking the line of sight to the TV's infrared receiver. • Move closer to the television (within 10 meters).
Some buttons are not responding.	• Low battery power. • Button stuck or dirty.	• Replace batteries. • Gently clean around the unresponsive button.
Remote control range is reduced.	• Low battery power. • Interference from strong light sources (e.g., direct sunlight, fluorescent lights).	• Replace batteries. • Minimize interference by adjusting lighting or position.

6. Specifications

- **Brand**: RemotesReplaced
- **Model Number**: 20VL64G
- **Compatible Devices**: Toshiba 20VL64G Television
- **Connectivity Technology**: Infrared
- **Power Source**: 2 x AAA Batteries (not included)
- **Maximum Range**: 10 Meters (approx. 33 feet)
- **Item Weight**: 120 Grams (approx. 4.2 ounces)
- **Manufacturer**: Linkwebb

7. Warranty and Support

7.1. Warranty Information

This RemotesReplaced remote control comes with a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the remote functions as described. Please retain your proof of purchase for warranty claims.

7.2. Customer Support

If you encounter any issues not covered in the troubleshooting section or require further assistance, please contact the seller or RemotesReplaced customer support through the platform where you purchased the product. Provide your model number (20VL64G) and a detailed description of the issue for efficient support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question