Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RemotesReplaced LT-32EU80U/B

RemotesReplaced Compatible Remote Control User Manual

For JVC LT-32EU80U/B Television

Introduction

This manual provides comprehensive instructions for the RemotesReplaced compatible remote control, designed specifically for JVC LT-32EU80U/B televisions. This remote offers full functionality, serving as a direct replacement for your original remote control. It is engineered to provide a reliable and cost-effective solution without the need for complex programming.

Features

- Direct replacement for the original remote control.
- No setup codes required; simply insert batteries to begin use.
- Capable of accessing all functions of your JVC LT-32EU80U/B TV.
- Specifically manufactured for this brand and model, not a generic universal remote.

Setup: Battery Installation

Your RemotesReplaced remote control requires 2 AAA batteries (not included). Follow these steps to install them:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery compartment cover downwards or outwards to open it.
3. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery compartment cover back into place until it clicks securely.

The remote control is now ready for use with your JVC LT-32EU80U/B TV. No additional programming or code entry is required.



Image: Side view of the remote control, highlighting the infrared (IR) emitter at the top. This component sends signals to your television.

Operating Instructions

This section outlines the basic functions of your remote control. Point the remote directly at your JVC LT-32EU80U/B television for optimal performance.





Image: Front view of the RemotesReplaced remote control, displaying all buttons and their labels. This image serves as a visual guide for button identification.

Basic Functions

- **POWER:** Turns the TV on or off.
- **MUTE:** Mutes or restores the TV sound.
- **TV/DTV:** Switches between TV and Digital TV modes.
- **Volume (+/-):** Increases or decreases the volume.
- **Channel (P+/P-):** Changes the TV channel up or down.
- **Number Buttons (0-9):** Directly select channels.
- **SOURCE:** Selects input sources (e.g., HDMI, AV).
- **MENU:** Opens the TV's main menu.
- **EXIT:** Closes the current menu or on-screen display.
- **Navigation (Up/Down/Left/Right) & OK:** Navigates through menus and confirms selections.

Advanced Functions

- **INFO:** Displays information about the current program or input.
- **EPG (Electronic Program Guide):** Accesses the program guide.
- **FAV:** Accesses favorite channels list.
- **TEXT:** Activates or deactivates Teletext.
- **SUB:** Toggles subtitles on or off.

- **SLEEP:** Sets the sleep timer.
- **SMART:** Accesses smart TV features (if supported by your TV).
- **NET TV:** Direct access to network TV features.
- **Color Buttons (Red, Green, Yellow, Blue):** Used for specific functions within menus or interactive services.
- **Playback Controls (Play, Pause, Fast Forward, Rewind):** For media playback functions.

Maintenance

To ensure the longevity and proper functioning of your remote control, follow these maintenance guidelines:

- **Cleaning:** Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners or abrasive materials, as they may damage the surface or internal components.
- **Battery Replacement:** Replace batteries when the remote's response becomes sluggish or stops working. Always replace both batteries at the same time with new ones of the same type (AAA).
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops:** Protect the remote from physical impact, as drops can damage internal circuitry.

Troubleshooting

If you experience issues with your remote control, try the following troubleshooting steps:

- **Remote Not Working:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA batteries.
  - Check if there are any obstructions between the remote and the TV's infrared sensor.
  - Ensure you are within the effective range and pointing the remote directly at the TV.
- **Buttons Not Responding:**
  - Clean the remote's surface, especially around the buttons, to remove any dirt or debris that might be preventing proper contact.
  - If only specific buttons are not working, it might indicate a fault with the remote itself.
- **Interference:**
  - Bright lights, especially fluorescent or LED lighting, can sometimes interfere with infrared signals. Try operating the remote in different lighting conditions.

If the problem persists after trying these steps, contact customer support for further assistance.

Specifications

Brand	RemotesReplaced
Compatible Devices	JVC LT-32EU80U/B Television
Connectivity Technology	Infrared

Model Number	LT-32EU80U/B
Batteries Required	2 x AAA (not included)
Item Weight	120 Grams

Warranty and Support

This RemotesReplaced compatible remote control comes with a**1-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please refer to the contact information provided by your retailer or visit the RemotesReplaced official website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question