De'Longhi ECAM22.360.S

De'Longhi ECAM22.360.S Fully Automatic Bean to Cup Coffee Machine

Instruction Manual

Model: ECAM22.360.S | Brand: De'Longhi

1. Introduction

Welcome to the world of authentic Italian coffee with your new De'Longhi ECAM22.360.S Fully Automatic Bean to Cup Coffee Machine. This appliance is designed to deliver a perfect coffee experience, from bean grinding to milk frothing, all at the touch of a button. Its advanced features include an integrated grinder, automatic cappuccino system, and intuitive controls for personalized beverages. Please read this manual carefully to ensure proper use, maintenance, and longevity of your machine.



Figure 1: The De'Longhi ECAM22.360.S Fully Automatic Bean to Cup Coffee Machine, showcasing its sleek silver design and integrated milk carafe, with a freshly prepared cappuccino in a glass.

2. Setup and First Use

Before operating your coffee machine, follow these steps to ensure it is set up correctly.

2.1 Unpacking

- Remove all packaging materials from the machine and its accessories.
- Place the machine on a stable, flat surface, away from water sources and heat.
- Ensure proper ventilation around the machine.

2.2 Initial Cleaning

- Wash the water tank, milk carafe, and drip tray with warm water and mild detergent. Rinse thoroughly.
- Wipe the exterior of the machine with a soft, damp cloth.

2.3 Filling the Water Tank

1. Remove the water tank from the back of the machine.
2. Fill it with fresh, cold tap water up to the MAX level indicator.
3. Replace the water tank securely.

2.4 Filling the Bean Hopper

- Open the bean hopper lid on top of the machine.
- Pour fresh coffee beans into the hopper. Do not fill above the MAX level.
- Close the lid firmly to preserve bean freshness.

2.5 Power Connection and Priming

1. Plug the power cord into a suitable electrical outlet (220-240V).
2. Press the **ON/OFF** button to turn on the machine.
3. The machine will perform an automatic self-diagnosis and rinsing cycle. Place a container under the coffee spouts.
4. Follow any on-screen prompts to prime the circuit if necessary. This ensures water flows through the internal system.

3. Operating Instructions

This section details how to prepare various coffee beverages and adjust settings.

3.1 Control Panel Overview


ESC
MENU
OK
CLEAN

Figure 2: The intuitive control panel of the ECAM22.360.S, featuring a two-line text display and dedicated buttons for various coffee preparations and settings.

- **Display:** Shows machine status, prompts, and menu options.
- **ON/OFF Button:** Powers the machine on or off.
- **MENU Button:** Accesses the settings menu.
- **ESC Button:** Exits current menu or cancels an operation.
- **Arrow Buttons (< / >):** Navigate through menu options.
- **OK Button:** Confirms selection.
- **Coffee Buttons:** Dedicated buttons for Espresso, Coffee, and Cappuccino.
- **Steam Button:** Activates steam function for manual frothing (if milk carafe is not used).

3.2 Preparing Espresso and Coffee

1. Place one or two cups under the coffee spouts.
2. Press the **Espresso** button for a single espresso or the **Coffee** button for a longer coffee.
3. For two cups, press the desired coffee button twice in quick succession.
4. The machine will grind the beans, brew, and dispense the coffee.

3.3 Using the Automatic Cappuccino System



Figure 3: The ECAM22.360.S with the detachable milk carafe securely attached to the machine's side, ready for automatic milk frothing.


READY
Standard taste
ESC
MENU
OK
CAPPUCCINO
De'Longhi

Figure 4: A close-up view of the milk carafe's integrated dial, showing the 'Clean' position for easy maintenance after use.

1. Fill the milk carafe with fresh, cold milk (dairy or non-dairy).
2. Attach the milk carafe to the machine's steam nozzle.
3. Place a cup under the coffee spouts and the milk spout.
4. Press the **Cappuccino** button. The machine will automatically froth the milk and then dispense the coffee.
5. After use, turn the milk carafe dial to the **CLEAN** position and press the **Cappuccino** button again to perform a quick rinse cycle.

3.4 Adjusting Grind Settings

- The integrated grinder has 13 adjustable settings.
- To adjust, turn the grind adjustment dial located inside the bean hopper.
- **Important:** Only adjust the grind setting when the grinder is operating. Turn the dial one click at a time.
- Finer grind (lower number) for stronger coffee, coarser grind (higher number) for lighter coffee.

3.5 Using Pre-Ground Coffee

- Open the pre-ground coffee funnel lid on top of the machine.
- Add one level scoop of pre-ground coffee (for one cup only). Do not add more than one scoop.
- Place a cup under the coffee spouts.
- Press the pre-ground coffee button (usually indicated by a spoon icon).

4. Maintenance and Cleaning

Regular cleaning and maintenance are crucial for optimal performance and longevity of your machine.

4.1 Daily Cleaning

- **Drip Tray and Grounds Container:** Empty and rinse daily. The machine will prompt you when the grounds container is full.
- **Coffee Spouts:** Wipe clean with a damp cloth.
- **Milk Carafe:** After each use, perform the automatic CLEAN cycle. For thorough cleaning, disassemble the carafe components and wash with warm water and mild detergent.

4.2 Brewing Unit Cleaning

- The brewing unit is removable for easy cleaning.
- Turn off and unplug the machine.
- Open the service door (usually on the right side).
- Press the two red release buttons and pull the brewing unit out.
- Rinse the brewing unit under running tap water. Do not use detergents.
- Allow it to air dry completely before reinserting. Clean monthly or as needed.

4.3 Descaling

- The machine will indicate when descaling is required.
- Use only De'Longhi descaler solution.
- Follow the on-screen instructions precisely for the descaling cycle. This process typically takes about 30 minutes.
- Regular descaling prevents limescale buildup and ensures optimal machine performance.

4.4 Water Filter Replacement

- If using a water filter, replace it approximately every 2 months or as indicated by the machine.

- Refer to the filter packaging for specific installation and replacement instructions.

5. Troubleshooting

If you encounter issues with your machine, consult this section before contacting support.

Problem	Possible Cause	Solution
No coffee dispensed.	Water tank empty; coffee beans empty; brewing unit blocked.	Fill water tank; fill bean hopper; clean brewing unit.
Coffee is too weak/watery.	Grind setting too coarse; insufficient coffee dose; old beans.	Adjust grind to finer setting; check coffee strength setting; use fresh beans.
Milk not frothing properly.	Milk carafe dirty/clogged; milk not cold enough; wrong milk type.	Clean milk carafe thoroughly; use fresh, cold milk; try different milk.
Machine displays 'Descale'.	Limescale buildup.	Perform descaling cycle as per instructions.
Machine is noisy.	Normal operation; grinder noise; air in circuit.	This is often normal; prime the circuit if display prompts.

For other error messages or persistent issues, please refer to the full user manual or contact customer support.

6. Specifications

Feature	Detail
Brand	De'Longhi
Model Number	ECAM.22.360.B (also known as ECAM22.360.S)
Color	Silver
Product Dimensions (W x D x H)	23.8 x 43 x 35.1 cm
Item Weight	10.7 kg
Water Tank Capacity	1.8 Liters
Bean Hopper Capacity	250g
Power / Wattage	1450 watts
Voltage	220-240 Volts
Pump Pressure	15 bar
Material	Plastic
Special Features	Cup Warmer, Integrated Coffee Grinder, Milk Frother, Programmable, Removable Tank, Thermoblock, Thermostat, Water Filter, Automatic Shut-off

7. Warranty and Support

De'Longhi products are manufactured to the highest quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official De'Longhi website for your region.

7.1 Customer Support

If you require technical assistance, spare parts, or have any questions not covered in this manual, please contact De'Longhi customer service. Contact details can typically be found on the official De'Longhi website or on your product's packaging.
You can also visit the official De'Longhi store for more information and products: De'Longhi Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question