Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OMEGA 5 ft Cable w/ XLR Connectors (ASIN: B00886ZGYI)

AES/EBU Digital Cable User Manual

Model: 5 ft Cable w/ XLR Connectors

Setup Operating Maintenance Troubleshooting Specifications Warranty & Support

Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your OMEGA AES/EBU Digital Cable. This 5-foot cable with XLR connectors is designed for professional audio applications, ensuring high-fidelity digital audio signal transmission.



Figure 1: OMEGA AES/EBU Digital Cable. This image shows the 5-foot digital audio cable with its distinctive XLR male and female connectors at each end, ready for professional audio system integration.

Setup

The OMEGA AES/EBU Digital Cable is designed for straightforward connection between compatible audio equipment. Follow these steps for proper setup:

1. **Identify Connectors:** The cable features standard 3-pin XLR male and female connectors. Ensure your audio devices have corresponding XLR input and output ports for AES/EBU digital audio.
2. **Power Off Equipment:** Before making any connections, ensure all audio equipment (e.g., digital audio converters, mixers, interfaces) is powered off to prevent potential damage or signal interference.
3. **Connect Source to Destination:**
    - Connect the *XLR male end* of the cable to the digital audio output (AES/EBU OUT) of your source device.
    - Connect the *XLR female end* of the cable to the digital audio input (AES/EBU IN) of your destination device.
4. **Secure Connections:** Ensure both XLR connectors are fully inserted and locked into place. A click sound typically indicates a secure connection.

5. **Power On Equipment:** Once all connections are secure, power on your audio equipment in the recommended order (e.g., source first, then destination).

Note: This cable is specifically designed for AES/EBU digital audio signals. While it uses XLR connectors, it is not intended for analog microphone or line-level signals, which require different cable specifications.

Operating

Once the OMEGA AES/EBU Digital Cable is properly connected, its operation is passive, as it functions solely as a signal conduit. The primary operational considerations involve the settings of the connected audio devices.

- **Signal Flow:** The cable facilitates the transfer of digital audio data from the source device to the destination device. Ensure the source device is configured to output AES/EBU digital audio and the destination device is set to receive AES/EBU digital audio.
- **Clock Synchronization:** In digital audio systems, proper clock synchronization is crucial. Ensure that your digital audio devices are correctly synchronized. This often involves setting one device as the master clock and others as slaves, or using an external word clock. Refer to the manuals of your audio equipment for detailed clocking instructions.
- **Troubleshooting Signal Issues:** If no audio signal is detected, verify the following:
    - All connections are secure.
    - Both source and destination devices are powered on.
    - The correct input/output types (AES/EBU) are selected on your devices.
    - Clock synchronization is established.

Maintenance

The OMEGA AES/EBU Digital Cable requires minimal maintenance to ensure its longevity and optimal performance.

- **Cleaning:** Keep the cable and its connectors clean. Use a soft, dry, lint-free cloth to wipe down the cable jacket. For connectors, a cotton swab lightly dampened with isopropyl alcohol can be used, ensuring the connectors are completely dry before re-connecting.
- **Storage:** When not in use, coil the cable loosely to prevent kinks and damage to the internal conductors. Avoid tight coiling or sharp bends. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Always grasp the connector housing when plugging or unplugging the cable. Avoid pulling on the cable itself, as this can strain the internal wiring and lead to damage.
- **Inspection:** Periodically inspect the cable for any signs of wear, such as frayed jackets, bent pins on the XLR connectors, or loose connections. If significant damage is observed, replace the cable to ensure signal integrity and safety.

Troubleshooting

If you encounter issues with your OMEGA AES/EBU Digital Cable, consider the following common troubleshooting steps:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No Audio Signal	• Loose connection • Incorrect input/output selected • Clock synchronization issue • Damaged cable	• Ensure XLR connectors are fully seated. • Verify AES/EBU input/output is selected on both devices. • Check and correct clock synchronization settings on all connected devices. • Test with another known-good AES/EBU cable.
Intermittent Audio	• Loose connection • Cable damage (internal break) • Interference	• Reseat connections firmly. • Inspect cable for visible damage; replace if necessary. • Ensure cable is not running parallel to power cables or other sources of electromagnetic interference.
Digital Noise/Clicks	• Clock synchronization issues • Improper impedance matching (less common with dedicated AES/EBU)	• Verify and correct clock synchronization settings. • Ensure all devices are operating at the same sample rate.

If these steps do not resolve the issue, contact OMEGA customer support or consult a qualified audio technician.

Specifications

The following are the technical specifications for the OMEGA AES/EBU Digital Cable:

- **Product Name:** AES/EBU Digital Cable
- **Brand:** OMEGA
- **Model Identifier:** 5 ft Cable w/ XLR Connectors (ASIN: B00886ZGYI)
- **Cable Length:** 5 feet (approximately 1.5 meters)
- **Connector Type:** XLR (3-pin)
- **Connector Gender:** Male-to-Male (one male end, one female end, standard for AES/EBU connections)
- **Cable Type:** Digital Audio Cable (AES/EBU standard)
- **Impedance:** 110 Ohm (standard for AES/EBU)
- **Shape:** Round
- **Special Feature:** Designed for AES/EBU digital audio signal transmission
- **Manufacturer:** OMEGA
- **Date First Available:** March 24, 2011

Warranty & Support

OMEGA stands behind the quality of its products. While specific warranty terms may vary, OMEGA cables typically come with a limited warranty covering defects in materials and workmanship under normal use.

- **Warranty Coverage:** This warranty generally covers manufacturing defects. It does not cover damage caused by misuse, abuse, unauthorized modification, or normal wear and tear.
- **Claim Process:** To inquire about warranty service or for technical support, please contact OMEGA customer service directly. You may be required to provide proof of purchase and a detailed description of the issue.
- **Contact Information:** For the most current support information, please refer to the official OMEGA website or the contact details provided with your product packaging.

Disclaimer: Warranty terms are subject to change. Always refer to the official warranty statement provided by the manufacturer at the time of purchase.

© 2023 OMEGA. All rights reserved.
This manual is for informational purposes only. OMEGA reserves the right to make changes to product specifications without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00886ZGYI

More documents and user manuals: **https://manuals.plus/**