De'Longhi DLSC500

De'Longhi EcoDecalk Descaler Instruction Manual

Universal Descaling Solution for Coffee & Espresso Machines

1. Product Overview

The **De'Longhi EcoDecalk Descaler** is an eco-friendly, universal descaling solution designed to maintain the optimal performance and longevity of your coffee and espresso machines. Water naturally contains minerals that can build up as limescale inside your machine, leading to premature breakdown and affecting the taste and temperature of your beverages.

This fast-acting, ecological descaling agent is scientifically formulated with plant-based lactic acid to effectively and safely remove limescale and mineral deposits, ensuring your machine operates smoothly and your coffee tastes consistently great.



Image: De'Longhi EcoDecalk Descaler bottle and its retail packaging.

2. Key Features

- **World-Leading Brand:** From De'Longhi, a recognized leader in espresso machines.
- **Enhanced Machine Performance:** Regular use helps prevent premature breakdown from scale buildup, maintaining consistent brew temperature and flavor.
- **Powerful & Safe Formula:** A fast-acting descaling agent with plant-based lactic acid, formulated to effectively and safely remove limescale and mineral deposits.
- **Eco-Friendly Ingredients:** Made using biodegradable and plant-based ingredients, thoroughly tested to be safe for cleaning food-grade internal components of coffee makers.
- **Universal Compatibility:** Suitable for use with De'Longhi machines and other leading brands such as Breville, Ninja, and Philips.
- **Economical Supply:** One 16.90 oz (500 ml) bottle provides approximately 5 uses, offering up to a 15-month supply for an average household (based on descaling every 3 months).
- **Easy-to-Use:** Simple application process, requiring only 100ml (1 dose) per descaling cycle, followed by your

machine's specific instructions.



Image: Visual representation of the descaler's benefits, including limescale removal, extended machine life, improved coffee taste, and restored brew time/temperature.

3. Usage Instructions (Operating)

Always refer to your specific coffee or espresso machine's instruction manual for detailed descaling procedures, as steps may vary between models. The De'Longhi EcoDecalk Descaler is designed to integrate seamlessly with most machine's descaling cycles.

General Descaling Steps:

1. **Prepare the Machine:** Ensure your coffee machine is turned off and cooled down. Empty the water tank and drip tray.
2. **Add Descaler:** Pour **100 ml (1 dose)** of De'Longhi EcoDecalk Descaler into the water tank. The bottle features clear measurement markings for easy dosing.
3. **Fill with Water:** Add **1 liter of fresh water** to the water tank, mixing it with the descaling solution.
4. **Initiate Descaling Cycle:** Follow your machine's specific instructions to start the descaling program. This usually involves pressing a dedicated descale button or navigating through a menu.
5. **Rinse Cycle:** After the descaling cycle is complete, thoroughly rinse the water tank and fill it with fresh water. Run one or more rinse cycles as instructed by your machine's manual to ensure all descaling solution residue is removed.
6. **Final Steps:** Empty and clean the drip tray. Your machine is now ready for use.



Image: A person pouring the descaling solution into the water reservoir of a coffee machine.



Image: The water tank being reinserted into the coffee machine after adding the descaling solution.



Image: A close-up of a coffee machine's display indicating the descaling process.

Official Product Videos:

Your browser does not support the video tag.

Video: "Ecodecalk Descaler Video" by De'Longhi. This video demonstrates the descaling process for De'Longhi coffee machines, including preparing the solution and running the descaling cycle.

Your browser does not support the video tag.

Video: "Descaler Solution for Espresso Machines" by De'Longhi. This video provides a concise overview of how to use the descaling solution for espresso machines.

4. Maintenance

The frequency of descaling depends on your water hardness and how often you use your machine. For an average household, it is suggested to descale approximately **every 3 months**. Your coffee machine will typically indicate when descaling is required, often through a warning light or message on its display.



Image: The descaler bottle highlighting its 15-month supply and 5 uses, indicating its long-term value.

5. Troubleshooting

If you encounter issues during or after the descaling process, consider the following:

- **Descaling Light Remains On:** Ensure you have completed all steps of the descaling and rinsing cycles as per your machine's manual. Some machines require specific button presses to reset the indicator.
- **Poor Coffee Flow/Taste After Descaling:** This could indicate residual scale or incomplete rinsing. Perform an additional rinse cycle with fresh water. If the issue persists, consult your machine's manual for advanced cleaning or troubleshooting steps.
- **Solution Not Draining:** Check for blockages in the machine's water pathways or ensure the water tank is correctly seated. Refer to your machine's manual for specific instructions on clearing blockages.
- **Unusual Odor/Taste:** Ensure thorough rinsing. If a slight odor or taste persists, run several cycles with fresh water. The EcoDecalk solution is plant-based and should not leave harmful residues.

For machine-specific issues not resolved by these general tips, always consult your coffee machine's original instruction

manual or the manufacturer's support resources.



Image: A visual comparison of a heating element before and after descaling, demonstrating the effectiveness of the solution in removing limescale.

6. Specifications

Attribute	Detail
Brand	De'Longhi
Model Number	DLSC500
Item Form	Liquid
Item Volume	500 Milliliters (16.9 Fl Oz)
Approximate Uses	5 doses per bottle
Product Dimensions	3.11 x 3.11 x 7.48 inches
Item Weight	1.1 Pounds
Main Ingredient	Lactic Acid (Plant-based)

Country of Origin	Italy

7. Safety Information

DANGER: CAUSES SEVERE SKIN BURNS AND EYE DAMAGE. CORROSIVE TO THE RESPIRATORY TRACT.
Read carefully other cautions on the entire label before use.

- Keep out of reach of children.
- Do not breathe vapors or mist.
- Wear protective gloves/protective clothing/eye protection/face protection.
- Wash thoroughly after handling.
- IF SWALLOWED: Rinse mouth. DO NOT induce vomiting.
- IF ON SKIN (or hair): Take off immediately all contaminated clothing. Rinse skin with water/shower.
- IF INHALED: Remove person to fresh air and keep comfortable for breathing.
- IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- Immediately call a POISON CENTER or doctor/physician.

8. Warranty and Support

Specific warranty information for the De'Longhi EcoDecalk Descaler is not provided in the available product data. For detailed warranty terms, product support, or further assistance, please refer to the product packaging or visit the official De'Longhi website.
You can visit the De'Longhi Store on Amazon for more products and information:De'Longhi Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question