Kodak 760H

Kodak 760H Carousel Slide Projector Instruction Manual

Model: 760H

Introduction

This manual provides detailed instructions for the safe and efficient operation of your Kodak 760H Carousel Slide Projector. Please read this manual thoroughly before using the projector to ensure proper setup, operation, and maintenance. The Kodak 760H is designed for projecting 35mm slides mounted in standard 2x2 inch frames, utilizing a carousel tray system for convenient slide management.

The Kodak 760H Carousel Slide Projector features whisper-quiet operation, remote control for forward and reverse slide advancement, automatic focus, and a reliable gravity feed system. It is equipped with an Ektanar C Zoom Lens f3.5 and supports a 140-slide cassette tray.



Image: The Kodak Carousel 760H Slide Projector, a black unit with a grey carousel slide tray mounted on top. The lens is visible on the front.

Safety Information

Always observe the following safety precautions to prevent injury or damage to the projector:

- Do not operate the projector with wet hands.
- Ensure the projector is placed on a stable, level surface.
- Do not block ventilation openings. Overheating can damage the unit.
- Unplug the projector from the power outlet before cleaning or performing any maintenance.
- Use only the specified lamp type for replacement.
- Keep the projector away from water or excessive moisture.

Setup

1. Unpacking and Placement

Carefully remove all components from the packaging. Place the projector on a firm, level surface, ensuring adequate ventilation around the unit. Avoid placing it near heat sources or in direct sunlight.

2. Installing the Lens

Your Kodak 760H projector comes with an Ektanar C Zoom Lens f3.5. To install, align the lens with the opening on the

front of the projector and gently push it into place until it clicks securely. Ensure it is firmly seated.



Image: Close-up view of the Kodak Ektanar C Projection Lens installed on the projector. The lens is black with blue lettering indicating "KODAK EKTANAR C 102mm f/2.8 Projection Lens".

3. Loading the Slide Tray

The projector uses a 140-slide cassette tray. Ensure slides are oriented correctly before loading. The emulsion side (dull side) of the slide should face the screen, and the image should appear upside down when viewed from the top of the tray. Place the loaded tray onto the projector's carousel spindle, aligning the key on the tray with the slot on the spindle. Gently press down until the tray is seated.



Image: Kodak Carousel 760H Slide Projector with a 140-slide carousel tray loaded on top. The tray is grey and numbered, indicating slide positions. The projector body is black.

4. Connecting Power and Remote

Plug the power cord into a suitable electrical outlet. Connect the remote control cable to the designated port on the projector. The remote allows for convenient slide advancement and reverse functions.



Image: The official "How to use KODAK CAROUSEL 760H Projector" instruction manual next to the wired remote control unit. The remote is black with two grey buttons for slide control.

Operating Instructions

1. Powering On and Initial Focus

Turn on the projector using the power switch, usually located on the side or rear of the unit. The lamp will illuminate. Use the focus control, typically a knob near the lens, to achieve a sharp image on your screen. The projector features automatic focus, which can be fine-tuned manually if needed.

2. Advancing Slides

To advance to the next slide, press the "Forward" button on the remote control. The projector's reliable gravity feed system will drop the next slide into position. To go back to a previous slide, press the "Reverse" button on the remote.

3. Adjusting Image Size

The Ektanar C Zoom Lens allows you to adjust the image size without moving the projector. Rotate the zoom ring on the lens to enlarge or reduce the projected image to fit your screen.

Maintenance

1. Cleaning the Lens

Periodically clean the lens with a soft, lint-free cloth specifically designed for optical surfaces. Use a lens cleaning solution if necessary. Avoid abrasive materials that could scratch the lens.

2. Cleaning the Projector Body

Wipe the exterior of the projector with a soft, dry cloth. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the ventilation openings. Always unplug the projector before cleaning.

3. Lamp Replacement

When the projection lamp burns out, replace it with a new lamp of the same type and wattage. Refer to the specifications section for the correct lamp type. To replace, ensure the projector is unplugged and cool. Open the lamp access cover (location varies by model, typically on the bottom or side), carefully remove the old lamp, and insert the new one. Close the cover securely.

Troubleshooting

This section addresses common issues you might encounter with your Kodak 760H projector.

- **No Power:**
  - Check if the power cord is securely plugged into both the projector and the electrical outlet.
  - Verify that the power outlet is functional.
  - Ensure the power switch on the projector is in the "On" position.
- **No Light from Lamp:**
  - The projection lamp may be burned out. Refer to the "Lamp Replacement" section under Maintenance.
  - Check if the lamp is properly seated in its socket.
- **Blurry Image:**
  - Adjust the focus control knob on the projector.
  - Ensure the lens is clean and free of dust or smudges.
  - Verify that the lens is correctly installed and seated.
- **Slides Not Advancing:**
  - Check if the slide tray is correctly seated on the carousel spindle.
  - Ensure the remote control cable is securely connected.
  - Inspect slides for any damage or warping that might cause them to jam.

Specifications

Feature	Detail
Model Name	760H
Brand	Kodak
Special Feature	Portable
Display Resolution	1920 x 1080
Display Type	Film
Brightness	1500 lumen
Wattage	3 watts

Controller Type	Remote Control
Control Method	Remote
Item Weight	7.4 Pounds
Color	Black
Mounting Type	Tabletop Mount

Warranty and Support

For specific warranty information regarding your Kodak 760H Carousel Slide Projector, please refer to the documentation provided at the time of purchase. Warranty terms and conditions may vary depending on the retailer and region.

If you require technical assistance or have questions not covered in this manual, please contact Kodak customer support or the retailer from whom you purchased the product. Keep your purchase receipt and model number (760H) readily available when seeking support.

© 2023 Kodak. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question