Emerson EVC1100

Emerson EVC1100 Flash Memory Camcorder User Manual

Model: EVC1100

1. Introduction

Thank you for purchasing the Emerson EVC1100 Flash Memory Camcorder. This compact digital video camera is designed for ease of use, allowing you to capture life's moments in video and still images. Featuring 4x digital zoom, expandable SD memory, and a built-in LED light, it is an ideal companion for everyday recording. This manual provides detailed instructions on the operation, maintenance, and troubleshooting of your camcorder.

2. Safety Information

- Do not expose the camcorder to water or moisture.
- Avoid extreme temperatures, direct sunlight, or high humidity.
- Do not attempt to disassemble or modify the camcorder. Refer all servicing to qualified personnel.
- Use only the specified battery type and charger.
- Keep out of reach of small children.
- Handle the camcorder with care to prevent damage from drops or impacts.

3. Package Contents

Please check that all items are present in your package:

- Emerson EVC1100 Flash Memory Camcorder
- USB Cable
- AV Cable
- Wrist Strap
- User Manual (this document)

4. Product Overview

Familiarize yourself with the various parts of your Emerson EVC1100 camcorder.



Image: The Emerson EVC1100 camcorder shown with its LCD screen rotated open. The front features the lens, 4x Digital Zoom marking, F2.8 f=8.0mm, a speaker grille, and the 'Emerson 3.0 MEGA PIXELS' logo. The side of the camcorder has 'Camcorder' text printed vertically.

4.1 Front View

- **Lens:** Captures video and still images.
- **Built-in LED Light:** Provides illumination in low-light conditions.
- **Microphone:** Records audio.

4.2 Side View (LCD Screen Open)

- **LCD Display:** For viewing live footage, playback, and menu navigation.

- **Control Buttons:** Power, Menu, Mode, Navigation (Up/Down/Left/Right), OK/Record.

4.3 Top View

- **Shutter/Record Button:** Initiates and stops video recording, or captures a still photo.

4.4 Bottom View

- **Battery Compartment:** Houses the camcorder's battery.
- **Tripod Mount:** For attaching the camcorder to a tripod.

4.5 Ports

- **USB Port:** For connecting to a computer for data transfer and charging.
- **AV Out Port:** For connecting to a television.
- **SD Card Slot:** For inserting an SD memory card (required for recording).

5. Setup

5.1 Battery Installation

1. Open the battery compartment cover on the bottom of the camcorder.
2. Insert the battery, ensuring the correct polarity as indicated inside the compartment.
3. Close the battery compartment cover securely.
4. Charge the battery fully before first use by connecting the camcorder to a USB power source using the provided USB cable.

5.2 Memory Card Installation

The camcorder requires an SD (Secure Digital) memory card for storing videos and photos. (Memory card not included).

1. Locate the SD card slot, usually on the side or bottom of the camcorder.
2. Insert the SD card with the metal contacts facing down (or as indicated by the diagram near the slot) until it clicks into place.
3. To remove, gently push the card in until it clicks, then release, and it will spring out.

5.3 Initial Power On and Settings

1. Open the LCD screen to power on the camcorder.
2. The first time you power on, you may be prompted to set the date and time. Use the navigation buttons to adjust and the OK button to confirm.

6. Operating

6.1 Recording Video

1. Ensure the camcorder is in video recording mode (check the icon on the LCD). If not, press the **Mode** button to switch.
2. Frame your subject using the LCD screen.
3. Press the **Record/Shutter** button to start recording. A red indicator or recording timer will appear on the screen.
4. To stop recording, press the **Record/Shutter** button again.

5. Use the zoom controls (if available, typically buttons near the lens or on the LCD panel) to zoom in or out during recording.

6.2 Taking Photos

1. Press the **Mode** button to switch to still photo mode.
2. Frame your shot.
3. Press the **Record/Shutter** button to capture a photo.

6.3 Playback

1. Press the **Mode** button to switch to playback mode.
2. Use the navigation buttons (Up/Down or Left/Right) to browse through your recorded videos and photos.
3. Press the **OK** button to play a selected video or view a photo in full screen.

6.4 Connecting to a Television

1. Connect one end of the provided AV cable to the AV Out port on the camcorder.
2. Connect the other end of the AV cable to the corresponding AV input ports on your television.
3. Select the correct AV input source on your television.
4. The camcorder's display will transfer to the TV screen, allowing you to view your media.

6.5 Connecting to a Computer

1. Connect the camcorder to your computer using the provided USB cable.
2. The camcorder should appear as a removable disk drive on your computer.
3. You can now transfer videos and photos to your computer by dragging and dropping files.

6.6 Menu Navigation

Press the **Menu** button to access settings. Use the navigation buttons to scroll through options and the **OK** button to select. Common settings include:

- **Resolution:** Adjust video or photo quality.
- **White Balance:** Adjust color balance for different lighting conditions.
- **Exposure:** Adjust brightness.
- **Date/Time:** Set or adjust the current date and time.
- **Format:** Erase all data on the memory card (use with caution).

7. Maintenance

7.1 Cleaning

- Use a soft, lint-free cloth to clean the camcorder body.
- For the lens and LCD screen, use a specialized lens cleaning cloth and solution. Do not use abrasive materials.
- Avoid spraying cleaning solutions directly onto the camcorder.

7.2 Storage

- Store the camcorder in a cool, dry place away from direct sunlight and extreme temperatures.

- If storing for an extended period, remove the battery.

7.3 Battery Care

- Charge the battery regularly, even if not in use, to maintain its lifespan.
- Do not expose the battery to high temperatures or dispose of it in fire.

8. Troubleshooting

Problem	Possible Cause / Solution
Camcorder won't turn on.	Battery is dead or not inserted correctly. Charge the battery or reinsert it.
No image on LCD screen.	Screen may be off or camcorder is in standby. Press any button to wake it up. Check battery level.
Cannot record video/take photos.	Memory card is full, not inserted, or corrupted. Insert a new card, format the current one (will erase data), or check insertion.
Poor video/photo quality.	Lens is dirty. Clean the lens. Lighting conditions are poor. Adjust settings or use the LED light.
Cannot connect to computer/TV.	Cables are not connected properly. Check connections. Ensure correct input source is selected on TV.

9. Specifications

- **Manufacturer:** Emerson
- **Model Number:** EVC1100
- **Digital Zoom:** 4x
- **Flash Memory Type:** SD (Secure Digital)
- **Lens Type:** Zoom
- **Package Dimensions:** 21.08 x 15.49 x 7.62 cm
- **Item Weight:** 272.16 g

10. Warranty and Support

For warranty information, please refer to the warranty card included with your product or visit the official Emerson website. For technical support or service inquiries, please contact Emerson customer service through their official channels.

Keep your purchase receipt as proof of purchase for warranty claims.

© 2023 Emerson. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question