JBL Micro Wireless

JBL Micro Wireless Ultra-Portable Speaker User Manual

Model: Micro Wireless

Introduction

The JBL Micro Wireless is an ultra-portable speaker designed for on-the-go audio. It features a built-in bass port and wireless Bluetooth connectivity, delivering full-range JBL sound in a compact form factor. This manual provides essential information for setting up, operating, and maintaining your speaker.



Figure 1: JBL Micro Wireless Speaker - Front View
This image shows the compact, circular design of the JBL Micro Wireless speaker, highlighting its black speaker grille, silver trim, and the blue LED indicator light at the top center. A silver handle is visible at the top.

What's in the Box

- One JBL Micro Wireless speaker
- One micro USB cable for recharging
- One carrying pouch
- Quick-start guide

Setup

1. Charging the Battery

Before first use, fully charge the JBL Micro Wireless speaker. The built-in Li-ion battery provides up to 5 hours of playback time. Use the included micro USB cable to connect the speaker to a USB power source (e.g., computer USB port or USB

wall adapter). The LED indicator will show charging status.



Figure 2: Charging Port and Audio Input
This image displays the side profile of the speaker, clearly showing the micro USB port for charging and the 3.5mm audio input jack, which allows for wired connections to non-Bluetooth devices.

2. Bluetooth Pairing

1. Press and hold the power button on the side of the speaker to turn it on. The blue LED indicator light will begin to flash, indicating it is in pairing mode.
2. On your Bluetooth-enabled device (smartphone, tablet, etc.), go to the Bluetooth settings.
3. Select "JBL Micro Wireless" from the list of available devices.
4. Once connected, the blue LED will glow steadily.

3. Wired Connection (Optional)

For devices without Bluetooth, use the integrated 3.5mm audio cable located at the bottom of the speaker. Simply pull out the cable and connect it to your device's headphone jack. The speaker will automatically switch to wired mode.



Figure 3: Integrated Audio Cable
This image displays the underside of the speaker, revealing the cleverly designed integrated 3.5mm audio cable that can be neatly stored when not in use, preventing tangling.

4. Daisy-Chain Capability

You can connect multiple JBL Micro Wireless speakers together for a more expansive sound experience. Use the 3.5mm audio cable from one speaker to connect to the audio input of another JBL Micro Wireless speaker.

Operating Your Speaker

Power On/Off

Press the power button on the side of the speaker to turn it on or off. The blue LED indicator will illuminate when the speaker is on.

Volume Control

Adjust the volume using the volume slider located on the side of the speaker. Slide it up to increase volume and down to decrease volume.



Figure 4: Power Button and Volume Control
This image shows the side of the speaker with the power button at the top and a vertical slider for volume adjustment below it, indicating the user controls.

LED Indicator

The blue LED indicator provides information about the speaker's status:

- **Solid Blue:** Connected via Bluetooth or wired, and powered on.
- **Flashing Blue:** Bluetooth pairing mode.

- **Flashing Red:** Low battery.
- **Solid Red (while charging):** Charging in progress.
- **Off (while charging):** Fully charged.

Maintenance

Cleaning

To clean your JBL Micro Wireless speaker, use a soft, dry cloth. Do not use abrasive cleaners or immerse the speaker in water.

Battery Care

To maximize battery life, avoid fully discharging the speaker frequently. Recharge the battery when the LED indicator flashes red. If storing the speaker for an extended period, charge it to approximately 50% every few months.

Troubleshooting

Problem	Possible Cause	Solution
No power	Battery is depleted.	Charge the speaker using the micro USB cable.
Cannot pair via Bluetooth	Speaker is not in pairing mode; device is out of range; previous pairing issue.	Ensure speaker is flashing blue. Move device closer. Turn off and on both speaker and device. Forget device on your phone and re-pair.
No sound	Volume is too low; incorrect input selected; device not playing audio.	Increase speaker and device volume. Ensure correct connection (Bluetooth or wired). Check if audio is playing on the source device.
Sound distortion	Volume too high; poor audio source quality.	Lower the volume on both the speaker and the source device. Try a different audio source.

Specifications

Model Name: Micro Wireless

Speaker Type: Portable Bluetooth Speaker

Connectivity Technology: Bluetooth

Wireless Communication Technology: Bluetooth

Speaker Maximum Output Power: 1 Watts

Audio Output Mode: Stereo

Battery Life: 5 Hours

Charging Time: 5 Hours

Battery Capacity: 1200 Milliamp Hours

Product Dimensions: 1.56"D x 1.56"W x 1.56"H

Item Weight: 8 ounces

Color: Black

Manufacturer: Harman Kardon

Bluetooth Range: 10 Meters (33 Feet)

Signal-to-Noise Ratio: 80 dB

Woofer Diameter: 1.63 Inches (40 Millimeters)

Compatible Devices: Smartphone, Tablet

Warranty and Support

Warranty Information

The JBL Micro Wireless speaker comes with a Limited Warranty. Please refer to the official JBL website or the warranty card included in your packaging for detailed terms and conditions.

Legal Disclaimer

Brimes International Inc. is not responsible for any merchandise that it does not receive or that is not returned in accordance with the following terms: Merchandise should be properly packed and insured with the carrier for the full amount of purchase. Any returned items that have any signs of abuse or intentional damage will be refused and returned to sender at sender's cost.

Customer Support

For further assistance, technical support, or warranty claims, please visit the official JBL support website or contact their customer service. Contact information can typically be found on the manufacturer's website or in the product packaging.

© 2023 JBL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question