Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Redi-Remote RT226419A

Instruction Manual

Replacement Remote Control for GE Televisions

Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your Redi-Remote replacement remote control. This remote is specifically designed to function as a direct replacement for various GE television models, ensuring full functionality without the need for complex programming.

Product Overview

The Redi-Remote replacement control is designed for ease of use, featuring a standard layout with clearly labeled buttons. The lower section of the remote features a sliding cover that reveals additional functions.



Image: Front view of the Redi-Remote replacement remote control. The top half displays primary controls such as Power, Volume, Channel, Mute, and number pad. The bottom half, initially covered, slides down to reveal advanced functions like Input, Setup, PIP, and other specialized buttons.

Button Functions (Top Section)

- **On PWR (Power)**: Red button, typically located at the top left. Used to turn the television on or off.
- **Off TV/VIDEO**: Black button, typically located at the top right. Used to switch the television off or cycle through video inputs.
- **SLEEP**: Black button, located below On PWR. Activates the sleep timer function.
- **DISP (Display)**: Black button, located below Off TV/VIDEO. Displays on-screen information.
- **CH+ / CH- (Channel Up/Down)**: Blue buttons, located centrally. Used to change channels.
- **VOL+ / VOL- (Volume Up/Down)**: Blue buttons, located on either side of the channel buttons. Used to adjust volume.
- **MUTE**: Black button, located below VOL-. Mutes or unmutes the television audio.
- **MENU**: Black button, located below SLEEP. Accesses the television's main menu.
- **RECALL / Prev Ch (Previous Channel)**: Black button, located below DISP. Switches to the previously viewed channel.
- **Number Pad (0-9, 100, ENT)**: Used for direct channel entry. "100" button may be used for channels 100 and above, and "ENT" (Enter) to confirm channel selection.

Button Functions (Lower Sliding Section)

Slide the bottom cover down to reveal additional controls:

- **RES-MEM (Resume Memory)**: Recalls previous settings or memory.
- **CS (Closed Captioning)**: Toggles closed captions on or off.
- **INPUT**: Cycles through available input sources (e.g., HDMI, AV, Component).
- **VIDEO**: Accesses video settings.
- **SETUP**: Enters the television's setup menu.
- **AUDIO**: Accesses audio settings.
- **PIP (Picture-in-Picture)**: Activates or controls the Picture-in-Picture function.
- **PROG (Program)**: Used for programming channels or other functions.
- **SWAP**: Swaps the main and PIP screens.
- **FREEZE**: Freezes the current image on screen.
- **CLEAR**: Clears entries or selections.
- **MOVE PIP**: Moves the Picture-in-Picture window.
- **Directional Arrows (Up, Down, Left, Right)**: Used for navigation within menus.
- **+/- Buttons**: Used for fine-tuning or selecting options.

Setup

Battery Installation

Your Redi-Remote requires 4 AAA batteries (included). To install:

1. Locate the battery compartment on the back of the remote control.
2. Slide the battery cover open.
3. Insert the 4 AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Slide the battery cover back into place until it clicks securely.

No Programming Required

This Redi-Remote is a custom-built replacement and does not require any programming. It is designed to work immediately with the specified GE television models upon battery installation. It cannot be programmed to control auxiliary devices.

Operating Instructions

Once batteries are installed, point the remote control directly at your GE television and press the desired function button.

- **Power On/Off**: Press the **On PWR** button to turn the TV on. Press it again or the **Off TV/VIDEO** button to turn it off.
- **Adjusting Volume**: Use the **VOL+** button to increase volume and **VOL-** to decrease volume.
- **Changing Channels**: Use the **CH+** button to go to the next channel and **CH-** to go to the previous channel. For direct channel entry, use the number pad and press **ENT**.
- **Muting Audio**: Press the **MUTE** button to silence the TV audio. Press it again to restore audio.
- **Accessing Menus**: Press the **MENU** button to open the TV's main menu. Use the directional arrows (found under the sliding cover) to navigate and **ENT** or other relevant buttons to select options.
- **Changing Inputs**: Slide down the lower cover and press the **INPUT** button to cycle through available video input sources (e.g., HDMI 1, AV 2).

Maintenance

To ensure the longevity and proper functioning of your remote control:

- **Cleaning**: Wipe the remote with a soft, dry cloth. Do not use liquid cleaners or abrasive materials.
- **Battery Replacement**: Replace batteries when the remote's response becomes sluggish or stops working. Always replace all batteries at the same time with new ones.
- **Storage**: Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Avoid Drops**: Protect the remote from physical impact, as drops can damage internal components.

Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

- **Remote Not Responding**:
  - Check if the batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new ones.
  - Ensure there are no obstructions between the remote and the television's infrared sensor.
  - Confirm you are pointing the remote directly at the television.
- **Certain Buttons Not Working**:
  - Check for any debris or stickiness around the button.
  - Ensure the remote is designed for your specific GE model. This remote is a direct replacement and does not require programming.
- **Remote Controls Other Devices**:

- This remote is designed exclusively for the specified GE television models and cannot be programmed to control auxiliary devices. If it is affecting other devices, ensure the other devices are not using the same infrared codes or are turned off when not in use.

Specifications

Feature	Detail
Product Dimensions	7 x 2.5 x 1 inches
Item Weight	4.5 ounces
Item Model Number	RT226419A
Batteries	4 AAA batteries (included)
Brand	Redi-Remote
Special Feature	No Programming Needed
Max Number of Supported Devices	1
Compatible Devices	Television (GE models: 197462, 20GT372, 211683, 211687, 27GC802, 27GC805, etc.)
Connectivity Technology	Infrared

Support

For any concerns or issues with your Redi-Remote replacement control after purchase, please contact the seller directly for assistance. They can provide specific support related to your product.

© 2023 Redi-Remote. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009D5LYBC

More documents and user manuals: **https://manuals.plus/**