

[Manuals.plus](#) /

› [Calypso](#) /

› CALYPSO K5607 Digital Watch User Manual

Calypso K5607

CALYPSO K5607 Digital Watch User Manual

Model: K5607

INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your CALYPSO K5607 Digital Watch. Please read this manual thoroughly before using your watch to ensure optimal performance and longevity.

PRODUCT FEATURES

- Digital time display.
- Durable multi-coloured rubber case.
- Comfortable blue rubber strap with buckle closure.
- Clear coloured dial for easy readability.
- Water resistance up to 10 ATM (100 meters), suitable for swimming and snorkeling.



Figure 1: CALYPSO K5607 Digital Watch. This image displays the watch's face, highlighting its digital display and button layout.

SETUP

1. Initial Time Setting

1. Press the **MODE** button (bottom left) repeatedly until the time setting mode is displayed.
2. Use the **START** button (top right) to adjust the hour.
3. Use the **RECALL** button (top left) to adjust the minute.
4. Press the **MODE** button again to confirm and exit the setting mode.

2. Strap Adjustment

The blue rubber strap is designed for comfort and durability. Adjust the buckle to fit securely but comfortably around your wrist. Ensure the watch is not too tight to allow for proper circulation.

OPERATING INSTRUCTIONS

Button Functions:

- **MODE** (Bottom Left): Cycles through different modes (Time, Alarm, Stopwatch, Timer).
- **RECALL** (Top Left): Used for reviewing stored data or adjusting settings in specific modes.
- **START** (Top Right): Initiates functions like stopwatch, timer, or adjusts values during setting.
- **STOP** (Bottom Right): Stops functions like stopwatch, timer, or resets values.
- **LIGHT/ADJ.** (Middle Right): Activates the backlight for visibility in low light conditions. Also used for adjustment in certain modes.

Modes of Operation:

1. **Time Mode:** Displays current time, day, and date. Press **LIGHT/ADJ.** for backlight.
2. **Alarm Mode:** Set daily alarms. Use **START** and **RECALL** to set alarm time.
3. **Stopwatch Mode:** Measures elapsed time. Press **START** to begin, **STOP** to pause/reset. **LAP/SPL** (top right, next to **START**) might be for lap/split times.
4. **Timer Mode:** Countdown timer. Set desired time using **START** and **RECALL**, then press **START** to begin countdown.

MAINTENANCE

Cleaning:

Wipe the watch case and strap regularly with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the watch's finish and seals.

Water Resistance:

The watch is water resistant to 10 ATM (100 meters). This means it is suitable for recreational swimming and snorkeling. Do not operate buttons underwater. Avoid exposing the watch to hot water or steam, as this can compromise the water resistance seals.

Battery Replacement:

When the display becomes dim or functions become erratic, the battery may need replacement. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance. Refer to the specifications for battery type.



Figure 2: CALYPSO Watch Packaging. This image shows the unique battery-shaped packaging for the watch.

TROUBLESHOOTING

- **Watch display is blank or dim:** The battery may be low or depleted. Replace the battery.
- **Time is incorrect:** Re-set the time according to the "Initial Time Setting" instructions in the Setup section.
- **Buttons are unresponsive:** Ensure the watch is not in a locked mode (if applicable, though not specified for this model). If issues persist, a battery replacement might resolve it.
- **Water ingress:** If water appears inside the watch, immediately take it to a qualified technician for inspection and repair. Do not attempt to open the watch yourself.

SPECIFICATIONS

Model Number:	K5607
Brand:	Calypso
Display Type:	Digital
Case Material:	Rubber
Strap Material:	Rubber
Water Resistance:	10 ATM (100 meters)
Product Dimensions:	10 x 10 x 15 cm
Item Weight:	50 g
Manufacturer:	Festina Lotus SA.

SAFETY INFORMATION AND REGULATORY NOTICES

⚠ BATTERY WARNING ⚠

KEEP OUT OF REACH OF CHILDREN

In case of ingestion, seek medical attention immediately.

Button batteries, often found in small portable devices like this watch, pose a significant risk if swallowed due to their small

size and round shape. Ingestion can be very dangerous and potentially fatal.

What to do in case of suspected ingestion:

- Immediately take the child to the emergency room.
- Do not give the child anything to drink or eat until an X-ray has confirmed whether a battery has been swallowed.
- Do not induce vomiting.
- Bring the device containing the battery or the original battery packaging to the emergency room to assist medical personnel in identifying the battery model and chemical composition.

Disposal of Electronic Waste (WEEE) and Batteries:

This product contains electronic components and a battery. Do not dispose of this product with household waste. It must be handed over to an appropriate collection point for the recycling of electrical and electronic equipment (WEEE) and batteries in accordance with local regulations. Proper disposal helps prevent potential negative consequences for the environment and human health.

For more information on WEEE and battery disposal, please visit www.festinagroup.com.

4.- AVVISI NORMATIVI

UNIONE EUROPEA

CE **RoHS** Dichiarazione di conformità CE semplificata
FESTINA LOTUS SA, con sede legale in C/Velázquez nº 150, 3º 1ª 28002 Madrid (Spagna), DICHIARA sotto la sua esclusiva responsabilità che questo prodotto e i relativi accessori sono conformi ai requisiti essenziali della Direttiva 2011/65/UE e della sua modifica 2015/863/UE. (RoHS) e/Direttiva 2014/35/UE, (LVD).
Dichiara inoltre che tutti gli articoli e/o accessori con connettività wireless sono conformi alla Direttiva 2014/53/UE (RED) e/o alla Direttiva 2014/30/UE (EMC).
Il testo completo della Dichiarazione di conformità dell'UE è disponibile al seguente indirizzo: <https://www.festinagroup.com/>

Apparecchiature elettriche ed elettroniche e riciclaggio delle batterie
L'orologio, gli accessori e la batteria contengono sostanze che non devono essere smaltite come rifiuti domestici e sono soggette a normative specifiche.
Fatte salve le normative nazionali, nell'Unione Europea le apparecchiature elettriche ed elettroniche sono soggette alla Direttiva 2012/19/UE sui rifiuti di apparecchiature elettriche ed elettroniche (RAEE) e le pile in esse contenute sono soggette al Regolamento UE 2023/1542 del 12 luglio 2023 sulle pile e batterie e i loro rifiuti.

Rifiuti di apparecchiature elettriche ed elettroniche, WEEE Direttiva 2012/19/UE
Questo prodotto non deve essere smaltito insieme ai rifiuti domestici, ma tramite un punto di raccolta RAEE autorizzato. Per ulteriori informazioni su dove è possibile consegnare i rifiuti per il riciclaggio, contattare le autorità locali o il rivenditore presso il quale è stato acquistato il prodotto.
Festina adempie ai propri obblighi di raccolta dei RAEE in quanto membro di differenti sistemi di conformità.
Per ulteriori informazioni: <https://www.festinagroup.com/>

Le batterie e i rifiuti di batterie Regolamento 2023/1542
Al momento di essere sostituite le batterie devono essere rimosse e smaltite presso un punto di raccolta autorizzato. Le batterie separabili devono essere rimosse prima dello smaltimento del prodotto e smaltite separatamente.
Festina adempie ai propri obblighi di raccolta, in questo settore, in quanto membro di vari programmi di conformità.
Per ulteriori informazioni: <https://www.festinagroup.com/>
Si ricorda che le rispettive legislazioni nazionali dei Paesi dell'UE possono raccomandare o obbligare a restituire i prodotti elettrici e/o elettronici e le pile e le batterie in determinati punti di raccolta pubblici o privati (punti vendita) al termine della loro vita utile.
Ulteriori informazioni sullo smaltimento di questi prodotti possono essere ottenute presso le autorità locali del Paese di residenza, se necessario, presso il servizio di gestione dei rifiuti competente e presso il punto vendita abituale.

Informazioni per i prodotti di consumo contenenti batterie:

**BATTERY WARNING**

KEEP OUT OF REACH OF CHILDREN
In case of ingestion seek medical attention immediately.



Le batterie a bottone sono appositamente progettate per piccoli apparecchi portatili. Le loro piccole dimensioni e la loro forma rotonda aumentano il rischio che siano ingerite accidentalmente dai bambini.

- Che fare in caso di sospetta ingestione?**
- Una batteria a bottone, se ingerita, corre il rischio di rimanere bloccata nell'esofago. Questa situazione può essere molto pericolosa e, nel peggiore dei casi, anche mortale.
- Portare subito il bambino al pronto soccorso.
 - Non dare al bambino da bere o da mangiare finché con una radiografia non si sarà stabilito se ha ingoiato una batteria.
 - Non indurre il vomito.
 - Portare al pronto soccorso l'apparecchio contenente la batteria o l'imballaggio originale delle batterie per aiutare il medico a identificarne il modello e la composizione chimica.

 Bluetooth

Caratteristiche principali della radio

Banda di frequenza	Funzionalità	Potenza massima di trasmissione
2,412-2,472 GHz	WLAN IEEE 802.11 b/g/n	19 dBm
2,402-2,480 GHz	Bluetooth 5.0	12 dBm

Il marchio e i loghi Bluetooth sono marchi registrati di proprietà di Bluetooth SIG, Inc. e qualsiasi uso di tali marchi da parte di FESTINA è concesso in licenza. Altri marchi e nomi commerciali appartengono ai rispettivi proprietari.

Figure 3: Regulatory and Safety Information. This document includes important warnings regarding battery safety and proper disposal of electronic waste.

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included with your purchase or visit the official Calypso website. Keep your proof of purchase for any warranty claims.

Manufacturer: Festina Lotus SA.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I use the stopwatch on the Calypso K5607 digital watch?

To use the stopwatch (cronómetro) on your Calypso K5607, follow these steps: Enter Stopwatch Mode: Press the MODE button (bottom left) repeatedly until you reach the Stopwatch screen. Start Timing: Press the START button...

[Read full answer](#)

Open the live page

<https://manuals.plus/asin/B009FJJC5Q>

More documents and user manuals: <https://manuals.plus/>