Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Stihl 46017404905

STIHL KB-KM Bristle Brush Instruction Manual

Model: KB-KM (46017404905)

1. Product Overview

1.1 About the STIHL KB-KM Bristle Brush

The STIHL KB-KM Bristle Brush is a specialized attachment designed for the STIHL CombiSystem. It features a working width of 60 cm and is engineered to thoroughly clean grouted surfaces or uneven natural stone floors, effectively removing coarse dirt and solid soil. This tool weighs approximately 1.4 kg and has a total length of 125 cm when assembled. It is compatible with all STIHL CombiEngines equipped with an all-round handle (R).

1.2 Key Features

- Combination tool sweeper brush for the STIHL CombiSystem.
- Designed for thorough cleaning of grouted surfaces or uneven natural stone floors.
- Effectively removes coarse dirt and solid soil.
- Approved for use with all STIHL CombiEngines featuring an all-round handle (R).



Figure 1: The STIHL KB-KM Bristle Brush attachment. This image shows the black bristle brush head with a protective cover, attached to a long, silver shaft, ready for connection to a STIHL CombiEngine.

2. Setup and Assembly

The STIHL KB-KM Bristle Brush is designed for quick and secure attachment to compatible STIHL CombiEngines. Ensure you have the necessary tools, such as a Torx wrench, for secure fastening.

2.1 Attaching the Bristle Brush

1. Ensure the STIHL CombiEngine is turned off and cooled down before beginning assembly.
2. Locate the coupling mechanism on both the CombiEngine and the KB-KM Bristle Brush attachment.
3. Align the shaft of the bristle brush with the coupling on the CombiEngine.
4. Push the attachment firmly into the coupling until it clicks into place or the alignment marks indicate a secure fit.
5. Tighten any securing screws or clamps (e.g., using a Torx wrench) to ensure the attachment is firmly fixed and there is no wobble. Refer to your CombiEngine's manual for specific attachment instructions.
6. Verify that the attachment is securely fastened before starting the engine.

3. Operating Instructions

3.1 Before Operation

- Always wear appropriate personal protective equipment (PPE), including eye protection, hearing protection, and sturdy footwear.
- Inspect the bristle brush for any damage or loose parts before each use. Ensure bristles are intact and not excessively worn.
- Clear the work area of any large debris or obstacles that could damage the brush or be thrown by it.
- Ensure the attachment is securely connected to the CombiEngine.

3.2 Using the Bristle Brush

1. Start the STIHL CombiEngine according to its operating manual.
2. Hold the CombiEngine firmly with both hands, maintaining a balanced stance.
3. Lower the bristle brush head gently onto the surface to be cleaned.
4. Move the brush steadily across the surface, allowing the rotating bristles to sweep away dirt and debris. For stubborn dirt, apply gentle, consistent pressure.
5. Work in overlapping passes to ensure complete coverage.
6. Avoid excessive force, as this can damage the bristles or the surface.
7. After use, turn off the CombiEngine and allow the brush to stop rotating completely before setting it down.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your STIHL KB-KM Bristle Brush.

4.1 Cleaning

- After each use, remove any accumulated dirt, leaves, or debris from the bristles and the brush housing.
- Use a stiff brush or compressed air to clean the bristles. Avoid using harsh chemicals that could damage the material.

- Wipe down the shaft and housing with a damp cloth.

4.2 Storage

- Store the bristle brush in a clean, dry place, away from direct sunlight and extreme temperatures.
- Hang the attachment if possible to prevent bristles from deforming.

4.3 Inspection

- Periodically inspect the bristles for wear. Replace the brush head if bristles are severely worn or damaged.
- Check all fasteners and connections for tightness. Tighten if necessary.
- Inspect the shaft for any bends or damage.

5. Troubleshooting

Problem	Possible Cause	Solution
Poor cleaning performance	Worn bristles; Incorrect operating angle; Excessive debris buildup.	Inspect and replace brush head if bristles are worn; Adjust operating angle for better contact; Clean brush head regularly.
Brush not rotating or rotating slowly	Improper attachment to CombiEngine; Engine issues; Obstruction in brush head.	Ensure attachment is securely fastened; Refer to CombiEngine manual for engine troubleshooting; Clear any obstructions from the brush head.
Excessive vibration or noise	Loose attachment; Damaged shaft or brush head; Unbalanced bristles.	Tighten all connections; Inspect for damage and replace parts if necessary; Clean brush head to remove any material causing imbalance.

6. Technical Specifications

Specification	Value
Model Number	46017404905
Working Width	60 cm
Weight	Approx. 1.4 kg
Total Length	125 cm
Product Dimensions (Packaged)	36.22 x 7.87 x 7.87 inches
Material Feature	Natural
Surface Recommendation	Stone
Compatible Engines	STIHL CombiEngines with all-round handle (R)

7. Warranty and Support

For information regarding warranty coverage, service, and technical support for your STIHL KB-KM Bristle Brush, please refer to the warranty documentation provided with your purchase or contact STIHL directly through their official website or

authorized dealer network.
STIHL products are known for their quality and durability. Ensure you register your product if required to activate any extended warranty benefits.
Note: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This disclaimer is unrelated to the product's function.

© 2024 STIHL. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009HO5WO4

More documents and user manuals: **https://manuals.plus/**