Hampton Bay WB0317

Hampton Bay Matte Black 1-Light Outdoor Jelly-Jar Wall Light Instruction Manual

Model: WB0317

Product Overview

The Hampton Bay Wall-Mount Outdoor Matte-Black Jelly-Jar Wall Light is designed for outdoor use, providing illumination for backdoors or side-entry applications. Its traditional design features a matte black finish and a clear glass jelly-jar shade, allowing for broad light distribution.



Image: Hampton Bay Matte Black 1-Light Outdoor Jelly-Jar Wall Light, showcasing its matte black base and clear ribbed glass shade.

Safety Information

Before beginning installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or removing the fuse at the fuse box. Consult a qualified electrician if you have any electrical questions.

- Ensure all electrical connections comply with local codes and ordinances.
- Use only the specified bulb type and wattage.
- Do not install near flammable materials.
- This fixture is designed for outdoor use and is weather resistant.

Package Contents

Verify that all parts listed below are included in your package:

- Light Fixture Assembly (Matte Black Base with Clear Jelly-Jar Shade)
- Mounting Hardware (Screws, Wire Nuts, Mounting Plate)
- Instruction Manual

Setup and Installation

1. **Preparation:** Turn off power at the circuit breaker or fuse box. Ensure the mounting surface is clean and dry.
2. **Mounting Plate Installation:** Attach the mounting plate to the electrical junction box using the provided screws. Ensure it is securely fastened.
3. **Wiring:** Connect the fixture's wires to the house wires. Connect the black wire from the fixture to the black (hot) wire from the junction box. Connect the white wire from the fixture to the white (neutral) wire from the junction box. Connect the ground wire from the fixture to the ground wire from the junction box (or to the mounting plate if no ground wire is present). Secure connections with wire nuts.
4. **Fixture Attachment:** Align the fixture base with the mounting plate and secure it using the provided screws. Ensure the fixture is flush against the mounting surface.
5. **Bulb Installation:** Insert an E26 Medium base bulb (not included) into the socket. Do not exceed the maximum wattage specified on the fixture.
6. **Glass Shade Installation:** Carefully attach the clear jelly-jar glass shade to the fixture. Ensure it is securely seated to prevent water ingress.
7. **Power Restoration:** Turn the power back on at the circuit breaker or fuse box. Test the light fixture.

Operating Instructions

This outdoor wall light operates via a standard wall switch (not included). Once installed and wired correctly, simply toggle the connected wall switch to turn the light on or off.

- **Power Source:** Corded Electric, 120 Volts (AC).
- **Light Source:** Designed for E26 Medium base bulbs. LED light source type is recommended for energy efficiency.

Maintenance

Regular maintenance will help prolong the life and appearance of your outdoor light fixture.

- **Cleaning:** To clean the fixture, wipe it with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or glass.
- **Bulb Replacement:** Ensure power is off before replacing the bulb. Allow the bulb to cool completely before touching. Replace with an E26 Medium base bulb of the appropriate wattage.
- **Inspection:** Periodically inspect the wiring and connections for any signs of wear or damage. Ensure the glass shade is securely in place to maintain its water resistance.

Troubleshooting

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connections. Faulty bulb.	Check circuit breaker/fuse. Verify all wire connections are secure. Replace bulb.
Light flickers.	Loose bulb. Loose wire connections. Incorrect bulb type.	Tighten bulb. Check wire connections. Ensure correct bulb type and wattage.
Water inside shade.	Shade not properly sealed.	Remove shade, dry interior, and re-install ensuring a tight seal.

Problem	Possible Cause	Solution

Specifications

Model: WB0317

Brand: Hampton Bay

Type: Outdoor Wall Light

Finish: Matte Black

Shade Material: Clear Glass

Material: Glass, Metal

Dimensions: 7.25"h x 4.5"w (approximate, based on product title)

Voltage: 120 Volts (AC)

Bulb Base: E26 Medium

Number of Lights: 1

Installation Type: Wall Mount

Indoor/Outdoor Usage: Outdoor

Water Resistance Level: Water Resistant

UPC: 725916814274

Warranty and Support

For warranty information or technical support, please contact Hampton Bay customer service. Keep your purchase receipt for warranty claims.
Note: Specific warranty details may vary. Refer to the product packaging or manufacturer's website for the most current information.

© 2023 Hampton Bay. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question