Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj PX 143

Bajaj Platini 30 L Convection Microwave Oven (Model PX 143) User Manual

Comprehensive instructions for safe and efficient operation.

Safety Instructions Product Overview Setup Operating Instructions Care & Maintenance Troubleshooting Specifications Warranty & Support

1. Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not allow the cord to hang over the edge of a table or counter, or touch hot surfaces.
- To protect against electrical shock, do not immerse the cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children. This appliance features a**Child Safety Lock**.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Only use utensils that are suitable for use in microwave ovens. Metal containers or foil should not be used in microwave mode.
- Always ensure proper ventilation around the oven. Do not block air vents.
- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not use corrosive chemicals or vapors in this appliance.

2. Product Overview

The Bajaj Platini 30 L Convection Microwave Oven (Model PX 143) is designed for versatile cooking, offering microwave, grill, and convection functions. Its 30-liter capacity makes it suitable for various household cooking needs.



Figure 1: Bajaj Platini 30 L Convection Microwave Oven (Model PX 143)

This image displays the Bajaj Platini 30 L Convection Microwave Oven, Model PX 143, featuring its silver finish and control panel. The oven has a sleek design suitable for countertop placement.

Key Features:

- **30 Litre Capacity:** Ideal for families.
- **Convection Function:** Allows for baking and roasting.
- **Steel Finish/Mirror Finish Body:** Durable and aesthetically pleasing design.
- **Auto Cook/One Touch Menu:** Pre-programmed settings for various dishes.
- **Auto Defrost:** Convenient defrosting by weight or time.
- **Cooking Completion Alarm:** Audible alert when cooking cycle finishes.
- **Child Safety Lock:** Prevents accidental operation by children.
- **Digital Clock:** Displays current time.
- **5 Power Levels:** Offers flexibility for different cooking requirements.
- **Timer in Minutes:** Precise control over cooking duration.
- **Tact Button/Jog Dial:** User-friendly interface for setting functions.

3. Setup and Installation

3.1 Unpacking

- Carefully remove the oven and all packing materials from the carton.
- Check the oven for any damage, such as dents or a misaligned door. Do not operate if damaged.

- Remove any protective film from the cabinet surface.
- Remove the turntable, turntable ring, and instruction manual from the oven cavity.

3.2 Placement

- Place the oven on a flat, stable surface strong enough to hold its weight. This is a **Countertop** installation type.
- Ensure adequate ventilation: leave a minimum of 20 cm (8 inches) of space above the oven, 10 cm (4 inches) at the rear, and 5 cm (2 inches) on both sides.
- Do not place the oven near heat sources or in a damp environment.

3.3 Electrical Connection

- Plug the power cord into a properly grounded electrical outlet. The oven operates on **230 Volts** and consumes **900 Watts**.
- Do not use extension cords or adapters.

4. Operating Instructions

The Bajaj Platini PX 143 features a user-friendly interface with a **Tact Button/Jog Dial** for easy program selection and time adjustment.

4.1 Setting the Clock

1. Press the "Clock" button.
2. Rotate the **Jog Dial** to set the hour. Press "Clock" again to confirm.
3. Rotate the **Jog Dial** to set the minutes. Press "Clock" to confirm. The digital clock will now display the time.

4.2 Microwave Cooking

1. Place food in a microwave-safe container on the turntable.
2. Close the oven door. The **Door Orientation** is Left.
3. Press the "Microwave" button.
4. Rotate the **Jog Dial** to select the desired power level (1-5).
5. Press "Microwave" again to confirm the power level.
6. Rotate the **Jog Dial** to set the cooking time (up to 99 minutes 99 seconds).
7. Press "Start" to begin cooking.

4.3 Convection Cooking

This oven features a **Convection** cooking mode, allowing for baking and roasting with even heat distribution.

1. Place food on the appropriate rack (if provided) in the oven.
2. Press the "Convection" button.
3. Rotate the **Jog Dial** to select the desired temperature.
4. Press "Convection" again to confirm the temperature.
5. Rotate the **Jog Dial** to set the cooking time.
6. Press "Start" to begin cooking.

4.4 Auto Cook / One Touch Menu

The oven includes pre-programmed settings for common dishes. Refer to the internal label or a separate recipe guide for specific menu options.

1. Press the "Auto Cook" or "One Touch Menu" button repeatedly to cycle through available programs.
2. Once the desired program is displayed, press "Start". The oven will automatically set the cooking time and power level.

4.5 Auto Defrost

The **Auto Defrost** function allows for efficient thawing of frozen foods.

1. Place the frozen food in a microwave-safe container.
2. Press the "Defrost" button.
3. Rotate the **Jog Dial** to select the food type or weight.
4. Press "Start" to begin defrosting.

4.6 Child Safety Lock

To prevent unsupervised operation by children, activate the**Child Safety Lock**.

- **To activate:** Press and hold the "Stop/Cancel" button for 3 seconds. A lock indicator will appear on the display.
- **To deactivate:** Press and hold the "Stop/Cancel" button for 3 seconds again. The lock indicator will disappear.

4.7 Cooking Completion Alarm

An audible alarm will sound when the cooking cycle is complete. Press any button or open the door to silence the alarm.

5. Care and Maintenance

Regular cleaning and maintenance will ensure the longevity and efficient operation of your microwave oven.

- **Cleaning the Exterior:** Wipe the exterior (Steel finish/Mirror finish body) with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Cleaning the Interior:** For the Stainless Steel interior, wipe with a damp cloth after each use. For stubborn food splatters, place a bowl of water with lemon juice inside and microwave for 2-3 minutes to loosen residue, then wipe clean.
- **Turntable and Ring:** The glass turntable and turntable ring can be washed in warm soapy water or in a dishwasher. Ensure they are completely dry before placing them back in the oven.
- **Door Seals:** Keep the door seals clean to ensure proper closure and efficient operation.
- **Ventilation Openings:** Ensure the ventilation openings are clear of dust and debris.
- Always unplug the oven before cleaning.

6. Troubleshooting Guide

If you encounter issues with your oven, refer to the following common problems and solutions before contacting service.

Problem	Possible Cause	Solution
Oven does not start.	Power cord not plugged in; Door not closed properly; Child safety lock activated.	Ensure plug is firmly in outlet; Close door securely; Deactivate child safety lock (refer to section 4.6).

Problem	Possible Cause	Solution
Food not heating.	Incorrect power level or cooking time set; Metal utensils used.	Adjust power level and time; Ensure only microwave-safe utensils are used.
Light inside oven not working.	Bulb needs replacement.	Contact qualified service personnel for bulb replacement. Do not attempt to replace yourself.
Display shows "E" or error code.	Internal malfunction.	Unplug the oven for 1 minute, then plug back in. If the error persists, contact customer support.

7. Product Specifications

Feature	Detail
Brand	Bajaj
Model	PX 143
Capacity	30 Litres
Oven Cooking Mode	Convection
Power Consumption (Microwave)	900 Watts
Operating Voltage	230 Volts
Installation Type	Countertop
Special Features	Tact Button/Jog Dial, Auto Cook, Auto Defrost, Child Safety Lock, Digital Clock, Cooking Completion Alarm
Defrost System	Defrost
Door Orientation	Left
Material (Exterior)	Steel Finish/Mirror Finish
Inner Material Type	Stainless Steel
Colour	Silver
Item Weight	2 kg *(Note: This weight is as per provided data and may vary)*
Part Number	490053

8. Warranty and Customer Support

8.1 Warranty Information

This Bajaj Platini 30 L Convection Microwave Oven (Model PX 143) comes with a **2-year warranty on the product** from the date of purchase. Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under normal household use.

The warranty does not cover damage caused by misuse, accident, unauthorized modification, or failure to follow the instructions in this manual.

8.2 Customer Support

For any service, repair, or technical assistance, please contact Bajaj customer support. You can find their contact details on the official Bajaj website or on your warranty card.
When contacting support, please have your model number (PX 143) and purchase details ready.

© 2023 Bajaj. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009OE4L6C

More documents and user manuals: **https://manuals.plus/**