Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj MX 1

Bajaj MX 1 1200-Watt Steam Iron User Manual

Model: MX 1

1. Introduction

This manual provides essential instructions for the safe and efficient use of your Bajaj MX 1 1200-Watt Steam Iron. Please read it thoroughly before first use and retain it for future reference.

Product Overview

The Bajaj MX 1 is a 1200-watt steam iron designed for effective garment care. It features a non-stick coated soleplate, variable steam control, and a steam burst function to help remove creases from various fabrics.



Figure 1: Bajaj MX 1 1200-Watt Steam Iron

This image displays the Bajaj MX 1 steam iron, showcasing its purple and white plastic body, non-stick soleplate, and control dials for

temperature and steam settings.

2. Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and personal injury.

- Ensure the iron is connected to a power supply matching its voltage rating.
- Do not leave the iron unattended while it is switched on or connected to the power supply.
- Keep the iron out of reach of children and pets.
- Always place the iron on a stable, heat-resistant surface.
- Do not immerse the iron, power cord, or plug in water or other liquids.
- Unplug the iron from the power outlet before filling or emptying the water tank, and when not in use.
- Exercise caution when handling hot surfaces and steam.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged.
- For safety, the iron is equipped with a thermal fuse.

Legal Disclaimer: Please check your local laws before purchasing and using this product.

3. Product Components

Familiarize yourself with the parts of your Bajaj MX 1 Steam Iron:

- **Non-stick Coated Soleplate:** Ensures smooth gliding over fabrics.
- **Water Tank:** Translucent 150ml capacity for steam generation.
- **Water Spray Nozzle:** For moistening stubborn creases.
- **Steam Control Dial:** Adjusts steam output.
- **Temperature Control Dial:** Selects appropriate heat for different fabrics.
- **Steam Burst Button:** Delivers a powerful burst of steam.
- **Neon Indicator:** Illuminates when the iron is heating and turns off when the set temperature is reached.
- **Power Cord:** Connects the iron to the electrical outlet.

4. Setup and Preparation

1. **Unpacking:** Carefully remove the iron from its packaging. Retain packaging for storage or disposal.
2. **First Use:** Before first use, wipe the soleplate with a damp cloth to remove any manufacturing residues. It is normal for a slight odor or smoke to occur during the first few minutes of operation as heating elements cure.
3. **Filling the Water Tank:**
    - Ensure the iron is unplugged and cooled down.
    - Set the steam control to the "Dry Ironing" position (minimum steam).
    - Open the water inlet cover.
    - Fill the 150ml translucent water tank with clean tap water up to the MAX mark. Do not overfill.
    - Close the water inlet cover securely.
    - **Important:** Do not use hard water, perfumed water, or chemical descaling agents, as these can damage the iron and cause leakage.

5. Operating Instructions

1. **Sorting Laundry:** Sort garments according to fabric type (e.g., linen, cotton, wool, silk, synthetics) and their recommended ironing temperature.
2. **Temperature Setting:**
    - Plug the iron into a suitable power outlet.
    - Turn the temperature control dial to the desired setting based on the fabric type. Refer to garment care labels.
    - The neon indicator will illuminate, indicating the iron is heating.
    - Wait for the neon indicator to turn off, signifying that the iron has reached the selected temperature. This is crucial for effective steam function and to prevent water leakage.
3. **Dry Ironing:**
    - Ensure the steam control dial is set to the "Dry Ironing" position (minimum steam).
    - Iron garments without steam.
4. **Steam Ironing:**
    - Ensure the water tank is filled (see Section 4).
    - Set the temperature control dial to a setting suitable for steam (typically cotton or linen, indicated on the dial).
    - Wait for the neon indicator to turn off, confirming the iron is hot enough.
    - Adjust the variable steam control dial to the desired steam output (up to 8g/min).
    - Begin ironing.
5. **Steam Burst:**
    - For stubborn creases, press the steam burst button. This delivers a powerful shot of steam.
    - Allow a few seconds between bursts for the steam to regenerate.
    - Use only when the iron is at a high temperature setting.
6. **Water Spray:**
    - Press the water spray button to lightly moisten fabrics, aiding in crease removal.
7. **After Ironing:**
    - Turn the temperature control dial to the minimum setting.
    - Unplug the iron from the power outlet.
    - Allow the iron to cool completely before emptying the water tank and storing.

6. Maintenance and Storage

Cleaning

- Always ensure the iron is unplugged and completely cool before cleaning.
- Wipe the soleplate with a damp cloth and a mild, non-abrasive cleaner if necessary. Do not use harsh scouring pads or metal cleaners.
- Clean the exterior plastic parts with a soft, damp cloth.
- **Self-Cleaning Function:** The iron is equipped with a self-cleaning function to prolong its shelf life. Perform this at least once a month. Refer to the specific instructions in your full product manual for detailed steps on using the self-clean feature.

Storage

- Empty any remaining water from the tank after each use.
- Allow the iron to cool down completely.
- Store the iron upright in a safe, dry place, away from moisture and direct sunlight.

7. Troubleshooting

If you encounter issues with your iron, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outage; faulty outlet.	Check power connection; test outlet with another appliance.
Water leakage from soleplate.	Iron not hot enough for steam; water tank overfilled; hard water usage.	Wait for the iron to fully heat up (neon indicator off) before using steam. Do not overfill the water tank. Use clean tap water; avoid hard water. Ensure steam control is set to "Dry Ironing" when not using steam.
Steam burst not working effectively.	Iron not hot enough; insufficient water in tank.	Ensure iron is at maximum temperature; refill water tank.
Soleplate sticking or leaving marks.	Incorrect temperature for fabric; residue on soleplate.	Adjust temperature; clean soleplate (see Maintenance).



Figure 2: Tips for preventing water leakage from your steam iron.

This image illustrates four key tips to prevent water leakage: waiting for the iron to heat up before using steam, avoiding hard water, keeping the iron clean, and preventing over-filling of the water tank.

8. Specifications

Feature	Detail
Brand	Bajaj
Model Number	MX 1
Power Consumption	1200 Watts
Soleplate Type	Non-stick coated
Steam Output	8 gram/minute

Feature	Detail
Water Tank Capacity	150 ml (translucent)
Special Features	Steam Burst, Variable Steam Control, Water Spray, Adjustable Thermostat, Self-Cleaning, Neon Indicator, Thermal Fuse
Item Weight	815 Grams
Base Material	Plastic
Colour	Purple

9. Warranty and Support

Your Bajaj MX 1 1200-Watt Steam Iron comes with a **2-year warranty** on the product from the date of purchase.
For warranty claims, technical support, or service inquiries, please contact Bajaj customer service. Keep your purchase receipt as proof of purchase.
For more information, you may visit the official Bajaj website or contact their authorized service centers.

© 2023 Bajaj. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009P2L9H2

More documents and user manuals: **https://manuals.plus/**