Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj RX 7

Bajaj Majesty RX 7 2000W Heat Convector Room Heater User Manual

Model: RX 7 | Brand: Bajaj

1. Introduction

Thank you for choosing the Bajaj Majesty RX 7 2000 Watts Heat Convector Room Heater. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.
The Bajaj Majesty RX 7 is designed to provide instant warmth and personalized comfort during colder seasons. With its powerful 2000W heating capacity and multiple heat settings, it ensures quick and effective heat distribution in your living space.

2. Important Safety Instructions

To reduce the risk of fire, electric shock, or injury, always follow these basic precautions:

- Read all instructions before using this heater.
- Do not use this heater outdoors. It is designed for indoor use only.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 meters) from the front of the heater and keep them away from the sides and rear.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Always unplug heater when not in use.

- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has an automatic thermal shutoff feature to prevent overheating. If the heater overheats, it will automatically turn off. Unplug the heater, let it cool down for a few minutes, then plug it back in.
- The cool-touch handle allows for safe carrying and repositioning during operation.
- The product is ISI Approved, ensuring quality and safety standards.

3. Setup

1. **Unpacking:** Carefully remove the heater from its packaging. Retain the packaging for storage or in case of return.
2. **Placement:** Place the heater on a firm, level surface. Ensure it is at least 3 feet (0.9 meters) away from walls, furniture, and other combustible materials. Do not place it directly under a power outlet.
3. **Power Connection:** Ensure the power cord is fully extended and not tangled. Plug the heater directly into a suitable 230V AC wall socket. Do not use extension cords or multi-plugs.
4. **Adjustable Height:** The RX7 comes with an adjustable height setting for your convenience. Adjust the height as needed to direct warmth effectively.



Image: Bajaj Majesty RX 7 Room Heater in a living room setting, showcasing its compact design.

4. Operating Instructions

The Bajaj Majesty RX 7 offers personalized comfort with its three heat settings.

1. **Power On:** Plug the heater into a suitable power outlet. Turn the main power switch to the 'ON' position.
2. **Select Heat Setting:** Use the control knob to select your desired heat output:
    - **600W:** For low heat and energy efficiency.
    - **1200W:** For medium heat.
    - **2000W:** For maximum heat and instant warmth.
3. **Adjust Thermostat (if available):** If your model includes a thermostat, turn the thermostat knob clockwise to increase the temperature setting or counter-clockwise to decrease it. The heater will cycle on and off to maintain the set temperature.

4. **Power Off:** To turn off the heater, turn the heat setting knob to 'OFF' and then unplug the unit from the wall socket.



Image: Close-up of the control knobs for heat settings and power on the heater.

Your browser does not support the video tag.

Video: A short overview of the Bajaj Majesty RX 7 2000 Watts Heat Convector Room Heater, highlighting its features and ease of use.

5. Maintenance

Regular maintenance ensures the longevity and efficient operation of your heater.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Air Vents:** Periodically clean the air intake and exhaust vents to ensure proper airflow. Use a vacuum cleaner with a brush attachment to remove dust and debris.
- **Storage:** When not in use, store the heater in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.



Image: Close-up of the heater's grille, illustrating the air vents that require periodic cleaning.

6. Troubleshooting

If you encounter any issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Thermal cut-out activated.	Check if the heater is properly plugged in and the power outlet is working. Unplug the heater, let it cool for 10-15 minutes, then plug it back in.
Heater is not heating effectively.	Incorrect heat setting. Room size too large. Blocked air vents.	Ensure the highest heat setting (2000W) is selected. This heater is suitable for rooms up to 150 sqft. Clean air vents as per maintenance instructions.
Heater suddenly turns off.	Overheating (thermal cut-out).	This is a safety feature. Unplug the heater, allow it to cool down for 10-15 minutes, and ensure air vents are not blocked. Then plug it back in.

If the problem persists after trying these solutions, please contact Bajaj customer support.

7. Specifications

Feature	Detail
Brand	Bajaj
Model Number	260023 (RX 7)
Special Feature	Adjustable Height, Auto Thermal Shutoff, Cool Touch Handle
Colour	Black
Form Factor	Cabinet
Indoor/Outdoor Usage	Indoor
Product Dimensions	22D x 18W x 10H Centimeters
Recommended Uses	Home (Bedroom, Home Office, Study Room)
Mounting Type	Floor Mount
Heating Coverage	150 sqft
Burner Type	Radiant

Feature	Detail
Voltage	230 Volts
Item Weight	3 kg 860 g
Net Quantity	1.00 Count



Image: Product dimensions of the Bajaj Majesty RX 7 heater.

8. Warranty and Support

The Bajaj Majesty RX 7 Heat Convector Room Heater comes with a 2-year warranty, ensuring peace of mind regarding its quality and performance.
For any product-related queries, service requests, or technical support, please contact Bajaj customer service. Refer to the product packaging or Bajaj's official website for the most up-to-date contact information.

Your browser does not support the video tag.

Video: A detailed look at the features and benefits of the Bajaj Majesty RX 7 Room Heater.

© 2026 Bajaj. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009P2LIA0

More documents and user manuals: **https://manuals.plus/**