Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bajaj Majesty 700 QT

Bajaj Majesty 700 QT 600-Watt Oven Toaster Griller User Manual

Model: Majesty 700 QT

1. Important Safety Instructions

Please read all instructions carefully before using this appliance. Retain this manual for future reference.

- Always ensure the appliance is placed on a stable, heat-resistant surface, away from flammable materials.
- Do not touch hot surfaces. Use oven mitts or gloves when handling hot items or parts.
- To protect against electrical shock, do not immerse the cord, plug, or any part of the appliance in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Do not use the appliance for other than intended household use.
- Oversized foods or metal utensils must not be inserted into the oven toaster griller as they may create a fire or risk of electric shock.
- A fire may occur if the oven toaster griller is covered or touching flammable material, including curtains, draperies, walls, and the like, when in operation.
- Do not place any materials other than manufacturer's recommended accessories in this oven.
- Do not place paper, cardboard, plastic, or similar products in the oven.
- Do not store any materials, other than manufacturer's recommended accessories, in this oven when not in use.

2. Product Overview

The Bajaj Majesty 700 QT is a compact 600-Watt Oven Toaster Griller designed for various cooking tasks such as toasting, grilling, and baking. It features a 7-liter capacity, temperature control, and a timer for precise cooking.



An image showing the Bajaj Majesty 700 QT Oven Toaster Griller from the front, highlighting its compact design, control knobs, and glass door.

3. Components

The Bajaj Majesty 700 QT Oven Toaster Griller typically includes the following components:

- Oven Toaster Griller Unit
- Grill Rack
- Baking Tray
- Crumb Tray (removable)
- Instruction Manual

4. Setup

1. **Unpacking:** Carefully remove the appliance and all accessories from the packaging. Dispose of packaging materials responsibly.
2. **Placement:** Place the oven toaster griller on a flat, stable, heat-resistant surface. Ensure there is adequate

clearance (at least 10-15 cm) on all sides and above the unit for proper ventilation. Do not place it near walls, curtains, or under cabinets.

3. **First Use Cleaning:** Before first use, wipe the interior and accessories with a damp cloth. Ensure all parts are dry before plugging in.
4. **Initial Burn-off:** It is recommended to run the oven empty for about 10-15 minutes at the highest temperature setting (250°C) to burn off any manufacturing residues. A slight odor or smoke may be present during this process; ensure the area is well-ventilated.
5. **Power Connection:** Plug the power cord into a standard electrical outlet. Ensure the voltage matches the appliance's requirements.

5. Operating Instructions

The Bajaj Majesty 700 QT features simple knob controls for temperature and timer settings.

5.1 Control Knobs

- **Temperature Control Knob:** Used to select the desired cooking temperature, typically ranging from 100°C to 250°C.
- **Timer Knob:** Used to set the cooking duration, usually up to 60 minutes. The oven will automatically switch off once the timer reaches zero.

5.2 General Operation

1. Place food on the grill rack or baking tray. Ensure the tray/rack is properly inserted into the oven.
2. Close the dropdown door securely.
3. Turn the **Temperature Control Knob** to the desired temperature setting for your recipe.
4. Turn the **Timer Knob** to the desired cooking time. The oven will begin heating. A pilot light may illuminate to indicate operation.
5. When the set time elapses, the oven will automatically switch off, and a bell sound may indicate completion.
6. Carefully open the door and remove the cooked food using oven mitts.

5.3 Specific Cooking Functions

- **Toasting:** Place bread slices on the grill rack. Set temperature to 200-220°C and timer for 3-5 minutes, or until desired crispness is achieved.
- **Grilling:** Use the grill rack for items like vegetables or small meat portions. Set temperature to 220-250°C. Monitor closely to prevent burning.
- **Baking:** Use the baking tray for small cakes, cookies, or reheating. Set temperature according to the recipe.

6. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your appliance.

1. **Always unplug the oven toaster griller**from the power outlet and allow it to cool completely before cleaning.
2. **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
3. **Interior:** Wipe the interior walls with a damp cloth and mild detergent. For stubborn stains, a non-abrasive cleaner can be used. Ensure to wipe off all detergent residue.

4. **Crumb Tray:** Pull out the crumb tray from the bottom of the oven. Discard crumbs and wash the tray in warm, soapy water. Rinse and dry thoroughly before reinserting.
5. **Grill Rack and Baking Tray:** These accessories can be washed in warm, soapy water. For baked-on food, soak them before cleaning. Rinse and dry completely.
6. **Glass Door:** Clean the glass door with a glass cleaner or a damp cloth. Avoid harsh chemicals that could damage the glass or seals.
7. Do not immerse the main unit, cord, or plug in water or any other liquid.

7. Troubleshooting

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outage; timer not set.	Ensure the plug is securely in the outlet. Check household circuit breaker. Turn the timer knob to the desired cooking time.
Food not cooking evenly.	Incorrect temperature setting; uneven food placement; door not fully closed.	Adjust temperature. Ensure food is spread evenly. Check that the door is securely closed.
Excessive smoke during operation.	Food residue or grease buildup; fatty food.	Unplug and allow to cool. Clean the interior and crumb tray thoroughly. Reduce fat content in food or use a drip tray.
Timer not working.	Timer knob malfunction.	If the timer knob does not engage or advance, contact customer support.

8. Specifications

Key technical specifications for the Bajaj Majesty 700 QT Oven Toaster Griller:

Feature	Specification
Brand	Bajaj
Model Name	Majesty 700 QT
Capacity	7 litres
Power Consumption	600 Watts
Control Type	Knob
Special Features	Temperature Control, Timer
Door Style	Dropdown Door
Door Material	Tempered Glass
Item Weight	2 kg 840 g

Feature	Specification
Colour	Black

9. Warranty and Support

This product is covered under the guarantee/warranty provided by Bajaj Electricals Limited. The specific period and terms are printed on the Guarantee/Warranty Card included with your product. Please retain your VAT paid Bill and the stamped Guarantee/Warranty Card as they are necessary documents to avail service.
For any service-related queries or assistance, please contact Bajaj Customer Care:

- **Toll-Free Number:** 022-41280000
- **Operating Hours:** 9:00 AM to 6:00 PM (IST)

Depending on your city's service facility, your product may be repaired at your premises, or you may need to deliver it to the nearest local service center at your cost. After the guarantee/warranty period, you can still avail servicing facilities from the same toll-free number by paying the prescribed charges.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B009P2LQKW

More documents and user manuals: **https://manuals.plus/**