Bajaj ICX 21

Bajaj Majesty ICX 21 2000-Watt Induction Cooktop User Manual

Model: ICX 21 | Brand: Bajaj

1. Introduction

Thank you for choosing the Bajaj Majesty ICX 21 Induction Cooktop. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read these instructions carefully before using the cooktop and retain them for future reference.

2. Important Safety Instructions

WARNING: To reduce the risk of fire, electric shock, or injury, observe the following:

- Always ensure the cooktop is placed on a stable, flat, and heat-resistant surface.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children. Close supervision is necessary when the appliance is used near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer service for examination, repair, or adjustment.
- Use only induction-compatible cookware. Non-compatible cookware will not heat.
- Do not place metallic objects such as knives, forks, spoons, lids, cans, or aluminum foil on the induction cooktop as they can become hot.
- Individuals with pacemakers or similar medical devices should consult their doctor before using an induction cooktop.
- Ensure proper ventilation around the cooktop during operation.

3. Product Overview

The Bajaj Majesty ICX 21 is a 2000-watt induction cooktop designed for efficient and quick cooking. It features a sleek design with feather-touch controls and a digital display.



Figure 1: Bajaj Majesty ICX 21 Induction Cooktop. This image shows the overall design of the cooktop, including the cooking surface and the control panel.

3.1 Components

- **Induction Cooking Surface:** The area where induction-compatible cookware is placed.
- **Control Panel:** Feather-touch buttons and digital display for operation.
- **Power Cord:** For connecting to an electrical outlet.
- **Ventilation Openings:** Located on the bottom and sides for heat dissipation.

3.2 Control Panel Features

- **Power Button:** To turn the cooktop ON/OFF.
- **Digital Display:** Shows temperature, wattage, timer, and error codes.
- **Preset Menu Buttons:** Six dedicated buttons for various cooking functions.
- **Temperature/Wattage Adjustment Buttons:** For increasing or decreasing heat settings.
- **Timer Button:** To set the cooking timer.
- **Delay Start Button:** To program a delayed start.

- **Child Lock Button:** To prevent accidental operation.

4. Setup

1. **Unpacking:** Carefully remove the cooktop from its packaging. Retain packaging for future transport or storage.
2. **Placement:** Place the induction cooktop on a dry, stable, and level surface. Ensure there is adequate space (at least 10-15 cm) around the cooktop for proper ventilation. Do not place it near heat sources or on metallic surfaces that could interfere with induction.
3. **Power Connection:** Plug the power cord into a standard 230V AC electrical outlet. Ensure the outlet is properly grounded and can support a 2000-watt appliance.

5. Operating Instructions

5.1 Cookware Compatibility

The Bajaj Majesty ICX 21 requires induction-compatible cookware. Look for cookware with a flat bottom and a magnetic base. Test compatibility by placing a magnet on the bottom of the pot; if it sticks, the cookware is compatible.

- **Compatible:** Cast iron, enamel iron, stainless steel (magnetic grade), flat-bottomed pans/pots with a diameter of 12-26 cm.
- **Not Compatible:** Ceramic, glass, aluminum, copper, non-magnetic stainless steel, round-bottomed pans, or pans with feet.

5.2 Basic Operation

1. Place induction-compatible cookware with food on the center of the cooking surface.
2. Plug in the appliance. The digital display will show "OFF" or a similar standby indicator.
3. Press the **Power** button to turn on the cooktop. The display will light up.
4. Select a cooking function:
    - **Preset Menus:** Press one of the six preset menu buttons (e.g., "Curry", "Fry", "Milk", "Dosa", "Roti", "Idli"). The cooktop will automatically adjust to a predefined power/temperature setting.
    - **Manual Adjustment:** If not using a preset, use the **Temperature/Wattage Adjustment** buttons ('+' and '-') to set your desired power level or temperature.
5. To turn off the cooktop, press the **Power** button again. The fan may continue to run for a short period to cool down the internal components.

5.3 Using the Timer Function

The timer function allows you to set a cooking duration, after which the cooktop will automatically shut off.

1. With the cooktop operating, press the **Timer** button.
2. Use the **Temperature/Wattage Adjustment** buttons ('+' and '-') to set the desired cooking time.
3. The timer will start counting down. Once the time expires, the cooktop will automatically switch off.

5.4 Using the Delay Start Function

The delay start function allows you to program the cooktop to start cooking at a later time.

1. In standby mode (cooktop plugged in but off), press the **Delay Start** button.

2. Use the **Temperature/Wattage Adjustment** buttons ('+' and '-') to set the desired delay time.
3. After setting the delay, select your desired cooking function (preset or manual). The cooktop will start operating after the delay time has elapsed.

5.5 Child Lock Function

The child lock prevents accidental changes to settings or operation, ensuring safety.

- To activate: While the cooktop is operating, press and hold the **Child Lock** button for a few seconds until a lock indicator appears on the display.
- To deactivate: Press and hold the **Child Lock** button again for a few seconds until the lock indicator disappears.

6. Maintenance and Care

Proper care ensures the longevity and optimal performance of your induction cooktop.

1. **Cleaning the Surface:**
    - Always unplug the cooktop and allow it to cool completely before cleaning.
    - Wipe the ceramic glass surface with a soft, damp cloth and mild detergent.
    - For stubborn stains, use a non-abrasive ceramic cooktop cleaner.
    - Do not use abrasive pads, harsh chemicals, or steel wool, as they can scratch the surface.
2. **Cleaning the Body:** Wipe the exterior body with a soft, damp cloth. Do not allow water to enter the ventilation openings.
3. **Storage:** When not in use for extended periods, clean the cooktop and store it in a dry, safe place, away from direct sunlight and moisture.

7. Troubleshooting

If you encounter issues with your cooktop, refer to the table below for common problems and their solutions.

Error Code	Reason	Actionable Solution
Beep Alarm	No vessel / Unsuitable vessel	Place an induction-compatible vessel at the center of the plate.
E1	Abnormal supply voltage (more than 275V)	Switch on the unit after power supply is back to normal (i.e., less than 230V).
E2	Abnormal supply voltage (less than 100V)	Switch on the unit after power supply is back to normal (i.e., 230V).
E3	Temperature of IGBT is too high. IGBT temperature sensor is short or open circuit.	Take the unit to the nearest service center for adjustment/repair.
E7	Temperature under the pot is too high.	Allow the induction cooktop to cool down, then resume operation.
E8	Temperature sensor under the plate is defective.	Contact Bajaj customer care.

For issues not listed above or if the problem persists, please contact customer support.

8. Specifications

Feature	Detail
Model	ICX 21
Brand	Bajaj
Power Consumption	2000 Watts
Voltage	230 Volts
Control Type	Feather Touch
Heating Elements	1
Special Features	Digital Display, Portable, Timer, 6 Preset Cooking Menus, Delay Start, Auto Shut Off, Child Lock
Item Weight	2.74 kg
Model Number (Part No.)	100000092

9. Warranty and Support

9.1 Warranty Information

This Bajaj Majesty ICX 21 Induction Cooktop comes with a**2-year warranty** on the product from the date of purchase. Please retain your purchase receipt for warranty claims. The warranty covers manufacturing defects under normal use conditions. It does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

9.2 Customer Support

For any queries, service requests, or technical assistance, please contact Bajaj customer care:

- **Customer Service Number:** 18001025963
- Please have your product model number (ICX 21) and purchase details ready when contacting support.

© 2023 Bajaj. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question