Technivorm Moccamaster 59618 KBG

Technivorm Moccamaster 59618 KBG 10-Cup Coffee Maker Instruction Manual

1. Introduction

This manual provides essential information for the safe and efficient operation of your Technivorm Moccamaster 59618 KBG 10-Cup Coffee Maker. Please read these instructions carefully before first use and retain for future reference.

The Moccamaster KBG is designed to brew a full 40 oz (10-cup) pot of coffee in approximately six minutes. It features a glass carafe and an automatic drip-stop brew-basket. The integrated hot-plate maintains coffee temperature between 175°F and 185°F and automatically turns off after 100 minutes.

Image 1.1: Technivorm Moccamaster 59618 KBG 10-Cup Coffee Maker, Red Metallic. This image shows the complete coffee maker unit, including the water reservoir, brew basket, and glass carafe.

Key Features:

- **Optimal Brewing Temperature:** Heats water to the ideal temperature for coffee extraction without a pump.
- **Efficient Brewing:** Brews a full 40 oz pot in 4-6 minutes.
- **Automatic Drip-Stop:** Brew-basket stops coffee flow when the carafe is removed.
- **Temperature Control:** Hot-plate with two settings (175°F and 185°F) to maintain coffee temperature.
- **Safety Shut-off:** Hot-plate automatically turns off after 100 minutes.
- **Durable Construction:** Made with BPA/BPS/BPF & Phthalate-free plastics, stainless steel, and aluminum.

Image 1.2: Specialty Coffee Association Certified Home Brewer logo. This logo indicates that the coffee maker meets rigorous standards for quality and brewing performance.

Note: No official product videos were available from the seller for embedding in this manual.

2. Setup

2.1 Unpacking and Component Identification

Carefully remove all components from the packaging. Ensure you have the following:

- Moccamaster Brewer unit
- Glass Carafe
- Brew basket
- Water reservoir lid
- Brew basket lid
- 9-hole outlet arm
- Owner's manual (this document)

2.2 Initial Cleaning

Before first use, wash the glass carafe, brew basket, and lids with warm, soapy water. Rinse thoroughly and dry. Wipe the exterior of the brewer unit with a damp cloth.

2.3 Placement

Place the coffee maker on a flat, stable, and heat-resistant surface. Ensure there is adequate clearance around the unit for ventilation and to prevent heat buildup.

2.4 First Brew Cycle (Cleaning Cycle)

1. Fill the water reservoir with fresh, cold water up to the 10-cup mark.
2. Place an empty paper filter (size #4 cone filter) into the brew basket.
3. Ensure the brew basket is correctly seated and the glass carafe is in place on the hot-plate.
4. Press the power switch to begin the brewing cycle.
5. Allow the full cycle to complete. Discard the water from the carafe and the used filter.

Image 2.1: Pouring water into the Moccamaster water reservoir. The reservoir has clear markings for precise measurement.

3. Operating Instructions

3.1 Preparing for Brewing

1. **Add Water:** Fill the water reservoir with fresh, cold water to your desired level (up to the 10-cup maximum).
2. **Insert Filter:** Place a new #4 cone paper filter into the brew basket.
3. **Add Coffee Grounds:** Add your preferred amount of medium-ground coffee to the filter. A common recommendation is 55-60 grams of coffee per liter (approximately 10 cups). Adjust to taste.
4. **Assemble:** Ensure the brew basket is properly seated under the 9-hole outlet arm and the glass carafe is placed on the hot-plate.

Image 3.1: Close-up of the Moccamaster brew basket. This image highlights the design of the brew basket, ready for a coffee filter and grounds.

3.2 Starting the Brew Cycle

1. Plug the coffee maker into a grounded electrical outlet.
2. Press the main power switch (usually marked with a power symbol) to begin brewing. The indicator light will illuminate.
3. Hot water will be dispensed over the coffee grounds, and brewed coffee will drip into the glass carafe.

Image 3.2: Water dripping onto coffee grounds in the Moccamaster brew basket. This illustrates the precise saturation of coffee grounds during the brewing process.

3.3 Hot-Plate Operation

The hot-plate automatically activates after brewing to keep your coffee warm. It has two temperature settings:

- **Low Setting:** Maintains coffee at approximately 175°F.
- **High Setting:** Maintains coffee at approximately 185°F.

Select your desired setting using the hot-plate switch. The hot-plate will automatically shut off after 100 minutes for safety and energy conservation.

3.4 After Brewing

Once brewing is complete, you can remove the carafe to pour coffee. The automatic drip-stop will prevent coffee from dripping from the brew basket. Replace the carafe on the hot-plate to keep the remaining coffee warm.

4. Maintenance

4.1 Daily Cleaning

- After each use, discard the used coffee grounds and paper filter.
- Wash the glass carafe, brew basket, and lids with warm, soapy water. These parts are generally top-rack dishwasher safe, but hand washing is recommended for longevity.
- Wipe down the exterior of the brewer unit with a soft, damp cloth. Do not immerse the main unit in water.

4.2 Descaling

Mineral deposits (limescale) can build up over time, affecting performance and coffee taste. Descale your Moccamaster regularly, depending on your water hardness (e.g., every 1-3 months).

1. Use a descaling solution specifically designed for coffee makers, following the product's instructions. Alternatively, a solution of white vinegar and water (1 part vinegar to 2 parts water) can be used.
2. Fill the water reservoir with the descaling solution.
3. Place an empty paper filter in the brew basket and the carafe on the hot-plate.
4. Run a full brewing cycle.
5. After the cycle, discard the solution.
6. Rinse the unit by running two full cycles with fresh, cold water to remove any residual descaling solution.

4.3 Material Information

The Technivorm Moccamaster is constructed with durable metal housings and BPA/BPS/BPF & Phthalate-free plastics, ensuring safety and longevity.

5. Troubleshooting

If you encounter issues with your coffee maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Coffee not brewing	Not plugged in; power switch off; water reservoir empty; carafe not in place.	Ensure unit is plugged in and power switch is on. Fill water reservoir. Confirm carafe is correctly positioned on the hot-plate.
Weak coffee	Insufficient coffee grounds; coffee too coarsely ground; old coffee.	Increase amount of coffee grounds. Use a medium grind. Use fresh coffee beans.
Coffee overflows from brew basket	Too much coffee grounds; filter clogged; brew basket not seated correctly.	Reduce coffee grounds. Ensure filter is not collapsed. Clean brew basket. Ensure brew basket is properly aligned.
Slow brewing	Mineral buildup (limescale).	Perform a descaling cycle as described in Section 4.2.
Coffee not hot enough	Hot-plate setting too low; hot-plate automatically shut off.	Adjust hot-plate to high setting. Note that the hot-plate turns off after 100 minutes.

If the problem persists after attempting these solutions, please contact Technivorm Moccamaster customer support.

6. Specifications

Specification	Detail
Brand	Technivorm Moccamaster
Model Name	59618 KBG
Color	Red Metallic
Coffee Maker Type	Drip Coffee Machine
Capacity	10-Cup (40 oz)
Operation Mode	Fully Automatic
Voltage	120 Volts
Product Dimensions	6.5 x 12.7 x 14 inches
Item Weight	6.26 pounds

Specification	Detail
Included Components	Moccamaster Brewer, Glass Carafe, Brew Basket, Water Reservoir Lid, Brew Basket Lid, 9-Hole Outlet Arm, Owner's Manual
UPC	793842103724, 781147931449, 735343126024

7. Warranty and Support

7.1 Product Warranty

The Technivorm Moccamaster 59618 KBG Coffee Maker is backed by an industry-leading**5-year warranty**. This warranty covers defects in materials and workmanship under normal use.

Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your product or visit the official Technivorm Moccamaster website.

7.2 Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty service, please contact Technivorm Moccamaster customer support. Contact information can typically be found on the manufacturer's website or on the product packaging.

© Technivorm Moccamaster. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question